



TOTO

SoftClose® Toilet Seat
Asiento de inodoro SoftClose®
Siège de toilette SoftClose®
0GU543

Installation Manual Manual de instalación Manuel d'Installation



Contents:

SoftClose® toilet seat, 1
(A) Anchors, 2
(B) Lock washers, 2
(C) Round washers, 2
(D) Screws, 2
(E) Bracket covers, 2

Required tools:

Flathead screwdriver

Contenido:

Asiento de inodoro SoftClose®, 1
(A) Anclajes, 2
(B) Arandelas de seguridad, 2
(C) Arandelas redondas, 2
(D) Tornillos, 2
(E) Cubiertas del soporte, 2

Herramientas necesarias:

destornillador de cabeza plana


Contenu :

Siège de toilette SoftClose®, 1
(A) Ancrages, 2
(B) Rondelles de blocage, 2
(C) Rondelles rondes, 2
(D) Vis, 2
(E) Couvercles du Support, 2

Outils Nécessaires :

Tournevis à tête plate

1



Insert the anchors (A) into the bowl seat holes.

NOTICE: Do not push anchors all the way through the holes of the bowl. If this notice is disregarded, you can lose the anchors.


Inserte los anclajes (A) en los orificios del asiento del inodoro.

AVISO: No empuje los anclajes a través de los orificios del asiento de la taza. Si no se tiene en cuenta este aviso, puede perder las anclas.

Insérez les ancrages (A) dans les trous de siège de la cuvette.

AVIS : Ne pas pousser les ancras tout au long des trous du siège du bol. Si cet avis n'est pas pris en compte, vous pouvez perdre les ancras.

2




Put seat on toilet bowl so that the hinge holes are centered with the holes in the bowl and the seat covers the entire surface with a slight overhang.

Coloque el asiento en la taza del inodoro para que los orificios del bisagra estén centrados con los agujeros en la taza y el asiento cubra toda la superficie con un ligero saliente.

Placez le siège sur la cuvette de toilette afin que les trous de charnière soient centrés sur les trous dans la cuvette, et que le siège couvre toute la surface avec un léger surplomb.

3

concave points facing up
puntos cóncavos hacia arriba
points concaves vers le haut




Place the lock washers (B) onto the hinge holes and make sure the concave points face up when placing.

Coloque las arandelas de seguridad (B) en los orificios de bisagra y asegúrese de que los puntos cóncavos hacia arriba al colocar.

Placez les rondelles de blocage (B) sur les trous de charnière et s'assurez que des points concaves face vers le haut lors du placement.

4




Place round washers (C) onto the lock washers (B). Insert the screws (D) into the holes and tighten with a screwdriver until seat is secure and immobile. **NOTICE:** Do not overtighten screw. If this notice is disregarded, you will damage the hinge.

Coloque las arandelas redondas (C) en las arandelas de seguridad (B). Inserte los tornillos (D) en los orificios y apriete con el destornillador hasta que el asiento esté seguro e inmóvil. **AVISO:** No apriete demasiado el tornillo. Si este aviso no se tiene en cuenta, dañará la bisagra.

Placez les rondelles rondes (C) sur les rondelles de blocage (B). Insérez les vis (D) dans les trous et serrez avec le tournevis jusqu'à ce que le siège soit sécurisé et immobile. **AVIS :** Ne pas trop serrer la vis. Si cet avis n'est pas pris en compte, vous endommageriez la charnière.

5




release paper
papel antiadhesivo
papier anti-adhésif

Remove the release paper from the bracket cover (E).

Retire el papel antiadhesivo de la cubierta del soporte (E).

Retirez le papier anti-adhésif du couvercle du support (E).


6



Place the bracket cover (E) onto the corresponding holes of the hinges and tighten them.

Coloque la cubierta del soporte (E) en los orificios correspondientes del bisagra y apretarlos.

Placer le couvercle du support (E) sur les trous correspondants des charnières et serrez-les.



Exploded view
Vista en despiece ordenado
Vue éclatée

Warranty

1. TOTO warrants its toilet seats ("Product") to be free from defects in materials and workmanship during normal use when properly installed and serviced, for a period of one (1) year from date of purchase. This limited warranty is extended only to the ORIGINAL PURCHASER of the Product and is not transferable to any third party, including but not limited to any subsequent purchaser or owner of the Product. This warranty applies only to TOTO Product purchased and installed in North, Central and South America.

2. TOTO's obligations under this warranty are limited to repair, replacement or other appropriate adjustment, at TOTO's option, of the Product or parts found to be defective in normal use, provided that such Product was properly installed, used and serviced in accordance with instructions. TOTO reserves the right to make such inspections as may be necessary in order to determine the cause of the defect. TOTO will not charge for labor or parts in connection with warranty repairs or replacements. TOTO is not responsible for the cost of removal, return and/or reinstallation of the Product.

3. This warranty does not apply to the following items:

- a. Damage or loss sustained in a natural calamity such as fire, earthquake, flood, thunder, electrical storm, etc.
- b. Damage or loss resulting from any accident, unreasonable use, misuse, abuse, negligence, or improper care, cleaning, or maintenance of the Product.
- c. Damage or loss resulting from sediments or foreign matter contained in a water system.
- d. Damage or loss resulting from improper installation or from installation of the Product in a harsh and/or hazardous environment, or improper removal, repair or modification of the Product. (NOTE: Product model codes allow a maximum of 80 PSI. Check local codes or standards for requirements).
- e. Damage or loss resulting from electrical surges or lightning strikes or other acts which are not the fault of TOTO or which the Product is not specified to tolerate.
- f. Damage or loss resulting from normal and customary wear and tear, such as gloss reduction, scratching or fading over time due to use, cleaning practices or water or atmospheric conditions.

4. In order for this limited warranty to be valid, proof of purchase is required. TOTO encourages warranty registration upon purchase to create a record of Product ownership at <http://www.totousa.com>. Product registration is completely voluntary and failure to register will not diminish your limited warranty rights.

5. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE, PROVINCE TO PROVINCE OR COUNTRY TO COUNTRY.

6. To obtain warranty repair service under this warranty, you must take the Product or deliver it prepaid to a TOTO service facility together with proof of purchase (original sales receipt) and a letter stating the problem, or contact a TOTO distributor or products service contractor, or write directly to TOTO U.S.A., INC., 1155 Southern Road, Morrow, GA 30260, or call (888) 295 8134 or (678) 466-1300, if outside the U.S.A. If, because of the size of the Product or nature of the defect, the Product cannot be returned to TOTO, receipt by TOTO of written notice of the defect together with proof of purchase (original sales receipt) shall constitute delivery. In such case, TOTO may choose to repair the Product at the purchaser's location or pay to transport the Product to a service facility.

THIS WRITTEN WARRANTY IS THE ONLY WARRANTY MADE BY TOTO. REPAIR, REPLACEMENT OR OTHER APPROPRIATE ADJUSTMENT AS PROVIDED UNDER THIS WARRANTY SHALL BE THE EXCLUSIVE REMEDY AVAILABLE TO THE ORIGINAL PURCHASER. TOTO SHALL NOT BE RESPONSIBLE FOR LOSS OF THE PRODUCT OR FOR OTHER INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OR EXPENSES INCURRED BY THE ORIGINAL PURCHASER, OR FOR LABOR OR OTHER COSTS DUE TO INSTALLATION OR REMOVAL, OR COSTS OF REPAIRS BY OTHERS, OR FOR ANY OTHER EXPENSE NOT SPECIFICALLY STATED ABOVE. IN NO EVENT WILL TOTO'S RESPONSIBILITY EXCEED THE PURCHASE PRICE OF THE PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTIES, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR USE OR FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION AND EXCLUSION MAY NOT APPLY TO YOU.

WARNING! TOTO shall not be responsible or liable for any failure of, or damage to, this Product caused by either chloramines in the treatment of public water supply or cleaners containing chlorine (calcium hypochlorite). NOTE: The use of a high concentrate chlorine or chlorine related products can seriously damage the fittings. This damage can cause leakage and serious property damage.

For your safety, read these instructions

To ensure your TOTO seat installation is completed correctly, please carefully read the instructions in this manual.

Use the following safety precautions for your personal safety and to protect your seat or toilet from potential damage.

 **Caution** Comply with all instructions preceded by this Caution symbol to avoid potential dangers or damages.

The $\oslash$ symbol indicates prohibited actions that must be avoided.

 Caution	 Do not stand on the toilet seat or put heavy items on it. This may scratch or break the seat. 
	 Do not use bleach, chemical thinners, cleaners with acids or alkaline detergents, metal scrub brushes, steel wool, polishing powders, or detergents with gritty or coarse particles to clean the seat. This will scratch, damage, or discolor the seat. For most cleaning, only use a soft wet cloth. 
	 Do not allow children to play with the seat. A falling seat could hurt their hands. 
 Caution: Do not allow children to use the seat unattended.	


Repair Instructions

1. If the seat does not fit the toilet properly, check the screws for looseness. To correct, follow the instructions in the installation manual to tighten them. If this does not fix the problem, please contact customer service for assistance.
2. Please contact customer service if the seat or components are damaged or defective.

Notice




Do not open or close the seat with excessive force, or the seat or toilet may break.



Do not expose the seat to direct sunlight, or it may become discolored.

- Open the seat and lid completely, otherwise when you let go, it could fall suddenly and hurt you.
- Please read the sheath instruction manual when putting the sheath on the seat. Note that sheaths purchased by other manufacturers may not fit the seat.
- If disposing of the product, do not throw away with your regular trash. Follow your local laws and regulations to responsibly recycle the product.

Maintenance




1. Periodic Cleaning

Wipe gently with a soft wet cloth.

2. Deep Cleaning

- Use a neutral detergent (such as diluted dish soap) on a soft wet cloth to clean, then dry with a soft clean cloth.
- Do not use metal scrub brushes, steel wool, polishing powders, or detergents with gritty or coarse particles.
- Do not use bleach, chemical thinners, or products with acids or alkaline detergents.
- Please note that bathroom chemicals and cosmetics can damage the seat.



Toilet seat specification:

Length*width*height: 514mm*357mm*60mm (20.2 in*14in*2.4in)

Weight: 2.2kg (4.9 Lb)