


FLOOR LAMP

WITH 350° ROTATION REMOTE CONTROL


User Manual



Thank you for choosing JACKYLED! Please read this user manual carefully and thoroughly to ensure your safe and proper use of the product. If you need any help, please feel free to contact our customer service at service@jackyled.net.

PACKAGE CONTENTS

Paketliste




A. Lampe × 1



B. Fernbedienung × 1



C. Basis × 1



D. Netzteil mit Kabel × 1

*Note: Remote-control batteries are not included. The remote control requires two AAA batteries.

-1-

SPECIFICATIONS

Product Name	Floor Lamp
Model	JKFL23
Power	36W
Luminous Flux	3200lm
Input Voltage	110-240V 50/60Hz
Dimmable	Yes
Color Temperature	3000K-6500K
Control	Remote control and touch control
Rotation	350° rotation


CHARACTERISTICS

- Color temperatures from 3000K to 6500K.
- Stepless dimming for flexible brightness control.
- Remote control and touch control are supported.
- Adjustable lamp head with 350° rotation.
- Easy to assemble with a stable, safe base.
- 1-hour timer setting.
- Memory function.
- Multiple modes: Working Mode, Reading Mode, Night Light Mode, and Breastfeeding Mode.

-2-

INSTALLATION STEPS

- 1.Make sure the lamp is unplugged before assembly.
- 2.Connect the tube to the lamp head by turning it clockwise.
- 3.Connect the tube to the other tubes by turning them clockwise.
- 4.Finally connect the tube to the lamp base by turning it clockwise.
- 5.After installation is finished, plug in the power adapter. You can then control the light by touch control or by remote control.
- 6.Do not overtighten the tubes or poles, as this may damage the mounting.




*Tip: Place all parts on a clean, flat surface during assembly. Adjust the lamp head gently and keep the base stable.

-3-

ADJUSTMENT

The diagram below shows the main product dimensions, touch-control position, remote-control key reference, and 350° lamp-head rotation.



*The lamp head can rotate 350°. Adjust the lamp head slowly and avoid forcing it beyond its designed rotation range.

-4-


REMOTE CONTROL

Model
NS-RF1501-FCC-433

The remote control requires two AAA batteries. Batteries are not included.

CHARACTERISTICS

- No pairing is required before normal use.
- The back of the remote control is magnetic and can be attached to the floor lamp pole or another metal object.



-5-

Button	Function
ON/OFF	Turn the lamp on or off.
1H Timer	Set the lamp to turn off after 1 hour.
Brightness +/-	Long press to smoothly increase or decrease brightness. Short press to increase or decrease the brightness by 20% each time.
100% Brightness	Set brightness to 100%.
Color Temperature +/-	Long press to smoothly increase or decrease color temperature. Short press to increase or decrease the color temperature by 20% each time.
Color Temperature Adjustment (K)	Cycle through 3000K / 3500K / 4000K / 5000K / 6500K.
Night Light Mode	3000K, 10% brightness.
Breastfeeding Mode	3000K, 50% brightness.
Reading Mode	4000K, 50% brightness.
Working Mode	6500K, 100% brightness.
Indicator Light	Shows remote-control input and pairing status.

PAIRING

If the remote control does not work, re-pair the remote control and floor lamp using the pairing method on the next page:

- Code pairing: Within 5 seconds after turning on the power, press and hold the key. The indicator light blinks twice, indicating successful code pairing.

-6-

WARNING

- Please cut off the power before installation or cleaning.
- Keep the lamp away from flammable materials and fire sources.
- The lamp is not waterproof. Use it indoors in a dry location only.
- Assemble the lamp according to the instructions and do not remodel it.
- Do not look directly at the lamp for a long time.

CARE & MAINTENANCE

- Always unplug the lamp from the power source before cleaning.
- Use a soft, dry cloth to clean the lamp. Avoid harsh chemicals or abrasive materials that may damage the surface.
- Periodically check and tighten all connections to maintain stability.
- When the lamp will not be used for an extended period, unplug the power adapter and store the lamp in a cool, dry place.

-7-

WARRANTY

The LED floor lamp comes with a 12-month product warranty. If there is a quality issue under normal use, please contact our customer service team with your order number. We will respond with prompt solutions within 24 hours. Accidental or intentional damage is not covered by the warranty.

ABOUT US

JACKYLED specializes in manufacturing advanced household charging and lighting products, and has provided excellent solutions to home improvement for over 10 years. We combine practicality and style in our products to make them a wonderful choice for improving your home and life quality.

QUESTION/PROBLEM?

We long to solve your problem and make you smile again. If you find the product not meeting your expectation, here's how we can connect:

service@jackyled.net

-8-



BY BRAND DESIGN

项目名称: JK朝天落地灯说明书

尺寸: 90*140 (mm)

印刷颜色: 四色印刷

材质及工艺: 120g书纸双面印刷+哑油

折叠方式: 风琴折

*包装设计类需先打样试装、过跌落测试后方可大货印刷

设计师: Fafa

日期: 2026-06-04

备注:

本品牌及其所使用的标志、名称、图像以及所有内容设计, 其版权均为本公司所拥有, 未经授权, 任何组织、个人、商业团体不得擅自使用、翻印, 本公司保留追究其法律责任的权力!

广州市磐世科技有限公司

NOTES

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment, This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The device can be used in portable exposure conditions without restriction.

FCC ID:2BWMO-NSRF1501