


# Sundu



## User Manual

1500W STEAM IRON

Thank you for choosing Sundu. We strive for the highest standards of quality and design, and we wish you much enjoyment with your new product. If you need any assistance please get in touch with our support team with your product model number and order number. Support and after-sale service: **support@sunduhome.com**

**Please read the user manual carefully before using the product.**

## ■ PACKAGE CONTENTS

Sundu 1500W Steam Iron x 1

Measuring Cup x 1

User Manual x 1

## ■ SPECIFICATIONS

Model	HJ-8065
Voltage	AC120V 60Hz
Power	1500W
Watertank Capacity	350mL
Weight	1102g
Power Cord Length	2.4m

## ■ GENERAL SAFETY INSTRUCTIONS


### Danger

- Do not immerse this product in water or other liquids, and do not rinse under the tap.
- Be careful of the hot steam produced by the table iron. Steam may cause burns.

### Warn



- Before connecting the product to the power supply, please check whether the standard voltage complies with the local supply voltage.
- Do not use the product if the plug, power cord or the product itself has been significantly damaged or the product has fallen or leaked.
- The product can only be sent to the authorized maintenance center for maintenance. Do not repair the product by yourself, otherwise the product maintenance guarantee will be invalid.
- If the power cord is damaged, it must be replaced by the manufacturer, its maintenance department or similar department professionals.
- User must not leave during product power up.
- This product is not suitable for use by children aged 8 years or older and people with unsound limbs, sensory or mental disabilities or lack of relevant experience and knowledge, unless someone supervises or guides them to use this product to ensure their safe use and make them aware of the associated hazards.
- Do not let children play with this product.
- When the product is energized or cooling, the product and its power cord should be placed out of the reach of children under 8.
- Children aged 8 years or older can clean this product only under supervision.
- Do not touch the steam holes and hot surfaces during use. This product will produce high temperature steam in the process of use, please do not aim at people and animals, and do not iron the clothes worn on the body, in order to avoid the danger of scald.
- Remove the power plug before cleaning the product or flooding the water tank.

## Pay Attention To

- Products can only use sockets with grounding.
- If the product is hot and connected to the power supply, do not let the steam nozzle contact with any surface when placing the product.
- Check the power cord regularly for damage.
- Do not let the power cord contact with the high temperature steam during the product operation.
- Do not use this product when the water tank is out of water.
- When you leave the product for a short time, please turn off the product power supply and unplug the power supply plug.
- After ironing, turn off the power and unplug it, and let it cool for 60 minutes before cleaning the product, emptying the tank or storing it.
- This product is limited to household use. Please do not use this product in the bathroom or outdoors.
- Do not drag the original product on the floor again.
- Steam may damage or cause some walls or doors to fade.
- By design, your product is suitable for using tap water. If the water in your area is very hard, scale may accumulate very quickly. Therefore, it is recommended that distilled water be injected into the tank to extend the service life of the product.
- Do not inject perfume, vinegar, detergent, ironing or other chemicals into the tank because this product is not suitable for these chemicals.
- When you first use the iron, you may notice slight smoke emissions and hear some swelling sounds. This was normal and stopped after a short time. We also recommend putting the iron on plain cloth before first use.
- The symbol "" means that the surface tends to heat up during use.

# ■ PRODUCT DIAGRAM

Synthetic  
 Silk  
 Wool  
 Cotton  
 Linen





- |                               |                                  |
|-------------------------------|----------------------------------|
| 1. Base Plate                 | 8. The Explosion Button          |
| 2. Thermal Baffle             | 9. Spray Button                  |
| 3. Bottom Cover Of Water Tank | 10. Temperature Knob             |
| 4. Blow Head                  | 11. Temperature Knob Coated Glue |
| 5. Water Box                  | 12. The Handle on The Cover      |
| 6. Add Water Cover            | 13. Tail-hood                    |
| 7. Steam Dial                 | 14. Line Cover                   |


## ■ OPERATION INSTRUCTIONS


### How to use the Steam Ironing?


1. After removing the product from the box, open the water cover, start adding water to the tank, add the water to the MAX position and close the water cover.





2. Plug the machine into the power supply, turn on the power supply, start heating, the red indicator light, the green indicator light that the heating is successful, the steam button dial to the right “”, the bottom plate to start steam, and then dial to the middle of the shutdown, the bottom plate to stop steam (Toggle to the far left without moving for the cleaning function, refer to section 5)




3. “” **Explosive Steam Method:** adjust the temperature knob to the maximum position and wait for the product to be heated is green indicator. To turn on the explosion steam function. If green not, the water flows directly out of the floor hole. When the heating is completed, press the explosion button every 2-3 seconds, the explosion button cannot be pressed when the red indicator is on, and the explosion steam can be reused when the green indicator. This explosion steam function can not be used at humans or animals to avoid accidents. Overuse of this feature will cause the bottom plate temperature to cool too quickly.



4. “” **Spray Method:** spray can be used in any position, whether in dry ironing or steam ironing, as long as the tank is full of water, press the water button, spray from the nozzle.



- 5. Self-cleaning Function:** add water to the indicated maximum water level, connect the device to the power outlet, turn on the power, rotate the temperature to the highest temperature, wait for the green indicator light (heating success), unplug the power plug from the outlet, place the device horizontally on the sink, dial the steam key to the far left to keep it still, and then shake the device a little bit until the boiling water, steam and impurities all flow out, and then clean it with a damp cloth after the base plate cools down. This function cleans the plates and removes impurities. We recommend using it every 10-15 days.



- 6.** When using is stopped, remove the power cord from the power outlet. Open the water cover on the tank (in a sink or bucket) and reverse the tank to empty the remaining water in the tank. Place vertically on a flat table or hold the iron to the seat for the product to cool.

## Dry Ironing

1. Set the steam control level to the minimum position.
2. Adjust the ironing temperature as per fabric's requirement.
3. The Light " Red " indicates that the iron's temperature is increasing steadily, once desired temperature is reached, the light will turn " Green " automatically.

## Auto Shut Off

After the device is plugged in, the 30S will trigger the automatic power off function. If the device needs to be shaken, the power will be restored. If the device is vertically for 8min will trigger the automatic power off function. If the device is shaken, the power will be restored.

## Vertical Steam

By holding the iron in a vertical position, you can apply burst of steam to remove creases from curtains or any type of hanging fabrics.

### Caution

If the steam iron has been used for a long time, it is hot and there is no water. Do not refill it with water until the steam iron cools down.

## ■ SPECIFICATIONS

- Clean with a wet cloth after the cooling of the bottom plate.
- Please do not use rough or abrasive cleaners or solvents.
- Avoid using the iron in water or other liquids.
- Do not fall, throw it, or try to bend it.
- Please do not try to remove the decomposition appliances.
- Empty the water tank after each use.
- Avoid storing electrical appliances in wet places
- Do not approach the heat source or let the sun shine directly on the electrical appliances.
- Always ensure that the steam outlet holes are clean, unstained and not blocked.
- It is recommended to store the iron in a flat position, such as in a cabinet.



Do not treat scrapped electrical appliances as unclassified municipal waste, but should give them to the official designated recycling center. This is good for environmental protection.

## Fault Maintenance Guide

Question	The possible solution
The iron is not heated	Check that the plug is inserted correctly. Check the power supply. Check the power supply push button.
The iron does not produce steam	Check that the water level and the water tank are loaded correctly. Press the steam button vigorously. Keep the iron in a horizontal position.
The water leaked from the tank	Ensure that the water is not above the maximum water level. Make sure that the water tank inlet is closed properly. Always keep the bench top iron in a horizontal position according to the operating instructions provided.
The steam engine has a loud hum or pumping	Check water level; if no water or low, add water to the tank.
Avoid the discoloration of the metal accessories on the clothing	Do not use steam ironing machine directly on metal accessories. Use steam carefully when there are metal fittings around it.

Model: HJ-8065

***Sundu***

1500W Steam Iron  
E-mail: [support@sunduhome.com](mailto:support@sunduhome.com)