


# Wall Mounted Pot Rack


## ASSEMBLY INSTRUCTIONS

### CAUTION

INSPECT CONTENTS IMMEDIATELY AND FILE CLAIM WITH DELIVERING CARRIER FOR ANY DAMAGE. **SAVE YOUR BOX AND ALL PACKING MATERIALS.** YOU ARE RESPONSIBLE FOR DAMAGE TO YOUR UNIT IF RETURNED IMPROPERLY PACKED.



Note: Depending on length purchased, the pot rack will have 2, 3, or 4 wall brackets.



### Parts (quantities)

| Part description: | Pot Rack length: |     |     |     |     |     |      |      |      |      |
|-------------------|------------------|-----|-----|-----|-----|-----|------|------|------|------|
|                   | 36"              | 48" | 60" | 72" | 84" | 96" | 108" | 120" | 134" | 144" |
| Flat Bar          | 2                | 2   | 2   | 2   | 2   | 2   | 2    | 2    | 2    | 2    |
| Left Bracket      | 1                | 1   | 1   | 2   | 2   | 2   | 3    | 3    | 3    | 3    |
| Right Bracket     | 1                | 1   | 1   | 1   | 1   | 1   | 1    | 1    | 1    | 1    |
| Screw             | 4                | 4   | 4   | 6   | 6   | 6   | 8    | 8    | 8    | 8    |
| Flat Washer       | 4                | 4   | 4   | 6   | 6   | 6   | 8    | 8    | 8    | 8    |
| Lock Washer       | 4                | 4   | 4   | 6   | 6   | 6   | 8    | 8    | 8    | 8    |
| Cap nut           | 4                | 4   | 4   | 6   | 6   | 6   | 8    | 8    | 8    | 8    |

### 1) Flat Bars

Attach flat bar to front of all brackets with hardware, as shown in *figure 1*. Hand-tighten cap nuts until all flat bars are installed.


### 2) Mounting

Square flat bars with wall brackets and tighten hardware. Mount to wall\*. Refer to *figure 2* for bracket mounting locations.

**(End)** Assembly is complete.

\* Note: Wall mounted units must be attached to a properly constructed and sound wall. For walls constructed of wood or steel studs, the mounting points must be directly on the stud or suitable in-wall grounds of plywood or sheet metal. Eagle Group cannot be held responsible for the failure of the device or any other devices due to improper installation.

### BRACKET MOUNTING LOCATIONS



| Length | A       | B      | C       |
|--------|---------|--------|---------|
| 36"    | N/A     | N/A    | 35.000  |
| 48"    | N/A     | N/A    | 47.000  |
| 60"    | N/A     | N/A    | 59.000  |
| 72"    | N/A     | 36.000 | 35.000  |
| 84"    | N/A     | 42.000 | 41.000  |
| 96"    | N/A     | 48.000 | 47.000  |
| 108"   | 36.3125 | 35.375 | 35.3125 |
| 120"   | 40.3125 | 39.375 | 39.3125 |
| 134"   | 44.3125 | 43.375 | 43.3125 |
| 144"   | 48.3125 | 47.375 | 47.3125 |

figure 2