
HERCULES™

Owner's Manual & Safety Instructions

25I

Model
HE761



BREAKER HAMMER TROLLEY

⚠WARNING: To prevent serious injury, User must read and understand Owner's Manual. SAVE THIS MANUAL.

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-800-444-3353 as soon as possible. Reference 59696

IMPORTANT SAFETY INFORMATION

⚠WARNING

Read all safety warnings and all instructions.
Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

1. **PRIOR TO USING THIS PRODUCT, READ AND UNDERSTAND ALL INSTRUCTIONS AND SAFETY PRECAUTIONS AS OUTLINED IN THE MANUFACTURER'S MANUAL OF THE BREAKER HAMMER THAT IS TO BE USED.**
2. **BOLT THE BREAKER HAMMER SECURELY TO THE CLAMPING BLOCKS ON THE BREAKER HAMMER TROLLEY AND TEST WORK SET-UP FOR STABILITY BEFORE USE.**
3. **UNPLUG THE BREAKER HAMMER FROM ITS ELECTRICAL SUPPLY BEFORE PERFORMING ANY SERVICE OR MAINTENANCE ON THE TROLLEY.** Make sure to unplug the breaker hammer before leaving the work area, moving the Trolley from one location to another, cleaning debris from the unit, etc.
4. This product is not a toy. Do not allow children to play with or near this item.
5. Use as intended only.
6. Maintain labels and nameplates on the tool. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

Work Area Safety

1. **Keep work area clean and well lit.** *Cluttered or dark areas invite accidents.*
2. **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** *Power tools create sparks which may ignite the dust or fumes.*
3. **Keep children and bystanders away while operating a power tool.** *Distractions can cause you to lose control.*

Assembly Precautions

1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep assembly area clean and well lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble when tired or when under the influence of alcohol, drugs or medication.
6. Weight capacity and other product capabilities apply to properly and completely assembled product only.

Personal safety

1. **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** *A moment of inattention while operating power tools may result in serious personal injury.*
2. **Use personal protective equipment. Always wear eye protection.** *Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.*
3. **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** *Carrying power tools with your finger on the switch or energizing power tools that have the switch on invites accidents.*
4. **Do not overreach. Keep proper footing and balance at all times.** *This enables better control of the power tool in unexpected situations.*
5. **Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts.** *Loose clothes, jewelry or long hair can be caught in moving parts.*
6. **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** *Use of dust collection can reduce dust-related hazards.*
7. **Only use safety equipment that has been approved by an appropriate standards agency.** *Unapproved safety equipment may not provide adequate protection. Eye protection must be ANSI-approved and breathing protection must be NIOSH-approved for the specific hazards in the work area.*

Percussion Hammer Safety Warnings

1. **Wear ear protectors.** *Exposure to noise can cause hearing loss.*
2. **Hold power tools by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord.** *Contact with a "live" wire will make exposed metal parts of the tool "live" and shock the operator.*
3. **Keep clear of moving parts.**
4. **Unplug before inspecting, removing or installing bit, or performing any service.**
5. **Pull on bit after installation and before use; bit may move but MUST NOT slide out.**
6. Wear steel-toed boots during use.
7. Do not operate this tool if you have back, neck, or wrist injuries, or other conditions that will be aggravated by the severe jerking forces that this tool exerts upon the operator.
8. Avoid unintentional starting. Prepare to begin work before turning on the tool.
9. Do not leave the tool unattended when it is plugged into an electrical outlet. Turn off the tool, and unplug it from its electrical outlet before leaving.
10. This product is not a toy. Keep it out of reach of children.
11. People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure. In addition, people with pacemakers should:

- Avoid operating alone.
- Properly maintain and inspect to avoid electrical shock.
- Properly ground power cord. Ground Fault Circuit Interrupter (GFCI) should also be implemented – it prevents sustained electrical shock.

12. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Vibration Safety

This tool vibrates during use. Repeated or long-term exposure to vibration may cause temporary or permanent physical injury, particularly to the hands, arms and shoulders. To reduce the risk of vibration-related injury:

1. Anyone using vibrating tools regularly or for an extended period should first be examined by a doctor and then have regular medical check-ups to ensure medical problems are not being caused or worsened from use. Pregnant women or people who have impaired blood circulation to the hand, past hand injuries, nervous system disorders, diabetes, or Raynaud's Disease should not use this tool. If you feel any medical or physical symptoms related to vibration (such as tingling, numbness, and white or blue fingers), seek medical advice as soon as possible.
2. Do not smoke during use. Nicotine reduces the blood supply to the hands and fingers, increasing the risk of vibration-related injury.
3. Use tools with the lowest vibration when there is a choice between different processes.
4. Include vibration-free periods each day of work.
5. Let the tool do the work.
6. To reduce vibration, maintain the tool as explained in this manual. If any abnormal vibration occurs, stop use immediately.

SAVE THESE INSTRUCTIONS

Warning Symbols and Definitions

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER **Indicates a hazardous situation which, if not avoided, will result in death or serious injury.**

WARNING **Indicates a hazardous situation which, if not avoided, could result in death or serious injury.**

CAUTION **Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.**

NOTICE **Addresses practices not related to personal injury.**

Symbology

	WARNING marking concerning Risk of Eye Injury. Wear ANSI-approved safety goggles with side shields.
	Read the manual before set-up and/or use.
	WARNING marking concerning Risk of Hearing Loss. Wear hearing protection.

	WARNING marking concerning Risk of Respiratory Injury. Wear NIOSH-approved dust mask/respirator.
	WARNING marking concerning Risk of Foot Injury. Wear steel-toe work boots.
	DANGER marking concerning Risk of Amputation. Keep hands well clear of cutting area.


SET UP - BEFORE USE

Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.


<u>Note:</u> For additional information regarding the parts listed in the following pages, refer to Parts List and Diagram.

Assembly


1. Remove Trolley from packaging. Unfasten hook and loop fasteners holding Struts, then raise Struts in direction of arrows.



2. Lift Wheel Frame to move Pin into first slot.




3. Fold hook and loop fasteners out of the way, then lower Struts and align Strut ends with brackets on Wheel Frame. Secure with Ball Pins (34).




4. Slide one Ø20 Flat Washer (31) onto each axle.

5. Install a Wheel on each axle and secure using Ø16 Flat Washers (28), Ø16 Lock Washers (29), and M16 Lock Nuts (30).




6. Stand Trolley upright on Wheels. Loosen Handlebar Knob, raise Handlebar 90° to Frame and tighten Knob.



For technical questions, please call 1-800-444-3353.

Note: Clamping Block position and use of Clamping Block Inserts will vary depending on brand and model of breaker hammer. Clamping setup for several breaker hammer models is shown below.




Hercules 57150
DeWalt D25960K

Bauer 64276
Bosch 11335K

Bauer 64277

7. Position Trolley flat and parallel to the ground.
8. Remove Inserts from two Clamping Blocks.
9. Place two Clamping Blocks onto Trolley, then lay breaker hammer (sold separately) onto Clamping Blocks. Secure hammer in place using remaining Clamping Blocks, Mounting Plate, M12x240 Bolts (1), Ø12 Lock Washers (2), and Nuts (10).

Hercules 57150 clamping setup shown



10. Return Trolley to upright position. Loosen Handlebar Knob, raise Handlebar and tighten Knob.

OPERATION


Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Tool Set Up

⚠WARNING

TO PREVENT SERIOUS INJURY FROM ACCIDENTAL OPERATION:
Make sure the breaker hammer power switch is in the off-position and unplug the tool from its electrical outlet before performing any procedure in this section.

1. Install a floor scraper, according to breaker hammer's instruction manual, that is suitable for leveling, scraping, and removal of coatings and flooring materials.
2. The Breaker Hammer Trolley has five adjustable angle settings. To adjust the angle, step on the Foot Pedal and pull down or push up on the Handlebar.



3. To adjust angle of Handlebar, loosen Handlebar Knob, raise or lower Handlebar and tighten Knob.

Work Area Set Up

1. Make sure the work area is clean and well-lit. The work area must not allow access by children or pets to prevent distraction and injury.
2. Route the power cord along a safe route to reach the work area without creating a tripping hazard or exposing the power cord to possible damage. The power cord must reach the work area with enough extra length to allow free movement while working.
3. There must not be objects, such as utility lines, nearby that will present a hazard while working. If working in the ground or on a concrete slab on the earth, call local utility company to ensure that area is clear of utility lines.
4. Keep power cord away from moving machines.

General Operation

⚠WARNING

TO PREVENT SERIOUS INJURY:
Wear ANSI-approved safety goggles, ear protection, steel-toe boots, dust mask and heavy-duty work gloves during use. Keep feet clear of breaker hammer. Keep children and animals well clear of the work area.


⚠WARNING

TO PREVENT SERIOUS INJURY:
Read the breaker hammer manufacturer's instruction manual before use. Ensure that the breaker hammer is firmly secured to the Trolley. Use with a breaker hammer only – do not use with any other type of power tool.

1. Check scraper for dullness, cracks, or other damage.

CAUTION! TO PREVENT INJURY: A dull scraper can cause unnecessary scraper movement, resulting in tool wear and possible injury. Use only sharp floor scraper.

2. Secure breaker hammer power cord to hook on end of either handle grip, and hook and loop fasteners, to keep cord clear of scraper blade and protect it from crushing, abrasion, and scraping by broken tile or other flooring materials.



3. Adjust Trolley to an angle suitable for the flooring material being removed.
4. Make sure the breaker hammer power switch is in the off-position, then plug the tool into an outlet on a circuit rated to 20 amps.

CAUTION! TO PREVENT INJURY OR PROPERTY DAMAGE: Keep power cord away from moving machines.

5. Turn on breaker hammer power switch.
6. Push the Trolley forward to begin striking flooring material. Use the Foot Pedal to apply more forward pressure for difficult to remove flooring materials or to increase demolition speed.

NOTICE: Running tool with no load or "empty blows" will damage the breaker hammer.

7. When work is complete, turn off power switch.
8. To prevent accidents, turn off the tool and disconnect its power supply after use.
9. Clean, then store the tool indoors out of children's reach.

MAINTENANCE

Procedures not specifically explained in this manual must be performed only by a qualified technician.

⚠WARNING

TO PREVENT SERIOUS INJURY FROM ACCIDENTAL OPERATION:
Turn the power switch of the breaker hammer off, unplug the tool from its electrical outlet, and remove breaker hammer before performing any procedure in this section.

TO PREVENT SERIOUS INJURY FROM TOOL FAILURE: Do not use damaged equipment. If abnormal noise or vibration occurs, have the problem corrected before further use.

Cleaning, Maintenance, and Lubrication

1. **BEFORE EACH USE,** inspect the general condition of the Trolley. Check for:
   - loose hardware
   - misalignment or binding of moving parts
   - cracked or broken parts
   - any other condition that may affect its safe operation.
2. **AFTER USE,** wipe external surfaces of the tool with clean cloth.
3. Periodically, apply light oil to all moving parts of the Trolley.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

PARTS LIST

Part	Description	Qty
1	Bolt M12x240	4
2	Lock Washer Ø12	11
3	Mounting Plate	1
4	Clamping Block	4
5	Clamping Block Insert	4
6	Resting Block	1
7	Bolt M10x30	6
8	Lock Nut M10	10
9	Main Frame	1
10	Nut	4
11	Bolt M12x60	4
12	Left Bracket	1
13	Right Bracket	1
14	Bolt M12x50	2
15	Lock Nut M12	6
16	Strut	2
17	Spring	2
18	Bolt M10x60	2
19	Sleeve A	4
20	Flat Washer	2
21	Ring Ø8	4
22	Rod 10x160	1
23	Connecting Bar	2
24	Wheel Frame	1


Part	Description	Qty
25	Flat Washer	2
26	Rod 10x180	1
27	Rubber Wheel	2
28	Flat Washer Ø16	2
29	Lock Washer Ø16	2
30	Lock Nut M16	2
31	Flat Washer Ø20	2
32	Bolt M10x40	2
33	Foot Pedal	1
34	Ball Pin	2
35	Lock Washer Ø10	10
36	Left Handgrip	1
37	Rivet	4
38	Handlebar	1
39	Right Handgrip	1
40	Hook and Loop Fastener	4
41	Flat Washer	4
42	Knob	1
43	Flat Washer Ø12	1
44	Cap	2
45	Handle Support w/ Gear Plate	1
46	Handle Bumper	2
47	Handle Support	1
48	Rivet	2

Record Product's Date Code Here:_____

Note: If product has no Date Code, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts. Specify UPC 193175557353 when ordering parts.

ASSEMBLY DIAGRAM



LIMITED 90 DAY WARRANTY

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of one year from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Visit our website at: https://www.harborfreight.com
Email our technical support at: productsupport@harborfreight.com
For technical questions, please call 1-800-444-3353

Copyright© 2025 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

HERCULES™

26677 Agoura Road • Calabasas, CA 91302 • 1-800-444-3353