

## **Distorted audio from the Z150 speakers**

If the audio coming from your Z150 speakers sounds distorted, try these suggestions:

- Make sure all cables and connectors are connected securely to both your speakers and your device.
- Adjust the volume on both the speakers and your audio source.

**NOTE:** If you're streaming audio content from the internet to your device, it could be the internet connection and not your speakers causing the problem. Try audio that is stored on your device to verify.

## **No audio coming from the Z150 speakers**

If you can't hear any audio from your Z150 speakers, try these suggestions:

- Make sure all cables are firmly connected to both your speakers and your device.
- Adjust the volume on both the speakers and your audio source.
- Verify that the audio isn't set to "Mute" on your audio source.
- If you're streaming audio content from the internet to your device, the issue could be with the internet connection and not your speakers. Try audio that is stored on your device to verify.
- If connected to a computer, make sure to select the audio-output device your speakers are connected to (see your computer's documentation for help).
- If connected to any other device with multiple output settings, make sure you have the correct output selected (ex. game console, DVD player, TV). See your device's documentation for help.