













 <p><b>FLIP-X</b> REVERSE CONTROL STUNT CAR</p> <p>Thank you for purchasing the Remote Control Stunt Car. This manual provides more information about the Remote Control Stunt Car. Please read the instructions before using.</p>	<p><b>Product Overview</b></p>  <p>Remote Control Stunt Car Remote Controller Instruction Manual</p>	<p><b>Package Contents</b></p> <p>Includes: 1(One) Remote Control Stunt Car 1(One) Remote Controller 1(One) Instruction Manual</p> <p><b>Specifications</b></p> <p>Power Supply: Remote Control Stunt Car: Requires 4 (Four) x AAA 1.5V Alkaline Batteries (Not Included) Remote Controller: Requires 2 (Two) x AAA 1.5V Alkaline Batteries (Not Included) Frequency: 27 MHz (Blue) 49 MHz (Green)</p> <p><b>Remote Controller</b></p>  <p>Left Forward/Backward Buttons Right Forward/Backward Buttons</p>	<p><b>Standard Control</b></p> <p><b>Note:</b> To avoid losing control, always pay attention when controlling the Remote Control Stunt Car.</p>  <p><b>Left + Right Forward Levers</b> Pushing both levers forward simultaneously makes the car move forward.</p>  <p><b>Left + Right Backward Levers</b> Pushing both levers backward simultaneously makes the car move backward.</p>	<p><b>Standard Control</b></p>  <p><b>Left Forward Lever</b> Pushing the left lever upward makes the car rotate to the right.</p>  <p><b>Right Forward Lever</b> Pushing the right lever upward makes the car rotate to the left.</p>	<p><b>Standard Control</b></p>  <p><b>Left Forward Lever + Right Backward Lever</b> Pushing the left lever upward while simultaneously pulling the right lever downward makes the car rotate 300 degrees to the right.</p>  <p><b>Right Forward Lever + Left Backward Lever</b> Pushing the right lever upward while simultaneously pulling the left lever downward makes the car rotate 300 degrees to the left.</p>	<p><b>Standard Control</b></p>  <p><b>Pushing both levers forward simultaneously and then quickly pulling them backward makes the car roll over backward.</b></p>  <p><b>Pushing both levers backward simultaneously and then quickly pushing them forward makes the car roll over backward.</b></p>
<p><b>Play with Friend</b></p>  <p><b>BLUE: 27 MHz</b> <b>GREEN: 49 MHz</b></p> <p>Please purchase other car with different frequency to play.</p>	<p><b>Power On/Off</b></p>  <p><b>Power ON/OFF:</b> Slide the ON/OFF Switch to ON to turn on the Remote Control Stunt Car. <b>Slide the ON/OFF Switch to OFF to turn off the Remote Control Stunt Car.</b></p>	<p><b>Batteries Installation For Remote Control Stunt Car</b></p>  <p>To install batteries into the Remote Control Stunt Car, connect the positive (+) and negative (-) ends of the battery to the corresponding (+) and (-) terminals on the battery tray. Batteries should be placed as shown on the diagram. Replace the battery box cover and tighten the cover.</p> <p><b>Notice:</b> When installing the batteries, you must check compatibility to the correct polarity. The Remote Control Stunt Car won't function if batteries are not inserted.</p>	<p><b>Batteries Installation For Remote Controller</b></p>  <p>To install batteries into the Remote Controller, remove the cover on the battery box cover using the screwdriver. Insert the AAA 1.5V alkaline battery into the battery slot. Batteries should be placed as shown on the diagram. Replace the battery box cover and tighten the cover.</p> <p><b>Notice:</b> When installing the batteries, you must check compatibility to the correct polarity. The Remote Controller won't function if batteries are not inserted.</p>	<p><b>Performance Tips</b></p> <ol style="list-style-type: none"> <li>Do not drive the Remote Control Stunt Car on grass, sand or go through water.</li> <li>Do not drive the Remote Control Stunt Car in windy or rainy weather.</li> <li>Do not drive the Remote Control Stunt Car for long time.</li> <li>Keep fingers, hair and loose clothing away from Remote Control Stunt Car.</li> </ol> <p><b>Care and Maintenance</b></p> <p>Always use dry and soft cloth to clean this product. Avoid this product from being exposed to sunlight or heat. Avoid immersing these toys in water. Otherwise, the electronic parts may be damaged. Check the product regularly. If any damage or discoloration, please stop using immediately, and do not attempt to repair or modify the product.</p> <p><b>IMPORTANT: BATTERY INFORMATION</b></p> <p><b>For AAA Batteries</b></p> <p><b>WARNING TO AVOID BATTERY LEAKAGE</b> The batteries used with this product are small cells and should be kept away from small children who will put things in their mouths. They are not intended for use as a source of power. The product should be used only for the intended purpose. Do not use the batteries if they are damaged, deformed, or if they are not the correct size and grade of battery. Do not use the batteries if they are not the correct size and grade of battery. Do not use the batteries if they are not the correct size and grade of battery. Do not use the batteries if they are not the correct size and grade of battery.</p>	<p><b>Warning</b></p> <p>This product is suitable to be used by people who have operating experience with remote toys or toys that have similar controls. Please do not put the product in your mouth to prevent choking hazard of small parts. Please do not use the product for long time continuously. Please do not play the product in a crowded area such as a shopping, shopping or playing area. Please drive the remote-control product continuously in places that are out of reach of children, in order to avoid the occurrence of accidents. Please do not use the product in high temperatures. Use only in places that are not exposed to direct sunlight. Please do not use the product in places where there are flammable materials or where there is a risk of fire. Please do not use the product in places where there is a risk of fire. Please do not use the product in places where there is a risk of fire. Please do not use the product in places where there is a risk of fire.</p>	<p><b>FCC Statement</b></p> <p>This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Caution: The user is cautioned not to make any modifications to the equipment for operation not intended by the manufacturer.</p> <p><b>RF warning statement:</b> This device has been evaluated to meet general RF exposure requirements. The device can be used for portable exposure condition without restrictions.</p> <p>Blue Dragon 1011 1/2 Street, Suite 200 Pharmacia, PA 19380 Distributed by: 1938 Holdings, Inc. 101 Market Street, Suite 200 Pharmacia, PA 19380 Made in Shenzhen, China Keep all Product Information for Future Reference <b>Serial ET-0973</b></p>

