

Wireless headset instruction:

Multifunctional Button:

Press once to activate voice changer during calls.

Press once Release when you hear a beep to activate voice control. You can switch between male, baby, and female voices.

Single press Switch between Game and Music modes. Double press Switch between Bluetooth and TF card. Single press In call mode, single press to activate call voice changer.

Add button:

Short press Volume up

Long press to switch to the next track.

Decrease button:

Press once to decrease the volume

long press to go to the previous track.

Power Button:

ON/OFF

Connection instructions:

After pressing and holding the switch to turn on the device, the prompt light will start flashing open the wireless device list, and find the name to connect; If you can't connect, repeat the operation.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.