


Specifications

Product Name	Bridge2
Model/HVIN	EB2
Brand	igloo
Power supply mode	AC to 5V DC USB power adapter with a minimum rating of 5W



Bridge 2 Quick Start Guide



Whats Included


- A Status LED
- B Type-C power IN
- C Power Cable
- D Base Plate
- E Reset Button
- F Mounting Screws
- G Screw Anchors

Getting Started

- 1 Take out your bridge and power cable from the box.
- 2 Find a place to install it, you will need a AC to 5V DC USB power adapter with a minimum rating of 5W.


*Power adapter not included

- 3 For a reliable Bluetooth® connection try to place the bridge within 5m (15ft) of the lock.
- 4 Place the bridge either on the wall or a table top clear of obstructions.




Wall Mounting

- 5 If wall mounting please detach the base plate (D) from the bridge and place it on the wall.
- 6 There are two methods of mounting, with adhesive tape or with screws.



Drill Sheet




IMPORTANT

To ensure secure installation, use the recommended pilot hole and anchor bolt guidelines below.

*The pilot holes should be drilled to a depth of 30 mm

Mounting Surface	Pilot Hole Diameter	Anchor Bolt
Wood	2 mm	X
Sheetmetal	2.5 mm	X
Brick	4.5 mm	ⓐ
Concrete	4.5 mm	ⓑ
Masonry	4.5 mm	ⓒ
Drywall	4.5 mm	ⓓ



Adhesive Tape

- 7 Peel off the mounting tape from the back of the base plate as shown.
- 8 Ensure that the wall is clean and dry before pressing the base plate onto the wall.




*Press it for 30 seconds to ensure a strong bond.

Mounting Screw

- 9 Position the base plate at the location you desire to install and mark the two hole locations as shown with a pencil.
- 10 Check and drill the pilot hole size for the mounting surface as specified on the drill sheet.
- 11 If anchors are required, insert the 2x screw anchors for Brick, Concrete, Masonry or Drywall.

*The anchors should tightly fit into the pilot holes to ensure a secure hold. For wood there is no need to insert wall anchors.



- 12 Mount the bridge onto the base plate by aligning the USB downwards, inserting it onto the tabs on the base plate and twisting clockwise by approximately 10 degrees until you hear a click.



- 13 Plug in the USB power into the bridge and the status LED should start to breathe orange indicating that it is ready to pair.



Congratulations!

You have successfully installed your Bridge 2. Please download the igloohome or iglooworks app to pair and complete setup.

App Store



Google Play



Contact Us

support@igloohome.co
+65 3129 2464 (Singapore)
+1 929 224 0688 (USA)



Learn more through our online guides and support portal:
<https://go.igloohome.co/EB2support>

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Operations in the 5.15-5.25GHz band are restricted to indoor usage only.

IC Warning

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux RSS exemptés de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne peut pas causer d'interférences.
2. Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un fonctionnement indésirable de l'appareil.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement respecte les limites d'exposition au rayonnement IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.

Operations in the 5.15-5.25GHz band are restricted to indoor usage only.