Welcome to MOVA Stellar X10 Plus Air Purifier

The illustrations provided in this manual are for reference only. Please refer to the actual product for accuracy.

EN .....P01~P09

FR .....P10~P19

DE .....P20~P29

IT .....P30~P39

ES .....P40~P49

PT .....P50~P59

Table of Contents

1. Safety Precautions 1

2. Product Overview 2

3. Connect to MOVAhome App 3

4. Product Usage 4

5. Care & Maintenance 5

6. Common Issues 6

7. Basic Specifications 7

Original Instructions

1. Safety Precautions

To prevent accidental injuries such as electric shock or fire caused by improper operation, please carefully read the User Manual before use and store it properly.


Warnings

- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Before cleaning and maintaining the air purifier, always disconnect the power supply.
- Do not expose the product or its power cord to heat sources or direct sunlight to prevent fire.
- Before long-term disuse, maintenance, or repair, unplug the power cord and ensure the air purifier is powered off.
- Do not pull or apply excessive pressure to the power cord.
- When unplugging, grasp the plug rather than the power cord.
- Do not use power extension cords.
- Do not place the power cord under the product.
- The air purifier must not be placed directly beneath a power outlet.
- Do not place textiles, curtains, or any other flammable materials near the product's air outlet.
- Fire hazard warning: Do not apply any type of fragrance to the air purifier's filter. These types of products are known to contain flammable chemicals which may cause the air purifier to catch fire.
- Do not pull the product by its head.
- Do not use the product if it is damaged or submerged in water.
- Do not place the product on an unstable surface to prevent damage from falling or potential harm to users.
- In the event of product drop, damage, or any other abnormalities, please contact after-sales service for repair. Do not attempt disassembly on your own.
- Use only accessories and replacement components recommended by MOVA.
- This product is designed for installation and use exclusively in dry indoor environments.
- Do not allow water, other liquids, or flammable cleaning agents to enter the product to prevent electric shock or fire.
- Do not spray any flammable materials such as insecticides or perfumes around the product.
- Before connecting the product to the power supply, check if the product's voltage rating matches the local power supply voltage.
- This product is not a substitute for normal ventilation, routine vacuuming, or the use of a range hood during cooking.
- The product must be placed and operated on a stable, flat, and level surface.
- The lower air inlet of the product requires a minimum clearance of 30 cm, while the upper air outlet must maintain at least 50 cm of unobstructed space.
- Before turning on the power, ensure that the filter and filter cover are properly installed.
- Do not insert fingers or objects into the air outlet or inlet to prevent physical damage or malfunction of the product.
- The appliance is only to be used with the power supply unit provided with the appliance.
- This appliance can be used by children aged from 8 years and above under supervision.

- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Cleaning and user maintenance shall not be made by children without supervision.

2. Product Overview


Air Purifier



3. Connect to MOVAhome App

1. Scan the QR code to download the App, or search for "MOVAhome" in the App Store or Google Play. After installation is complete, please create an account and log in.

2. The device automatically turns on when connected to power. Please turn off the device first by pushing the eyeball downwards until the side with the Power button ⏻ facing upward. When you hear a "click", the device is turned off.
3. Long-press the ⏻ to turn on the device. After you hear a "beep", the device is turned on and the eyeball will blink orange, indicating that the device is ready for connection. Before connecting, please check the following:
   - Ensure that both your mobile phone and the device are within the same Wi-Fi network coverage range with a strong signal.
   - Ensure the current Wi-Fi network is a single-band network of 2.4 GHz frequency.
   - Bring your phone close to the device (the distance between your phone and the device should be within 1 m).
   - Do not change the Wi-Fi network during connection.
4. Open the App, go to the Device page, tap the "+" in the upper-right corner to add your device. Alternatively, you can choose either of the following methods to add your device:
   A. Scan to add: Go to the Device page, tap Scan to Connect, scan the QR code on the device, and follow the App instructions to complete the connection.



   B. Add manually:
   - Go to the Device page, tap Add, choose your device model, and key in the Wi-Fi password.
   - Make sure the device is restarted and in pairing mode, then tap"next step".
   - Follow the App instructions to switch your Wi-Fi network to the device hotspot "movaairp-xxx", and return to the App to complete the connection.

Note: Please complete the connection within 5 minutes after the device enters pairing mode. If the connection times out, unplug the adapter for 30 seconds and then repeat the steps above.


*Actual procedures may vary due to App updates. Please refer to the App instructions for accuracy.

4. Product Usage

Mode Selection

Auto mode


Press the power button to activate the automatic purification mode. The air purifier will automatically adjust to the corresponding purification level based on indoor air quality, while the screen shows different emoticons to indicate current air conditions.




Mode Selection

Manual mode

When the air purifier is off, gently push the eyeball control module by hand. The machine will switch between different stepless purification levels based on the push angle.
Push the eyeball control module towards the side with the power button facing upward to turn off the air purifier.






Filter Replacement

Filter replacement reminders will be pushed to your phone via the app. Only use genuine filters. Do not use non-genuine filters.

1. Always unplug the air purifier from the power outlet first.
   Turn the air purifier upside down with the base facing upward. Then hold the handle and rotate the base in the direction marked "OPEN" to unlock and open the base.
2. Remove the filter from the air purifier.
3. Remove the packaging materials from the new filter.
4. Install the new filter into the air purifier.
   Install the base into the air purifier, hold its handle, and rotate the base in the direction marked "CLOSE" to secure it firmly.
   After replacing the filter, plug the air purifier into the power outlet.



Reminder:
Before using the new product, remove the packaging materials from the filter.
Always unplug the air purifier from the power outlet before removing/installing the filter.
Regularly clean the dust from the filter. The filter is not washable or reusable.
Only use MOVA genuine filters. Do not use non-genuine filters.

5. Care & Maintenance

Precautions:

- Before performing maintenance, always turn off the purifier and unplug the power cord.
- Do not immerse the air purifier in water or any other liquid.
- Do not use abrasive, corrosive, or flammable cleaning agents (such as bleach or alcohol) to clean any components of the air purifier.

Cleaning:

- Power off and unplug the power cord
- Clean the air inlet/outlet, and wipe the exterior casing of the air purifier with a neutral detergent and a soft cotton cloth.

  Caution: When cleaning the air outlet, ensure no water droplets fall into the air purifier.

Storage:

- Power off and unplug the device, then neatly coil and secure the adapter cable.
- Cover the clean unit with a dust-proof cover/bag and store it in a well-ventilated area away from direct sunlight.
- If the air purifier remains unused for an extended period, it is advisable to periodically power it on and operate it for several minutes to maintain its optimal performance.

6. Common Issues

The air purifier will automatically shut down in case of abnormal operation. Please refer to the troubleshooting table for possible causes and corresponding solutions. If the issue persists, please contact after-sales service for repair.

Common issues	Possible Causes	Solutions
The product fails to power on	Power is not connected or plug is not fully inserted	Check if the power cord is properly connected to the outlet. Ensure the power plug is securely inserted before operation.
	The outlet has no power	Try another power outlet
	The air purifier is damaged	Please contact after-sales service for repair
The product emits unpleasant odors	First-time use of the new product	A slight plastic odor during initial use is normal. If the odor persists after removing the filter, please contact after-sales service for repair
	Excessive absorption of gaseous pollutants	It is recommended to replace the filter or place it in a well-ventilated area to dissipate odors
	Filter dampness	Dry the filter thoroughly and ensure the product is placed in a dry environment
	Expired service life for the filter	Replace with a new filter and reset the filter life
The product is making unusual noise	The product is not placed on a stable surface	Place the product on a stable surface
	Excessive noise during nighttime operation	Set the fan speed to a lower level in manual mode
	If the issue persists after excluding the cases above, please contact after-sales service for repair	
Airflow direction cannot be adjusted	The product's eyeball component rotates unsmoothly	Check the product's head rotation area for any foreign object blockages
	If the issue persists after excluding the cases above, please contact after-sales service for repair	
Filter replacement still prompts filter expiration	Filter life is not reset	After replacing with a new filter, reset the filter life

7. Basic Specifications

Air Purifier	
Model	X10 Plus
Rated Voltage	24 V ⎓
Rated Power	45 W
Dimensions (length × width × height)	244 × 244 × 544 mm
Wireless Frequency Range	Wi-Fi: 2412-2472 MHz
Max. RF Output Power	WIFI: 19.99 dBm
Accessories/Components	2.4G Wi-Fi Module

Note: Hereby, XingKuang Innovation Technology (Suzhou) Co., Ltd. declares that the radio equipment type X10 Plus is in compliance with Directive 2014/53/EU

The full text of the EU declaration of conformity is available at the following internet address: https://www.mova.tech/pages/contact-us

After-Sales Service Policy

For products within the warranty period, any damage caused by manufacturing defects or component failures under normal usage conditions, as verified by MOVA's maintenance personnel, will be covered by free warranty service.

Warranty Coverage

Type	Warranty Coverage	Warranty Period
Machine	Machine (excluding accessories and consumables)	1 year
Motor	Motor	1 year
Consumables	Filter	No warranty

In the event that the warranty period mandated by national laws exceeds the duration specified in this User Manual, the statutory requirements shall prevail.

Care & Maintenance

Serial No.	Fault Description and Replaced Component	Service Date	Service Center
1			
2			
3			

Product Warranty Card

User Name	
Mailing Address	
Contact Number	
Product Name and Model	
Product Serial No.	
Purchase Date	

After-Sales Service Policy

Service policy/Notification/Technical support

Service Policy:
MOVA strictly complies with the product repair and return liability regulations and provides guarantee for repair, refund and change of goods for consumers who purchase our product.For detailed service policies, please refer to the official after-sales policy section of the MOVA brand at https://www.mova.tech/.

*Please note that the following circumstances are excluded from the coverage of our guarantee policy:

1. Warranty period expiration;
2. Damage caused by failure to use, maintain, or store the product in accordance with the instruction manual;
3. Damage caused by disassembly or repair performed by service providers unauthorized by MOVA;
4. No valid warranty certificate or valid invoice provided (except when the product's warranty period can be otherwise verified);
5. Unauthorized alteration of the warranty certificate;
6. Inconsistency of the product model or serial number on the physical warranty certificate with the actual product;
7. Lack of manufacturer name, factory address, production date, or product certification;
8. Damage caused by force majeure;
9. Normal wear and tear parts (such as filters).

Certificate of Compliance

Inspector 03

Technical Support:
If you require additional assistance or encounter any operational issues while using this product, please contact us for further technical support.