




- ① Previous / Volume –
- ② Indicator Light
- ③ Multi-function Key
- ④ Next / Volume +
- ⑤ Charging Port

Music Time $\geq 25H$ (80%Volume)
 Call Time $\geq 20H$
 Standby Time $\geq 250H$
 Charging Time $\geq 2.5H$

- ③ Power On 25'
 Long press 25' Power On
 Blue light on for 1 S'
 Power On
- Pair with phone
 Automatically enter pairing mode after power-up.
- Red & Blue light flash alternately fast
 Pairing
- When the earphones in pairing state, locate "180S" on your device to pair them.
- Answer/Hang up *1
 Short press Answer/Hang Up
- Play/Pause *1
 Short press to pause Short press again to play
- ④ Next track 1S'
 Long press button to select next song
- ① Previous 1S'
 Long press button to select previous song
- Power Off 35'
 Long press 35' Power On
 Red light on for 1 S'
 Power Off
- Pairing succeeded
 After auto reconnect on power on or pairing succeeded
- Blue light flashes once every 5 S'
 du
- Smart voice *2
 (Activate Siri)
 Double press Activate Smart Voice
- Increase volume *1
 Short press button to increase volume
- Decrease volume *1
 Short press button to decrease volume

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.