120x80mm

Gaswei

TWO-WAY RADIO

NA

GUIDE

GUIPROPLUS

User Manual

CONTENTS

English 2-14

Before using this radio, please read this manual.
For detailed product information, user manuals, and apps and accessories, visit **www.gaswei.com**.

⚠ WARNING! Important Safety Instructions

Only accessories included in this package or specified by the manufacturer should be used with the radio. The first full charge/ charging input is compatible with most high-quality USB Type-C chargers. Please ensure the charger is from a reputable brand.

Do not allow unsupervised access to clean the exterior of the radio. Use only a damp or dry cloth.

Do not attempt to repair the radio by yourself. Removing the cover will void the warranty. Changes or modifications not expressly approved by **Gaswei** may void the user's authority granted by the FCC to operate the radio. Contact us for repair services.

Do not plug the wall adapter into the power outlet if the cord is damaged.

Do not use any portable radios that has a damaged antenna. If damaged, antenna cannot be replaced and must be sent to the factory.

⚠ WARNING: Important Safety Instructions for Battery

Read All Instructions:

- Do not recondition the battery even if it is severely damaged or is completely worn out.
- Do not disassemble or crush the battery pack can explode in a fire.
- Do not use the battery in an unusual manner. Improper battery use may result in overheating, explosion or other hazards.
- Do not short circuit the battery. The battery pack can explode in a fire.
- Do not expose the battery pack to water or other liquids. Any liquids created in a professionally explosive atmosphere can cause an explosion or fire.
- Do not disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.
- Do not touch the battery pack's battery with an appliance or heat source, such as a stove or microwave oven.
- Do not charge the battery pack if the battery pack or charger appears damaged or has been exposed to water or other liquids. If you do not operate, perform or maintain the battery as there may be corrosive leakage which can cause damage to eyes or skin and may be toxic if swallowed.

Recycle Battery

Local, state or federal laws may prohibit disposal of batteries in ordinary trash.

Consult your local waste authority for information regarding available recycling and/or disposal options.

01 Operational Cautions

Exposure to high volume sound levels may cause temporary or permanent hearing impairment. Do not use the radio with volume at a level that is uncomfortable to your ears. You should always use care with the volume set at low level and avoid prolonged exposure to high volume sound levels.

- Set the volume control in a low position and use as low a volume as possible.
- Avoid turning up the volume to block out noisy surroundings. Whenever possible, use your radio in a quiet environment with low background noise.

Compliance with RF Exposure Standards

National and international regulatory authorities have established exposure limits for the electromagnetic energy (RF) emitted by radio equipment. The exposure standard for wireless equipment operating at normal use position utilizes a unit of measurement known as the Specific Absorption Rate (SAR). Testing for SAR is conducted using standardized methods with the radio transmitting at the highest certified power level in all frequency bands tested.

02 Limited Warranty

Gaswei provides a 1-year warranty from purchase date for defects in manufacturing and materials.


Gaswei is not liable for damage to other property caused by improper use or indirect losses (e.g., profit loss, data loss).

Exclusions:

- Normal wear, battery leakage or misuse.
- Damage from unauthorized products.
- Accessories (life-only warranty: antennas, chargers, headsets).
- Cosmetic damage (scratches, dents) not affecting performance.

Gaswei is not liable for damage to third-party products or property.

03 Control buttons



1. Antenna
2. External Speaker/ Microphone Jack
3. On/ Off
4. Vol+/Fast Backward
5. Vol-/Fast Forward
6. Menu/Lock
7. Call/Scan
8. Up Arrow/ Channel Selector
9. Down Arrow/ Channel Selector
10. Monitor/Flashlight
11. Back/LED Display

04 LCD Display



1. Channel Numbers
2. High/Low Power
3. Radio/Alert tone
4. NOAA Weather Band Icon
5. Call Tone Icon
6. Voice Icon
7. Roger Beep Icon
8. Transmit/Receive status
9. Battery Level Indicator
10. Dual Watch Icon
11. VOX Icon
12. DCS/CTCSS Icon
13. Privacy codes Channel
14. Volume Leveling
15. Scan Icon
16. Keypad Lock Icon
17. Key Tone Icon
18. Power Saving Icon

English 3
English 4

05 Using Your Radio

IP67 Waterproof Rating

This radio has an IP67 waterproof standard, making it suitable for use in the rain and other wet conditions. However, it is not designed for battery cover, accessory port, and Type-C charging port are properly sealed. Ensure these components are fully closed before using the radio or disassembling the device may compromise its waterproofing.

Charging

This device supports fast charging methods.

Use the included USB Type-C cable to charge the radio. Connect the cable to the charging port on the radio and the other end to a USB power source (wall charger, computer, etc.). The battery icon will display the battery's charging status. Charging is complete when the battery icon shows a full battery. Disconnect the charger from the radio and power source.

Turning the Radio On/Off

Press and hold the **PTT** button for 3 seconds, the radio beeps and briefly displays all function icons available on the radio. The display then shows the current channel number. The radio is now powered on and ready for use.

To turn off the radio, press and hold the **CHDE** button again for 3 seconds.

Low Battery Alert

When the battery is low, the battery icon displays ☐ and the radio emits periodic beeps to remind you to recharge it promptly.

English 5
English 6

NOAA Weather Band

Our radio includes an NOAA weather function, allowing you to listen to local broadcasts on NOAA weather channels. Follow these steps to activate and use this feature:

To select a weather channel:

1. Press the **MENU** button to enter the weather mode, then press the **CHDE** button to confirm.
2. Use the ▲ or ▼ button to select the desired channel.
3. Press the **CALL** button to exit the weather mode.

To monitor weather alerts:

1. Press the **CALL** + **PTT** button to activate the weather monitoring mode.
2. Use the ▲ or ▼ button to select the desired channel.
3. Press the **CALL** + **PTT** button to confirm the selection.

Note:

1. NOAA Weather Radio stations are designated to cover specific areas, and service may be limited. Check with your local weather forecasts office to find out which channel broadcasts in your area. Please refer to the new available transmitters in your area. Use of the NOAA logo does not constitute an endorsement or implied approval by the National Oceanic Weather Service.
2. When the weather radio reception, weather channel reception depends on the distance from the broadcasting station and the surrounding terrain. For the best reception, ensure that channel transmissions are unloaded, they are broken static or noise.

FM Radio

The radio features an FM broadcast receiver, covering a range of stations across the frequency spectrum from 87.5MHz to 108MHz.



To turn on the radio, Press the **CHDE** button twice, the ☐ icon is displayed on the screen, indicating that the FM radio is active.

Fine-tune the FM radio frequency: after entering the FM radio mode, press the **MENU** + **CALL** button to enter the FM frequency.

Automatically scan the FM radio station: After entering the FM radio mode, press and hold the **MENU** button for 3 seconds to start the automatic search for available stations. The radio will stop when it detects a signal. After pressing a FM radio station with a signal, it will stop immediately. Press the **PTT** button to exit the search.

Exit the FM radio: Press the **CHDE** button again to turn off the radio. You will return to standby mode.

Note: The FM radio is designed for use with your environment. Move to an outdoor location for improved reception for the best experience.

English 7
English 8

06 Mode Functions

Scrolling Through the Mode Function

Try scrolling through the **MENU** functions, you can select or switch on your preferred settings. Press the **MENU** button to enter the **MENU** mode, then press the ▲ or ▼ button to scroll through the following functions:

MENU Functions	Further Functions and Setting Options
Back	Ch-Channel
Ch-Channel	Ch-Channel Selection

Ch - Channel	22 channels
Call Tone Selection	off-01-02-03-04
Voice Leveling	off-01-06
Power Saving	off-01-06
Dual Watch Control	on or off
Key Tone setting	on or off
Keypad Automation Tone	on or off
Screen backlight	on or off
120 Hdp Options	on or off
Roger Beep	on or off
VOX Control	on or off
Channel Scanning	22 channels
DCS/CTCSS Encoding & Decoding	01-02-03-04
Privacy Codes	01-02-03-04-05-06-07-08

When the Dual Watch is enabled, the radio has the setting the channel and the ☐☐ icon appear. It will be hidden when Dual Watch is disabled.

English 9
English 10

Power saving

Press the **MENU** + **PTT** (3 s) to select Power saving.

Press **MENU** to confirm and **POWER SAVER** icon appears.

Press **PTT/CALL** button to confirm or **MENU** button to continue.

Press the ▲ or ▼ button to select the desired power saving level.

Tip: The higher power saving level may cause the first 0.6-0.5 seconds of transmission to be cut off.

Call Alert

Your radio can send a call reminder of a fixed duration, to send a call reminder, press the **CALL** button. The ☐ icon will appear and the call alert will be sent out.

Setting Call Alert Tones

There are two additional call tones.

Press the **MENU** + **CALL** button, the screen displays the ☐ icon.

Press the ▲ or ▼ button to select the desired call tone.

Press **PTT/CALL** button to confirm or **MENU** button to continue.

Note: Call tone selection remains active until you select a different one.

Key Tone On/Off

You can enable or disable the key tone sound.

Press the **MENU** + **5** button, the ☐ icon appears.

Press **MENU** to confirm and ☐ of the key tone.

Press **PTT/CALL** button to confirm or **MENU** button to continue.

English 11
English 12

Vibration Alert

Vibration is used for incoming signals.

Press **MENU** button until the ☐ icon appears.

Press the ▲ or ▼ button to select **ON** or **OFF**.

Press **PTT/CALL** button to confirm or **MENU** button to continue.

Note: Turn on the vibration reminder, and the radio will vibrate when receiving signals. Vibration mode will not vibrate repeatedly within a specific time.

Dual Watch

The radio has a dual-receive mode, allowing users to scan 2 channels to monitor activity. Press the **MENU** + **0** button, the ☐ icon appears on the screen, indicating that Dual Watch is enabled.

Turn On Dual Watch Mode:

Press **MENU** to confirm and the **ZCH** icon appears.

Press the ▲ or ▼ button to select the transmission power level.

Press **PTT/CALL** button to confirm or **MENU** button to continue.

Channels A (A-01-02-03-04) has been paired with **Channels** 5-7 and 15-22 can set DCS / QT or top-tier transmit power level.

Channels B (B-01-02-03-04) has been paired with **Channels** 8-14. The same to receive Low and no DCS / QT adjustment.

English 13
English 14

07 Product parameter

Model	GUIPROPLUS
Transmit Power	0.5 Watts / 2 Watts
Channel Capacity	22 Channels
Frequency Range	462.5625-467.7125MHz
Frequency Stability	± 2.5ppm
Channel Spacing	12.5/25kHz
Channels	22
Privacy Codes	121 DTCSS (-38,39,39-152)
Type of using	2Way
Radio Interface	Type-C
Operating Voltage	3.7V
Operating Temperature	-10℃ - 60℃
Battery Type	1800mAh Lithium Battery

08 Frequency table

■ Weather Channels and Frequencies

Ch	Freq.	Ch	Freq.
1	162.550	4	162.425
2	162.400	5	162.450
3	162.475	6	162.500
7	162.525	8	161.650
9	161.775	10	163.275

■ CTCSS Privacy Code Table

Ch	Freq.	Ch	Freq.	Ch	Freq.	Ch	Freq.
01	67.0	12	94.8	23	136.5	34	186.2
02	69.3	13	97.4	24	141.3	35	192.8
03	71.9	14	100.0	25	146.2	36	203.5
04	74.4	15	103.5	26	151.4	37	210.7
05	77.0	16	107.2	27	156.7	38	218.1
06	79.7	17	110.9	28	162.2	39	225.7
07	82.5	18	114.8	29	167.9	40	233.6
08	85.4	19	118.8	30	173.8	41	241.8
09	88.5	20	123.0	31	179.9	42	250.3
10	91.5	21	127.3	32	186.2	43	254.1
11	94.8	22	131.8	33	186.2		

■ Frequency Allocation

Ch	Freq. (MHZ)	Power	Ch	Freq. (MHZ)	Power
1	462.5625	0.5 / 2W	12	462.6625	0.5W
2	462.5875	0.5/2W	13	467.6875	0.5W
3	462.6125	0.5/2W	14	467.7125	0.5W
4	462.6375	0.5/2W	15	462.5500	0.5/2W
5	462.6625	0.5/2W	16	462.5750	0.5/2W
6	462.6875	0.5/2W	17	462.6000	0.5/2W
7	462.7125	0.5/2W	18	462.6250	0.5/2W
8	467.5625	0.5W	19	462.6500	0.5/2W
9	467.5875	0.5W	20	462.6750	0.5/2W
10	467.6125	0.5W	21	462.7000	0.5/2W
11	467.6375	0.5W	22	462.7250	0.5/2W

09 Frequently Asked Questions

About Waterproof Performance

- The waterproof performance of the radio may decrease with daily use and aging.
- If it must be used in extreme conditions, it is recommended to apply the sealer, please let it sit immediately to avoid damaging the radio.
- Please ensure that the battery cover, accessory port, and Type-C charging port are fully closed before using the radio to maintain its waterproof seal.

About Charging

- Please ensure the radio channels may also reduce the temperature before charging.

10 General Specifications

IMPORTANT NOTICE

WARNING! Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

11 RCSS-GMR

This device complies with EEDC license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Under EEDC regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by EEDC. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication. This radio transmitter has been approved by EEDC to operate with the antenna types listed below, with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.



English 15
English 16

Safety Information for Radios

Your wireless handheld portable transceiver contains a low power transmitter. When the **PTT** button is pushed, it sends out radio frequency (RF) signals. The signals can interfere with electronic devices that do not have adequate shielding. Such interference can cause malfunctions. FCC adopted RF exposure guidelines with safety levels for handheld wireless devices.

Normal Position

Hold the transceiver approximately 2 inches from your face and speak in a normal voice with the antenna pointed straight up.

Important

FCC RF Exposure Requirements: For bodyworn operation, this radio has been tested and meets the FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the radio a minimum of 1 inch from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the radio in the normal position next to your mouth, then position the radio and antenna at least one inch away from your body.

Radio Interference Statement-NOTE:

The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.



CE Maintenance

1. Use careful with the earphone maybe excessive sound pressure from earphones and



headphones can cause hearing loss.

2. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

3. The product shall only be connected to a USB interface of version USB2.0.

4.Adapter shall be installed near the equipment and shall be easily accessible.

5.EUT Operating temperature range: 0° C to 40° C .

6. Adapter： The plug considered as disconnect device of adapter

Power supply and ADP(rating):

Input: 100~240V, 50~60Hz, 0.25A

Output: 5.0V, 1000mA

Maximum utput power: 28.11dBm

7. The device complies with RF specifications when the device used at 25mm your body.

8. To prevent possible hearing damage. Do not listen at high volume levels for long periods.

Declaration of Conformity

Shenzhen Todakj Co.,Ltd. hereby declares that this Holding a walkie-talkie is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10),This product is allowed to be used in all EU member states.

CE

Federal Communication Commission Interference Statement
FCC ID: 2AQQS-G2PROPLUS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Radiation Exposure Statement:
This device meets the government's requirements for exposure to radio waves.
This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions (25mm) accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.