



291C 190C 116C 2767C

451 mm

92 mm

**PACKED PARTY**  
**SING IT!**  
WIRELESS MICROPHONE

**QUICK START GUIDE**  
UL-8006

### What's in the Box?

**A**

**B**

**C**

Quick Start Guide

A. 1 wireless microphone  
B. 1 USB-A to USB-C charging cable  
C. 1 quick start guide

### Basic Button Operation

<p>1. <b>Power</b> </p> <p>Long Press: ON/OFF Short Press: Mode switching</p> <p>2. <b>PREV</b> </p> <p>Press: Play the previous song</p> <p>3. <b>NEXT</b> </p> <p>Press: Play the next song</p> <p>4. <b>SCAN</b> </p> <p>Short Press: Play/Pause</p> <p>5. <b>REC</b> </p> <p>Long Press: Change different magic sounds</p>	<p>6. <b>"VOL +"</b></p> <p>Increase music volume</p> <p>7. <b>"VOL -"</b></p> <p>Decrease music volume</p> <p>8. <b>MIC VOL +/-</b></p> <p>Gradually push to adjust the sound of mic</p> <p>9. <b>REMIX +/-</b></p> <p>Gradually push to make your voice better</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Note:** The device will automatically power off after approximately 5-10 minutes in standby mode. The red indicator light turns on while charging and turns off when fully charged.

### Multi-function Operation

#### Wireless Karaoke

- Turn on the power: long press power button to turn on the microphone.
- Wireless connection: Open the Bluetooth of the mobile phone, click it to connect "Turn It Up Karaoke Mic" and the prompt sound appears to indicate successful connection.
- Turn on the music on your phones or Pads. (Don't need to download a special App, just use some normal audio software, such as Spotify, iTunes, YouTube etc.)
- Start Karaoke and adjust some settings according to the Basic Button Operation.

#### Selfie function

- Short press the button to switch from wireless mode to selfie mode.
- Connect the Bluetooth in the mobile phone, search Bluetooth "shutter", click it for connection.
- Turn on the camera of the mobile phone, press the button **PREV** or **NEXT** to take photos.

### Multi-function Operation

**Note:** This microphone can support both Android mobile phone(Above Android 4.2.2) and iPhone iOS system(Above iOS 6.0). It doesn't support the mobile phone which has a separate physical button to take photos.

#### Radio Mode

- Short press the button to switch from selfie mode to Radio mode.
- Long press the button **SCAN** to search FM Channels automatically.

#### Wireless Speaker Function

Plug the TF card or USB flash drive with music and play music, and the microphone can be used as a wireless speaker.

**Note:** The USB flash drive and TF card must be formatted to FAT32. Only MP3 format music files can be played.

### Multi-function Operation

#### Recording with mobile phone

- Turn on the power: long press power button to turn on the microphone.
- Connect the recording wire: Insert the Micro cable of the recording wire into the Micro interface of microphone, and plug the 3.5mm jack into the earphone jack of the mobile phone.
- Open the Karaoke software with recording function in the mobile phone, record the song according to the instructions of Karaoke software, then select your favorite song and start singing.
- Test and save the song: Refer to the instructions of Karaoke software.

### Technical Parameters

<b>Output Power:</b>	2W
<b>Frequency Range:</b>	100HZ-10KHZ
<b>Max Sound Pressure Level:</b>	>115DB 1KHZ THD<1%
<b>Reverberation Mode:</b>	Sound Effect Reverberation
<b>Power Supply:</b>	Built-in 14500 Li-Battery
<b>Battery Capacity:</b>	500mAh
<b>Charging Power:</b>	DC 5V
<b>Transmission Distance:</b>	32.8 ft (10 meters) at an environment without wall blocking

**WARNING:** Listening to loud audio for extended periods of time may damage your hearing permanently.

### Need Help?

For customer support regarding your device, please submit a request by emailing [techsupport@packedparty.com](mailto:techsupport@packedparty.com).

Please make sure to note the model number and a description of your inquiry.

Thank you for purchasing a Packed Party product.

Designed in Austin, Texas. Made in China. All designs © 2026 Packed Party, Inc. All Rights Reserved. © 2026  
USB is used to solely describe the compatibility of our technology and in no way is intended to infringe on any intellectual property rights of any respective protected marks. Siri is a registered trademark of Apple Inc. Packed Party is a registered trademark of Packed Party, Inc.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: Changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

**PACKED PARTY**  
**LIFE'S A PARTY**  
WHEN YOU MAKE IT ONE!  
[WWW.PACKEDPARTY.COM](http://WWW.PACKEDPARTY.COM)

**FOLLOW THE PARTY**  
**@PACKEDPARTY**

折痕线