

TO BE REMOVED BY THE CUSTOMER AFTER INSTALLATION IS COMPLETE

(Vea el otro lado para la versin español.)

✓ **INSTALLATION CHECKOFF LIST**

Doors

- ☐ Door seals completely to cabinet on all sides
- ☐ Freezer door is level across the top

Leveling

- ☐ Refrigerator is level, side to side and tilted 1/4" (6mm) front to back
- ☐ Toe grille is properly attached to refrigerator
- ☐ Cabinet is setting solid on all corners

Electrical Power

- ☐ House power turned on
- ☐ Refrigerator plugged in

Ice Maker


- ☐ House water supply connected to refrigerator
- ☐ No water leaks present at all connections - recheck in 24 hours
- ☐ Ice Maker is turned ON.

Final Checks


- ☐ Shipping material removed
- ☐ Fresh Food and Freezer controls set
- ☐ Crisper Humidity controls set
- ☐ Registration Card sent in

Refer to your *Owner's Use and Care Manual* for additional information about your refrigerator.

Tools You Will Need:




1 HAND TRUCKING




- Load refrigerator from side of cabinet only.
- Do not run retaining straps over handles.
- Do not over-tighten retaining straps.
- Never use refrigerator handles to move the refrigerator.
- Remove tape from doors only after unit is in place.

2 SHIPPING MATERIAL



Remove Shipping material. (Features may vary per model.)

3 WATER SUPPLY



The water valve on the back of the refrigerator will Click/Buzz if the water valve is closed.

House plumbing line

Waterline hookup

Be certain the water valve is open and there are no leaks.

WATER SUPPLY

Connect water supply - check for water leaks. Turn icemaker OFF if water supply is not connected immediately. Connecting to a reverse osmosis system is not recommended.

4 INSTALLATION CLEARANCES

Allow the following clearances for ease of installation, proper air circulation, and plumbing and electrical connections:

- Sides & Top.....3/8"
- Back.....1"


NOTE: If you are installing your refrigerator beside a wall, leave 1/2" minimum between hinges and wall to allow for the door to swing open.

5 LEVELING AND ADJUSTING

All four corners of refrigerator must rest firmly on a solid floor. Your refrigerator has adjustable rollers to help level it and to adjust the doors.



To level cabinet or change door height:

1. Remove toe grille.
2. Use a screwdriver, 3/8" wrench, or nutdriver to adjust the rollers. To raise cabinet, turn screw clockwise. To lower cabinet, turn screw counterclockwise.




6 CONTROLS

When changing **CONTROLS**, wait 24 hours before making additional adjustments.




7 ICEMAKER



Ensure icemaker is turned ON.

8 DOOR REMOVAL



If you need to remove the doors to get your refrigerator into the house please see "Door Removal Instructions" in your *Use & Care Guide*.

9 REGISTRATION

- ✓ See "Normal Operating Sights & Sounds" in the *Use & Care Manual* so you understand the sounds you may hear once your refrigerator is running.
- ✓ Please read entire *Use & Care Manual* to become aware of important safety instructions and to become familiar with your new refrigerator.
- ✓ Send in Registration card to register your refrigerator.
- ✓ Congratulations! You are ready to enjoy your new refrigerator.

IF YOU ARE DISSATISFIED WITH THE INSTALLATION, PLEASE CALL THE STORE YOU PURCHASED IT FROM.



✓ **LISTA DE VERIFICACION DE LA INSTALACION**

Puertas

- ☐ La puerta cierra herméticamente en todos los lados del gabinete
- ☐ Las puertas están niveladas a través de la parte superior

Nivelación

- ☐ El refrigerador está nivelado de lado a lado e inclinado 1/4" (6 mm) desde adelante hacia atrás
- ☐ La rejilla inferior está correctamente instalada en el refrigerador
- ☐ El gabinete descansa firmemente en todas las esquinas

Energía Eléctrica

- ☐ La energía eléctrica de la casa está conectada
- ☐ El refrigerador está enchufado


Máquina de Hacer Hielo

- ☐ El suministro de agua del hogar está conectado al refrigerador
- ☐ Los acoplamientos del agua y de la energía están conectados en la puerta
- ☐ No hay escape de agua en ninguna de las conexiones - verifique nuevamente dentro de 24 horas
- ☐ La máquina de hacer hielo está ACTIVADA


Verificaciones Finales

- ☐ Se retiraron los materiales de embarque
- ☐ Se ajustaron los controles del refrigerador y del congelador
- ☐ Se ajustaron los controles de humedad del cajón de las verduras
- ☐ Se envió la Tarjeta de Registro

Consulte el *Manual de Uso y Cuidado* para obtener mayor información sobre su refrigerador.




1 TRANSPORTE CON CARRETILLA




- Cargue el refrigerador por el lado del gabinete solamente.
- No pase las correas por encima de las manijas.
- No apriete demasiado las correas.
- Nunca use las manijas del refrigerador para moverlo.
- Retire la cinta de las puertas después que el refrigerador esté instalado en su lugar.


2 MATERIALES DE EMBARQUE



Retire los materiales de embarque.
(La características pueden variar según el modelo.)



La válvula del agua en la parte trasera del refrigerador emitirá un ruido seco/zumbido si la válvula del agua está



Asegúrese de que la válvula del agua esté abierta y que no haya fugas.

SUMINISTRO DE AGUA

Conecte el suministro de agua - verifique si hay escapes de agua. **APAGUE** la máquina de hacer hielo si el suministro de agua no es conectado inmediatamente. No se recomienda la conexión a un sistema de osmosis inversa.


4 ESPACIOS LIBRES PARA LA INSTALACION

Deje los siguientes espacios libres para facilitar la circulación de aire adecuada durante la instalación y para las conexiones eléctricas de fontanería:

- Lados y parte superior....3/8"
- Parte trasera1"




NOTA: Si instala el refrigerador junto a una pared, deje un espacio mínimo de 12,7 mm (1/2 pulg.) entre las bisagras y la pared para permitir que la puerta se pueda abrir.

5 NIVELADO Y AJUSTE




6 Cuando ajuste de controles, espere 24 horas para que la temperatura se establezca antes de hacer cambios adicionales.

CONTROLES




7



La máquina de hacer hielo está ACTIVADA

8



Si es necesario retirar las puertas para poder entrar el refrigerador en la casa, por favor vea la sección *Instrucciones para el Desmontaje de las Puertas* en su Manual de Uso y Cuidado.

9

- ✓ Vea la sección "Sonidos Normales del Funcionamiento" en el *Manual de Uso y Cuidado* para que se familiarice con los sonidos que pueda oír cuando su refrigerador sea puesto en funcionamiento.
- ✓ Por favor lea todo el *Manual de Uso y Cuidado* para conocer las instrucciones importantes de seguridad y para familiarizarse con su nuevo refrigerador.
- ✓ Envíe la Tarjeta de Registro para registrar su refrigerador.
- ✓ ¡Felicitaciones! Ya puede comenzar a disfrutar de su nuevo refrigerador.