




BEEM 490

Smart LED Projector

USER MANUAL


PACKING LIST




1 Projector



2 Remote
(Batteries Not Included)




3 User Manual



4 HDMI Cable



5 Power Cable




6 Cotton Swab



7 AV Cable

01 / Remote control introduction



Power button:
Turn on/off



Mute button:
Mute



Focus button:
Adjust focal distance



Signal source button:
Choose to enter the Application Center, HDMI



Return button:
return to last step



Menu button:
enter the setting page



Home button:
short press and return to the homepage




Direction Buttons:
● Up ● Down
● Left ● Right
● OK




Volume button:
Volume-, Volume+

● To avoid power shortage, please do not mix up the old and new batteries. To avoid battery leakage and corrosion, please take the battery out if do not use remote control for a long time.

02/Host Appearance and Function Description



◀ Left ▶ Right ▲ Up ▼ Down **ENTER** OK ≡ Menu [Signal Source] Signal Source [Return] Return [Power] Power button




Headphone HDMI 1 HDMI 2 USB 1 USB 2 Power

03/Setting


First step

On the homepage, Settings



Second step


you can find Wifi setting,
Bluetooth setting, language setting...



04/Search page


First step

On the home page,
click Free Search in the upper left corner.




Second step

You can get what you are interested in.




05/Interface connection


USB interface




Display USB logo
connection is successful




• FileManager



HDMI interface




• On the homepage,HDMI1/HDMI2



06 / Auto Focus / Auto Keystone / Electronic focusing


Auto Focus

Move the projector, the following picture will appear and it will be in Auto Focus




Auto Keystone

Move the projector, the following picture will appear and it will be in Auto Keystone





Electronic focusing

Press the " ⏪ " " ⏩ " " ⏴ " to adjust clarity



07/Projection distance & size




08/Technology Features

Imaging technology	TFT LCD	Power input	100V-240V-50/60HZ
Native resolution	1920 x 1080	Input	USB x 2/HDMI x 2/AV
Light source	LED	Output	Earphone
Focus mode	Automatic focus	Speaker	5W
Projection distance	1.2 - 4.5M	Unit size	245 x 192 x 94mm
Screen size	39-150 inches	Net Weight	1.5KG
Aspect ratio	16: 9	Throw Ratio	1.35:1

09/Unload the Dust Net and Clear

First step

Take out dust net from the projector bottom



Second step


Clean the dust net

! For your safety, please cut off the power before cleaning



Third step


Align the bottom bayonet and install the dust net




10/Projector Installation

• Desktop use


- ① attachment bracket



- ② Rotate the bracket until it is fixed.




- ③ Installation completed




• Hoisting and use


- ① attachment bracket



- ② Rotate the machine to a fixed position.



- Installation completed



● Fixed Hanger Screw Hole Type: 1/4 inch threaded hole

Note: The above brackets are not included with the machine, and are for illustration only.

Please read the notes carefully:

- To ensure stable power supply, please use national standard power cable and power cord with grounding;
- Please use the type of power supply indicated on the projector and the supplied power supply for power supply;
- Please do not disassemble the machine yourself, otherwise the company will not undertake warranty service;
- Do not look directly at the projector lens while the machine is working, it might cause damage to your eyes;
- To prevent clogging the projector vents, do not cover them with cloth, carpet or other materials;
- This projector does not have waterproof function, please keep it away from rain, moisture and other items containing liquid such as vase, cup, etc;
- To prevent electric shock, please keep the projector away from rain, water or moisture;
- Cut off the power supply if do not use this projector for a long time;
- Use the original foam or other anti-shock material to protect projector if you need transport this projector;
- If you find the projector has problems, please contact with the supplier, do not repair by yourself;
- To extend the projector life span and protect your eyesight, we suggest you may have a break after 3-4 hours using.

Note: Any damage caused by physical impact, water/ liquid, fire, etc. caused by the customer or nature shall not be covered under warranty.

Only product design, feature and functionality-related faults can be considered. As per the brand's discretion, the product is eligible for repair and not for replacement, during the warranty period.



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hours : Monday - Saturday, 10:00am - 6:00pm)



E-Waste Management

E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste