


PORTABLE WIRELESS LABEL PRINTER

B11s Series




Please read the instruction manual carefully before using the product.

Version:4.0

PACKAGE CONTENT&SPECIFICATIONS

Item Checklist



Printer*1



Instruction Manual*1



Type-C Cable*1



Paper

Specifications

Name	Portable Wireless Label Printer
Model	B11s
Reference model	B11、B11 Pro、C11、C11 Pro、C11a、C11b、C11-BT、C11s、C11 Max、D492、D492a、D492b
Consumable Width	25-56mm
Resolution	203dpi
Communication Port	USB/Bluetooth
Power Supply	Type-C 5V $\bar{\equiv}$ 2A
Product Dimensions	91*130*65mm
Manufacturer	xiamen AiYin Technology Co., Ltd.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Warning

IC Caution:

Radio Standards Specification RSS-Gen, issue 5-English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-French:

Cet appareil contient des émetteurs /récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada.

Le fonctionnement est soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.


Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil. Déclaration d'exposition

RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF.


L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

Product Introduction




Installation Consumables

Press down the cover button to open the paper bin cover.



Move the paper guide to the center and load the paper with the printing side facing down into the paper tray.



Label Paper: Press the power button once, and the label will feed out



Charging Introduction

- Please connect one end of the included USB cable to the device and the other end to a 5V = 2A adapter or computer USB port for charging;
- Charge time: about 3 hours;
- We recommend you to use Mobile phone chargers for charging;
- If not used for a long time, please charge once every 3 months to avoid long-term natural loss of lithium battery can not be charged.



This product has a built-in rechargeable lithium-ion battery which cannot be removed by end-users.
Do not dispose of this product together with household waste.
At the end of product life, hand over the whole device to an official collection point for electrical and electronic waste for battery recycling.
The battery shall only be removed by qualified service personnel. Do not attempt to disassemble the battery or product housing.
Batteries must not be burned or incinerated.

Power Button Description

Button	Operation	Functions
Power button	Hold for 2 seconds	Power on/off
	Press twice	Print diagnostic page and the QR code to connect the printer with smart phone App
	Press once	The label will runout and stay in the gap
	Press three times	Learning Function

Indicator Light

Light	Functions
Light steady on	Bluetooth connected
Light flashing slowly	Bluetooth disconnected
Green light on	Normal use status /Full charged
Red light on	Cover opened/Nopaper/Over-heat
Yellow light on	Low battery,please charge in time
Yellow light flashing quickly	Charging



Auto power off: The printer will automatically power off after 20 minutes without operation. You can set the timer in the App.

How to Use Usage Overview



App Download (Printing with your phone)

Method 1:

Search for [Lable expert]on Google Play or App Store.



Method 2:

Scan the following QR code to download App.



- 1 iOS: Turn on Bluetooth,allow Lable expert App to access.
Android: Turn on Bluetooth and Location,allow Lable expert App to access.
- 2 Open the corresponding APP and tap the device icon in the upper right corner to connect the thermal printer.



NOTE

- This product needs to be connected to the printer in the App;
- Due to the requirements of mobile phone system,the Android mobile phone will use the user's geographic location when connecting,so that the user needs to turn on the GPS and confirm the authorization;
- This app only supports phones with Android 7.0 or iOS 11.0 or above systems.

Driver Download (Printing with your computer)

- 1 Visit <https://help.aiyin.com> you can download driver after searching keyword Shipping Printer Driver.Note: Before installing the driver, turn off the computer antivirus software.
- 2 Turn on the printer. Connect the printer to computer via USB cable Double-click the file you downloaded to install the driver.
- 3 Click install.
- 4 Click Finish after installation.



NOTE

Please turn on the printer before connecting it to the computer.

Manufacturer:
xiamen AiYin Technology Co., Ltd.