

1.  Turn the fan "OFF" only.


2.  Adjust the fan speed from 1 (low) to 6 (high)

3.  Creates a natural Breeze effect.

4.  Light ON/OFF.


5.  Forward / Reverse alters the direction of blade rotation. (Summer / Winter)

6.  Adjust Light colour (Cool, Natural and Warm)


7.  Adjust the light intensity up to maximum brightness.
 Adjust the light intensity down to minimum brightness. (For LED model only)

8.   One, four hour Fan off timer.

9.  Night light mode. (原来按键上的 8H 改成这个)



x 2 AAA batteries included.
Note: Use good quality
Lithium batteries to extend
time between Battery
changes.



Remote control Pairing:

How to pair the remote control (without wall control):

Step 1: Preparation: Turn the isolation switch 'OFF' for a minimum of 1 minute.

Step 2: Turn the isolation switch or speed dial /light switch on and within 2 seconds, press and hold the fan off button for 3-4 seconds until you hear a 'beep, beep' sound to indicate pairing succeeded.

FCC statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.