







Function Keys and Operating Instructions

Features	Button		Instructions
Power On/Off		Long press	Press and hold for 3 seconds to turn the device on or off
Play/Pause	○	Short press	In mobile music playback mode: Tap once to play or pause the music
Answer/Hang up		Short press	In call mode: Press briefly to answer the call Press briefly again to end the call
Block calls		Long press	In call mode: Press and hold to reject Hang up
End Replay		Double-click	In call mode: Double-tap the last number to redial
Turn up the volume	+	Short press Long press	Tap briefly to increase the volume one level at a time; press and hold to increase the volume continuously
Volume decreases	-	Short press Long press	Press briefly to decrease the volume one level at a time, press and hold to decrease the volume continuously
Previous Song	↶	Short press	When the Bluetooth connection is active: While music is playing on your phone, press briefly to skip to the previous track
Next song	↷	Short press	When the Wireless connection is active: While music is playing on your phone, press briefly to skip to the previous track
Voice Assistant		Double-click	When the Wireless connection is active: Double-tap to activate the voice assistant, then double-tap again to exit the voice assistant (depending on your phone)



日本語



Magyar nyelv



čeština



Język polski



Nederlands



Svenska



Franska



Ελληνικά



Italiano



Dansk



Deutsch



Türkçe

