

Thank you for your purchase! We hope you enjoy your new **Groovz Headphones**.

If you have any questions or concerns, please reach out:
support@groovzaudio.com.

Visit us at **www.groovzaudio.com** for exciting product offers and to register your warranty.

We are here to help!

  @Groovzaudio



GROOVZ

OPEN

Open Ear Wireless Headphones

MANUAL GUIDE



GROOVZ

MANUAL GUIDE

TABLE OF CONTENTS

DEVICE DIAGRAM	01	TROUBLESHOOTING	09
PACKAGE CONTENTS	02	PRECAUTIONS FOR USE	11
SPECIFICATION	03	WARRANTY INFORMATION	13
SETTING UP YOUR HEADPHONES	04	NEED HELP?	14
• Bluetooth Pairing	04		
• Turn ON	05		
• Turn OFF	06		
• How to Operate	07		
• How to Wear	08		



- 1 Charging Pin
- 2 Call Microphone
- 3 Indicator Light
- 4 Touch Area
- 5 Noise Reduction Mic
- 6 Charging Contact
- 7 Sound Output
- 8 Power Display
- 9 Type-C Interface

PACKAGE LIST

- Bluetooth Headsets
- Headphone Charging Case
- Type-C Charging Cable
- User Guide



SPECIFICATION

Model:	Y70
Speaker:	14.2 mm
Earbud Battery:	70 mAh
Music Time:	≈6.6 h
Charging Port:	Type-C
Stand by Time:	≈200 days
Bluetooth Version:	V5.3
Frequency Range:	20Hz ~ 20kHz
Charging Case Battery:	450 mAh


Call Time:	≈4.5 h
Charging Time:	≈1.5 h
Transmission Distance	≥10 m

03

BLUETOOTH PAIRING

- Take out the earbud from the charging case, and the earbud will automatically turn on.
- Turn on your phone's Bluetooth and find the device name "Groovz" in the Bluetooth list.
- Click on the connection button, and a voice reminder will be given after the connection is successful.

Note: If there is existing pairing information, the headset will automatically connect to the device. If the headset is not connected to any device, it will automatically turn off after 3 minutes of standby.



04

TURN ON

- Open the top cover of the charging compartment and remove the headphones. At this time, the headphones will automatically turn on and pair, waiting to connect to the phone.
- If the earphones are not in the charging compartment and are turned off, press and hold the left or right earbud for 3 seconds to turn them on.



05

TURN OFF

- Put the left and right earphones into the charging compartment, and the earphones will automatically shut down and begin charging.
- Press and hold the left or right earbud for 5 seconds while the headphones are connected to turn off the device.



06

HOW TO OPERATE

PLAYING STATE

Play/Pause	Single Tap
Previous Track	Double Tap Left
Next Track	Double Tap Right
Volume +	Triple Tap Left
Volume -	Triple Tap Right

CALL STATE

Answer/End a Phone Call	Single Tap
Reject a Phone Call	Long Press

IN SIRI

Active Voice Assistant	Tap & Hold for 2 Seconds
------------------------	--------------------------

WEAR

Please confirm left/right ear before wearing

STEP 1

Gently hang the earbud to the ear.

STEP 2

Gently rotate backwards to adjust the angle.

STEP 3

Until the earbuds are securely worn.



TROUBLESHOOTING

HAVING TROUBLE PAIRING YOUR GROOVZ EARBUDS?

- **Ensure Bluetooth Is On:** Confirm Bluetooth is enabled on your smartphone, tablet, or computer.
- **Check Earbud Battery:** Place the earbuds in the case and check the LED indicators to ensure they are charged.
- **Charge the Case:** Connect the charging case to power if the battery is low.
- **Restart Your Devices:** Restart your device (phone, tablet, etc.).

RE-PAIRING STEPS:

- **Forget the Device:** Remove the earbuds from your device's Bluetooth list (this is often called "forget" or "unpair").
- **Restart Bluetooth:** Turn Bluetooth off and back on again on your device.
- **Re-Pair the Earbuds:** Place the earbuds in pairing mode and attempt to pair again.

PRECAUTIONS FOR USE

- Store headphones in a cool, dry, ventilated environment. Avoid contact with oil, water vapor, and steam as this can void the warranty.
- Avoid cleaning with irritating, organic solvents or materials containing these ingredients.
- Use the headset according to the provided specifications, and avoid exposing it to environments that could affect performance like moisture, dust, or extreme heat.
- Do not use soap or household cleaners to clean earbuds.

- To ensure smooth connection, it is recommended that the distance between the mobile phone and the earphone be within 10 meters.
- If the earphone fails to connect or communicate properly, do not dismantle the earphones without permission. The device and its accessories are not guaranteed otherwise.
- To charge the earphones, please use the standard Type-C charging cable or the one specified by our company.
- Keep the earphones sufficiently charged to ensure normal operation.

WARRANTY INFORMATION

Groovz headphones come with a 1-Year Limited Warranty from the date of purchase. The warranty covers defects in materials and workmanship. It does not cover accidental damage, misuse, or unauthorized repairs. Should your product become defective during the warranty period, we will repair or replace (at our option) your product.

To register your warranty or report any defects, please contact customer support at support@groovzaudio.com.



GROOVZ is a registered trademark of JTB Products, West Chester, PA.
Designed and Engineered in the USA.

GROOVZ

NEED HELP?

SCAN THIS CODE WITH YOUR PHONE FOR

- Step-by-step tutorial Videos
- Frequently asked questions
- 7-day-a-week support

www.groovzaudio.com
West Chester, PA

