

# TWS

## User Manual

FCC ID: 2BHIM-AI

### Warning

Special Note: Before using the earphone for the first time, please put the earphone into the ordinary charging case once and then remove it. Only then can touch be effective.

Please read the warnings below carefully. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to.

To reduce the risk of injury :

Keep batteries out of reach of children.

Do not heat, open, or dispose of battery pack in fire.

Do not allow metal objects to touch the battery on the device.

Do not expose battery pack to excessive heat.

Do not use a high current charger, or the charging line will burn out.

Please Charging with a DC 5V adapter (not included in the package)

### Product Specification

- Bluetooth version: 6.0
- Support: A2DP, AVRCP, HSP, HFP
- Playing time:6-7hours(High quality music and volume may accelerate battery consumption)
- Effective distance:>10M
- Speaker size: 10mm
- Sensitivity(horn unit): 105±1.5 dB S.P.L at 1KHz
- Speaker impedance(horn unit):32± 15% at 1mW / 1000Hz
- Mic sensitivity:-38±1dB
- Talk time:5-6 hours
- Earphone charging time: about 1H
- Charging case charging time: about 2H

### Pairing

#### 1:Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

Open up Bluetooth setting on your smart device and scan for **GS\_G25** .

## 2: Syncing your earphones

The headset is not synchronized during use.

- 1) : Turn off Bluetooth on your device.
- 2) : Put both headphones back into the headset case and close the charging case.
- 3) : Remove the headset and wait for pairing.
- 4) : Open Bluetooth Settings of smart device and scan GS-G25.

# Operation

## 1: Power on/off .

- 1.) Take the earphones out of the charging case, automatically turn on;  
Put the earphones back to the charging case, automatically turn off;
- 2.) Long press 3 seconds to turn on.  
Long press 5 seconds to turn off.

## 2: Play/Pause music.

When listening to music.

Quickly tap the left earphone twice to play or pause the music.

## 3: ANC Mode

When taking the earphones out of the charging case, it is regular Bluetooth mode.

Long press left earphones for 2 seconds to enter **Transparent mode**;

Long press left earphones for 2 seconds to enter **regular Bluetooth mode**.

Long press right earphones for 2 seconds to enter **Noise reduction mode**;

Long press right earphones for 2 seconds to enter **regular Bluetooth mode**.

## 4:Previous /Next Song

When listening to music.

Quick tap right earphones 3 times to go to previous song.

Quick tap Right earphones twice to go to next song.

## 5: Volume operation

When listening to music.

Tap the left earphone once to reduce the volume

Tap the right earphone once to increase the volume

## 6: Answer/Hang up

When there is an incoming call.

Tap the left and right headphones twice to answer the phone.

Tap the left and right earphones twice again to end the call.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.