

**How to Enable or Disable the Apple Find My network**

Follow the steps below to disable your Nomad Tracking Card from accessing the Find My network.

1. To disable the Find My network, press and hold the Find My button on the Card for 3 seconds. The Card will beep twice.
2. Press and release the Find My button once. The Tracking Card will play a tune.
3. Press and hold the Find My button for 3 seconds. The Tracking Card will beep twice to confirm the Find My network has been disabled.
4. To enable the Find My network, press and release the Find My button. The Tracking Card will play a tune to confirm the Find My network is enabled.

**How to Perform a Factory Reset**

Follow the steps below to unpair the Tracking Card from your Find My account so that it can be paired to a different Find My account.

1. Open the Find My app, navigate to the Items tab, and tap your Tracking Card.
2. Scroll to the bottom of the Item Detail card, tap Remove Item, and follow the instructions.
3. On the Tracking Card, press the Find My button 5 times in quick succession and hold the button on the 5th press.
4. The Tracking Card will play a tune and perform the factory reset.

**How to Find the Serial Number**

1. Via the Find My app: Open the Find My app, tap the Items tab, and tap your Tracking Card. Scroll to the bottom of the Item Detail card. The serial number is displayed below Manufacturer.
2. On the device: The serial number is printed on the backside of the Tracking Card.

**Use & Care**

The Tracking Card is water-resistant but not waterproof. We encourage you to bring your Tracking Card along on most of your wild adventures, but deep-sea explorations (and the like) are not recommended. It is not recommended that you expose the Charging Card to extreme hot or cold temperatures.

**Legal**

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple Find My, Apple Watch, Find My iPhone, iPad, iPadOS, iPod touch, Mac, macOS and watchOs are trademarks of Apple Inc. iOS is a trademark of Cisco and is used under license.

Before you put the Tracking Card in your wallet, let's get it connected to the Apple Find My app.

1. Quickly press and release the Find My button to turn on your Tracking Card.
2. Open the Apple Find My app on your iOS device, tap the + and select Add Other Item from the menu.
3. The Tracking Card will appear on the screen. Tap to connect and set a custom name and icon for your card.

**Charge Before Use**

Make sure to fully charge the Tracking Card battery before use.

**To Charge:** Align the lightning bolt icon with the center of your wireless charger.

**While Charging:** The indicator light will be red. When the battery is charged, the indicator light will be green.

**Features of the Apple Find My app**

The Tracking Card works exclusively with the Apple Find My network. The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, or Mac. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.

**Requirements**

To use the Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.

**Privacy**

The Apple Find My network uses advanced encryption to ensure that no one else, not even Apple or Nomad can view the location of your Tracking Card.

**FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, (2) this device must accept any interference received, including interference that

may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radiocommunications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

**Tracking Card Air - Find My**

NM009544858, NM009551858  
NM009537858

**Nomad Goods, Inc**

1187 Coast Village Rd. #638  
Suite 1 Santa Barbara, CA 93108