

portable director chair with side table



visit our website



SCAN ME
serenelifehome.com

The Portable Director Chair with Side Table is made for comfortable outdoor seating. It features a sturdy steel frame, padded seat, side table with cup holder, and a lightweight folding design for easy carrying and storage. Perfect for camping, picnics, tailgating, and outdoor events.

Features:

- Easy to Open and Fold with Carry Bag
- Lightweight and Portable Design
- Padded Seat, Shoulder Rest and Wide Armrest
- Durable, Rust-resistant Steel Frame
- Weather-Resistant 600D PVC Fabric
- Folds for Easy Packing and Transport
- Ideal for Camping, Tailgating, Picnics and Outdoor Events

What's in the Box:

- Portable Director Chair with Side Table with Cup Holder and Side Pocket
- Carry Bag

Technical Specs:

- Construction Materials: Steel Frame with 600D PVC Fabric
- Item Weight: 12.35 lbs
- Weight Capacity: 250 lbs
- Unfolded Dimensions (D x W x H): 33 x 20 x 34.6 Inches
- Folded Dimensions (L x W x H): 18.9 x 5.12 x 33.4 Inches

CALIFORNIA PROP 65 WARNING

⚠️ WARNING:

This product may expose you to chemicals, which is known to the state of California to cause cancer, birth defects and other reproductive harm. Do not ingest.

For more info go to: www.P65warnings.ca.gov



questions? comments?

We are here to help!

Phone: 1.718.535.1800

serenelifehome.com/contact-us

Safety Information

IMPORTANT NOTICE

Please retain these instructions for future reference.

1. Be careful when opening and folding the chair.
2. Make sure the chair is fully opened before use.
3. Children should use the chair with adult supervision.
4. Keep away from fire and heat.
5. Do not stand or jump on the chair.
6. Do not use on wet or slippery surfaces.
7. Do not exceed 250 lbs.



How to Open the Chair

1. Remove the chair from the carry bag.
2. Hold both sides of the frame.
3. Pull the chair open until fully expanded.
4. Make sure the chair is stable before use.

How to Fold the Chair

1. Remove items from the side table and cup holder.
2. Hold both sides of the frame.
3. Fold the chair inward slowly.
4. Place the chair into the carry bag.

Cleaning and Care

- Wipe the frame with a damp cloth.
- Clean fabric with mild soap and water.
- Let dry completely before storing.
- Do not use harsh cleaners.

Storage

- Store in a cool, dry place.
- Keep inside the carry bag when not in use.
- Avoid long exposure to rain and sunlight.



Register Product

Thank you for choosing SereneLife. By registering your product, you ensure that you receive the full benefits of our exclusive warranty and personalized customer support. Complete the form to access expert support and to keep your SereneLife purchase in perfect condition.

Start Here



serenelifehome.com/pages/register