


VIVANT


Where Temperature and Terroir Meet



Venus Portable Wine Chiller User Guide


How to Use

1




Plug the charging cord into the charging port or use battery to activate VIVANT Portable Wine Cooler.

2




Get wine from your wine cellar or refrigerator

3



Put the wine bottle into the VIVANT Portable Wine Chiller

4





Long press the power button for 3 seconds to activate the VIVANT Portable Wine Chiller, set your desired temperature.

5



Enjoy your wine, as the temperature will be maintained precisely by the VIVANT Portable Wine Chiller

Charging Method



① Offline charging:


Insert the battery pack into the charging dock, and wait until the indicator light turns from red to green, indicating that the battery is fully charged.

② Plug-in charging:

After installing the battery into the wine chiller, turn off the machine and plug the charging cord directly into the charging port.

Clean the water tray

▲ Empty the water tray after use. Steps 1~2 to unload the tray.



Notices


- Please charge the battery in the cooler before first use or after prolonged storage.
- To ensure the performance of heat dissipation, it's important to keep both sides of the chiller clear and allow for at least 30cm of space around it.
- To extend the life of the battery, it's suggested to charge it after each use.
- It is recommended to place the wine bottle as close as possible to the cooling plate of the machine.
- The battery is custom made for VIVANT products only, do not use non-product chargers to charge, and disassembling the battery is strictly prohibited.
- VIVANT portable wine chiller with temperature control contains electronic components, please do not place it in high-temperature environments such as dishwashers, microwaves, or ovens.

Please see more FAQ at <https://www.vivantwine.com>


Buttons on the Cooler/Indicators

Icon	Description
	Power button; long press to turn on/off the system.
	Long press the button to increase the temperature. When the temperature reaches the expected setting value, release the button and the screen will flash for three seconds to indicate that the setting is completed. Pressing the  and  buttons at the same time can switch between Celsius and Fahrenheit.
	Long press the button to decrease the temperature. When the temperature reaches the expected setting value, release the button and the screen will flash for three seconds to indicate that the setting is completed. Pressing the  and  buttons at the same time can switch between Celsius and Fahrenheit.
	Temperature display (acceptable temperature range for setting): When it is constantly on, it shows the current temperature; when it is flashing, it indicates that it has entered the setting mode and the temperature can be adjusted. After the temperature is set, the display screen will return to being constantly on (displaying the current temperature)." E0: Battery abnormal, or low power. Replace fully charged battery or use the AC cord to activate the machine. E3: Fan not working. Please contact VIVANT. E4: Temperature sensor abnormal. Please contact VIVANT.
	Battery power display (upward represents for power increasing; downward represents for power decreasing)
	Degree(s) Celsius
	Degree(s) Fahrenheit


Device Description



- ① LED Display
- ② Temperature-controlling buttons
- ③ Rechargeable Li-ion Battery Pack
- ④ Battery cover



- ⑤ Water tray
- ⑥ Charging socket



- ⑦ Bracket :
 - A connect to the chiller
 - B connect to the battery cover

▲ The battery life will gradually decrease over time, depending on usage. It is recommended to replace the battery every 2 to 3 years.

▲ To replace the battery, pull out the battery cover and use your finger to press the latch located at the bottom of the battery compartment. The side marked with the VIVANT logo should face upwards, then push the new battery pack all the way in.

▲ Temperature range: 8~20°C / 46~68°F

▲ Please use the power adapter and cord in the box. The power adapter can supply charging method and the VIVANT Wine Chiller

