

A6Plus说明书

165mm

140mm

Guidelines for use

AROMA

A6Plus
Essential Oil Diffuser

APEX
SCENT

Overview

Diffuser

Charging Cable

Essential Oils 15ml*5

Instructions

Step 1
Rotate the atomizing head clockwise and take it out.

Step 2
Pour the essential oil into the atomizing bottle.

Note: When adding essential oils, do not exceed the MAX line of the atomization bottle's capacity.

Step 3
Tighten the atomizing bottle onto the atomizing head.

Step 4
Screw the essential oil-filled atomizing assembly (atomizer head + atomizing bottle) tightly onto the diffuser main body, then turn on the diffuser for normal use.

Buttons/Indications

Power Button/Mood Light
Long press to power on/off.
Mood Light: After powering on, click to switch the light mode or turn off the light.

Bluetooth
Press and hold the Bluetooth button for 3 seconds to enter or exit Bluetooth mode. When Bluetooth mode is activated, the four gear indicator lights will light up and flash synchronously.

Gear
Click to switch gears.

Timer
Click to switch the timing.

Intensity

Timer

Gear I	Work for 15s, pause for 200s	● ○ ○ ○
Gear II	Work for 15s, pause for 100s	● ● ○ ○
Gear III	Work for 15s, pause for 60s	● ● ● ○
Gear IV	Work for 15s, pause for 30s	● ● ● ●

Bluetooth Mode
The gear indicator lights are on simultaneously.

1H	Shut down after 1 hour.	○ ○ ● ●
4H	Shut down after 4 hour.	○ ○ ● ●
8H	Shut down after 8 hour.	○ ● ● ●
24H	Shut down after 24 hour.	○ ● ● ●

Device shutdown timing ○ ○ ○

Caution/Maintenance

Safety Instructions

- If you are not a technician, do not attempt to modify, disassemble, or repair the equipment to avoid damage. In case of abnormal operation, first check if the equipment is used according to proper guidelines or refer to the troubleshooting manual. If the issue persists, contact us via email for after-sales support, and we will handle it appropriately.
- When adding essential oils, do not drip them into the device. Do not invert or tilt the device during use. If the device needs to be transported to another location, first perform maintenance and cleaning on it (see Equipment Maintenance for details), place it properly, and then pack and transport it to avoid damage caused by essential oil leakage. Be sure to maintain and clean the device to ensure it remains in optimal working condition.

Maintenance

To ensure optimal diffusion performance of the device, users can inspect and maintain it every six months. Maintenance is also recommended when frequently changing essential oil scents or noticing weakened diffusion effects.

- First, pour an appropriate amount of alcohol into the atomizing bottle for cleaning and let it dry (alcohol is used here as a cleaning agent to effectively remove residues and dirt inside the atomizing bottle).
- After cleaning the atomizing bottle, pour a small amount of alcohol into it again. Tighten the assembled atomizing bottle and atomizing head onto the diffuser, then turn on the device and run it for 5-8 minutes (this step allows alcohol to pass through the atomization system, thoroughly cleaning the precise pipes inside the atomizing head).
- After the cleaning run is complete, unscrew the atomizing bottle and atomizing head. At this point, there may still be residual alcohol on them. Place them in a well-ventilated area to allow the alcohol to dry and evaporate naturally. This step is crucial, as residual alcohol may affect the scent and effectiveness of essential oils used subsequently.

Prohibitions

Do not lay the machine flat or tilt it.

Do not directly drip essential oils into the spray outlet.

Why isn't the essential oil atomizing? →

When adding essential oils each time, note the following tips.

Replacement of Essential Oils

- When adding essential oils, do not exceed the MAX line of the atomization bottle. This is to prevent the essential oils in the bottle from being overfilled, which may cause the oils to surge due to air pressure, potentially atomizing the atomization hole, producing gurgling sounds, and affecting the atomization effect.
- Prohibited to pour in other liquids! Do not mix fragrance oils with different ingredients to avoid chemical reactions between components in some inferior oils, which may cause corrosion of the atomization core or block the precise atomization system of the diffuser!

If the equipment is blocked and fails to atomize, please refer to the maintenance methods in (Precautions/Maintenance) of this manual for deep cleaning of the atomization pipeline.

We recommend APEXSCENT fragrance essential oils. Our oils are carefully blended, safe and harmless, specially developed for cold mist diffusers, offering multiple fragrance options at reasonable prices.

1

Is the essential oil atomizing bottle tightened?

← Tighten this part!

2

Is the atomizing head tightened?

→ Tighten this part!

Troubleshooting

- After powering on, the diffuser does not operate or only runs without atomizing the essential oil.
 - Check if the machine has a low battery
 - Please connect the power cable to charge
 - During charging-The gear indicator light flashes cyclically.
 - Fully charged-The four gear indicator lights are always on.
 - Low battery-The gear indicator lights flash three times before turning off and shutting down.
- Power on, the device runs, but the device no mist/small mist
 - Check if it is waterless aroma essential oil
 - Add essential oils specifically designed for aroma diffusers. Avoid adding water or using essential oils made for humidifiers or spa treatments.
 - Check if the bottle, atomizing head, and body of the machine are tightly screwed
 - The atomization component must be fully tightened; otherwise, the machine will leak air due to incomplete sealing, resulting in the inability to atomize essential oils.
 - Check if it is outside the working hours set by the Bluetooth App. For example, today is Saturday, and the Bluetooth setting is Monday to Friday; or it is now 8 pm, and the Bluetooth App setting is from 6 am to 6 pm.
 - Create a new schedule and save it.

❖ Using for a Period

- Check if the device is clogged. After turning on the machine, press your finger against the mist outlet to check for air jet pressure.
- Refer to the machine cleaning and maintenance steps, clean the machine regularly.
- Check if the essential oil in the oil storage tank is below the minimum capacity of 5%.
- Add essential oils specifically designed for aroma diffusers

The fragrance is not strong enough.

- Under normal circumstances, our machine can cover an area of 1000-1500 square feet. However, you can enhance the fragrance by following the methods below.
- Choose high-concentration waterless essential oil (recommended not to exceed 85%)
- Re-select the gear button or open the app to reset a longer mist/work time.
- Place the machine near the air intake of the room, and the natural air flow will carry the subtle dry fragrance throughout the space.
- Ensure that there's at least 3 feet of clearance above the diffuser so that nothing is blocking the air from passing over the diffuser and dispersing scent in the room.

Parameters

Product Name	Essential Oil Diffuser
Model	A6 Plus
Power	10W
Input	DC 5V = 2A (Type-C)
Coverage	1500sq.ft
Battery Capacity	1000mAh
Essential Oil Volume	100ml
Product Size	Φ120*368(mm)
N.Weight	1.8kg


FUTURE FRAGRANCE RESEARCH (HONGKONG) LIMITED
ADDRESS: RM G8, FLAT 4, 3/F, BLK A TAK LEE IND CENTRE, 8 TSNINGYUNG CIRCUIT, TUEN MUN HONG KONG

If you have any questions while using the device, please feel free to contact us:
apexcscent@proton.me | 163.com

Order ID:
Describe the issues you meet.
Add some pictures or video

825mm

A6Plus蓝牙折页



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.