

LED Matrix Panel




User Manual


Full Color LED Screen/Custom Editing/Double-Row Display



Remote Control Guidelines



1.Download & Install APP





Scan the QR code below to download and install app with your mobile phone, or enter Google Play/APP Store and search for “iPixel Color” to download



Scan the QR code and download the APP


2.If you don't have APP Store/Google Play, please click the third one to download from Local Server




3.APP Authorization Permission

Firstly, Turn ON Bluetooth and Location


① Allow access to your location information



② Allow to find and connect to nearby devices




4. Connect The Device



Note:

- 1: When you open the APP for the first time, please Allow to all permissions
- 2: Please click the + sign to add a Bluetooth device
- 3: If Bluetooth cannot be searched on your Android phone, please check if you have turned on the GPS.




5. Text Editing



6. Text border/Special Effects/Records Kept



7.Partition Display




page down

8.Partition Display



9.Partition Display



Save


Edit Frame/Insert

undo/restore
Horizontal mirror/Vertical mirror
Move the layer/Insert a picture

Standard Color

Color Palette

Move/Zoom Out/Zoom In
Delete/Eraser/Brush





Edit

Preview

adjust the brightness
adjust the speed

Insert Image
Delete
Preview Play


10. Gallery




download materials

Dynamic image / Static image

11. Program List





Select ←



→ Delete

→ Delete/Play

12.Remote Control




Remote Control
Power Switch

edit the
preset content


Preset Content

send/
restore defaults



save



13.Clock




Time System/Date

14. Text Animations

Modify/Delete Text Animations



15. Text Animations



Text

Text animation


Gallery

Delete

Cancel

Skip to No.5-
Text Editingg

kip to No.10-Galler



Enter text

Text Color Effect

Text Color

Dynamic Effect



Adjust Speed

Dwell Time

text direction

save

16.Settings



Switch Language

Restore Factory Settings

Device Version Information

Locking Password Setting

Screen Rotation

Adjust Screen Brightness

APP Version Number

Operation Instructions for Resetting the Device :

This method for resetting the device : applicable when the device cannot be connected after a password is set. This process does not require the use of an app; it can be completed simply by turning the power on and off five times.

Execution of the reset operation:

Power on the device and observe its status. Once see the white light, quickly turn off the power switch. Repeat this process five times in a row.

On → Off → On → Off → On → Off → On → Off → On → Off → On (five times in total).

Notes:

Operation frequency: Perform the on/off operation after seeing the white light. If the intervals are too long or too short, the operation may be ineffective.

The number of consecutive power on/off cycles must be strictly no less than five. Fewer cycles may not trigger the reset.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm the radiator human body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna nr transmitter.

- a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate."
- b) The statement "Even used batteries may cause severe injury or death."
- c) The statement "Call a local poison control center for treatment information."
- d) A statement indicating the compatible battery type (e.g., LR44, CR2032). (LR44, CR2032). (LR44, CR2032)。
- e) A statement indicating the nominal battery voltage. 3.7v
- f) The statement "Non-rechargeable batteries are not to be recharged." g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- a) The statement "Ensure the batteries are installed correctly according to polarity (+ and -).
- b) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- c) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- d) The statement "Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children."



RoHS



