

User Manual


Specifications

- Output Power: 30W
- Drive Unit: 6.5Inch Subwoofer & 2Inch Tweeter*2
- Wireless Version: V5.3
- Wireless Name : A6
- Battery Capacity: 4000mAh(3.7V)
- Power Input: DC 5V==2A
- Battery Charging Time: about 5-6 Hours
- Play Time: about 4-5 Hours
- Wireless Range: 20m
- TF Card/ USB Reader Supported
- Product Dimension: L348mm * W145mm * H257mm
- Product Weight: 2000g

Above is the Lab test data, the actual use time may differ by environment and use habits, for reference only.

Package


Karaoke Machine x1
Wireless Microphone x2
Hand Belt x1
Charge Cable x2
3.5mm AUX Cable x1
Remote Control x1
User Manual x1



- (1) Microphone Input
- (2) AUX 3.5mm Jack
- (3) TF Card Slot
- (4) USB Port
- (5) Microphone Reverb Adjustment
- (6) Microphone Volume
- (7) TYPE-C Charging Port
- (8) Power Switch/Main Volume
- (9) MIC.PRI Function
- (10) Mode: BT/AUX/FM
- (11) Sound Recording, (This feature requires inserting a USB drive)
- (12) Previous Track
- (13) Pause/Play
- (14) Next Track
- (15) LED Mode
- (16) Number Key 1-9 and Long press for Funny Sound Effects

MIC.PRI Function

Short press this button once to eliminate the original song with only accompanying music, and press it again to automatically restore normal music playback mode



- (1) Scorn
- (2) Awkwardness
- (3) Mwah
- (4) Gunshot
- (5) Laughter
- (6) Applause
- (7) Blow a kiss
- (8) Cheer
- (9) Female Pop
- (0) Super-duper
- (11) On/Off
- (12) Mode
- (13) STOP
- (14) MUTE
- (15) REPEAT
- (16) EQ: Pitch Change,
Rock Mode, Pop Mode
- (17) Main Volume +
- (18) Main Volume -
- (19) Previous / Fast Retreat
- (20) Next Song / Fast Forward
- (21) Pause / Play

NOTE: The (repeat) and (0-9 buttons) functions need to be used in USB mode

Low Power Indicator

When the battery is less than 10%, the machine will have a "Low Battery" voice prompt, when the amount is less than 5%, it will automatically shut down;

Note: If the battery is undervoltage, please charge the battery within 48 hours. If the battery is not working for a long time, it is necessary to keep the power, otherwise it may cause battery damage.

Charging Function

- A: Insert the USB end of the adapter charging cable into the 5V adapter, and insert the DC headend into the DC motherboard. When charging, the indicator light on the function panel shows that it is charging;
- B: After the battery is full, the indicator light is turned off and the charging is completed.
- C: Charging input: DC5V==2A

TWS Function

- A: Two machines, when long pressing the ">00" key simultaneously, interconnect automatically, allowing you to enjoy the surround stereo sound.
- B: Press and hold the ">00" button again to disconnect TWS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.