

90 mm

User Manual Z5 Soundbar

Introduction

1. Precautions

Care and Maintenance

Always keep the device clean. Do not expose the battery to high temperatures or fire.

Charging

Use the recommended 5V charger. Do not charge with incorrect adapters to avoid damage to the battery. Product Modifications: Only use authorized accessories and chargers. Any unauthorized modification may void the warranty.

2. Safety Tips

General Safety: Ensure that the device is used in compliance with the relevant safety standards.

Handling: Avoid dropping the device. Keep it away from strong magnetic fields and sources of heat.

3. Package Content

The device packaging includes the following items:

- Z5 Soundbar *1
- USB Charging Cable *1
- User Manual *1
- Warranty Card *1

4. Charging Instructions

Before using for the first time, fully charge the battery using the included 5V charger.

Charging Requirements: Only use the 5V adapter provided or specified in the manual.

Battery Care: Avoid overcharging or deep discharging the battery for extended longevity.

5. Bluetooth Device Connection

Bluetooth Connection

Press the power button to turn on the speaker. Turn on your Bluetooth device (phone/tablet) and search for "FASTER Z5". Select the speaker from the device list to pair. Bluetooth Call Functionality

Answer Calls: Short press the button to answer an incoming call.
Reject Calls: Long press the button to reject the call.
Redial Last Call: Double-click to redial the last number.

6. External TF Card and USB Audio Playback

TF Card

Insert a TF card (up to 32GB) with MP3 files into the speaker to play music directly.

USB Audio Playback

Connect a USB drive formatted in FAT32 to the speaker. It will automatically detect and play MP3 files.

7. AUX Input Mode

AUX Mode: Connect an AUX cable to switch to the AUX mode for external audio input.

8. FM Mode

FM Radio: Short press the "M" button to switch to FM mode. Press play/pause to start auto-scanning for radio stations.
Station Switching: Use the previous/next buttons to switch stations.

Antenna: Use the USB charging cable as the antenna for better radio reception.

9. TWS (True Wireless Stereo) Function

Pairing Two Speakers: If you have two FASTER Z5 speakers, you can pair them in TWS mode for stereo sound. Turn on both devices and they will automatically connect.

10. Product Specifications

Bluetooth Version: 5.3

Charging Voltage/Current: 5V/1A

Maximum Power Output: 5W * 2

Battery Capacity: 3.7V 4400mAh

Transmission Distance: Approximately 10 meters (varies based on environmental factors)

Scan me



Buy Online

www.hellofaster.com

60 mm

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.