

90*120mm Fold



SW165 TANDUM MAGNETIC WIRELESS SPEAKERS



Instruction Manual

Notice:

Please read the user manual carefully and keep it for your records. [Safety instructions]

- Do not disassemble, dispose of, or damage this product. Consult your local waste collection agency for proper disposal or recycling methods.
- This product is not a toy. Be extremely careful when children use them.
- Keep the products away from direct sunlight, fire and high voltage equipment. Do not store the products in a car in hot weather.
- The unit may become warm during charging.
- Make sure to turn off the product completely when plugging it in and unplugging it from the outlet.

Specifications:

- Wireless version: V5.3
- Wireless range: Up to 10M
- Speaker power: 5W×2
- Battery Capacity: 2000mAh × 2
- Charging input: DC 5V 500mA
- Charging time: 4-5 Hours
- Playing time: 6-10 Hours
- Function: Wireless/ TF card/ FM/ TWS

Contents:

- 2 x Wireless Speaker
- 1 x 30cm Type C Charging Cable
- 1 x User Guide

SPEAKER OPERATION

Keys Instruction

- ⏻ Long press to power ON/ OFF the Speaker.
Short press to volume +
Triple press to last song
- 🔊 Short press to volume -
Long press to switch modes among Wireless/ FM/ TF card.
Double short press to switch ON/ OFF TWS function
Triple press to next song

MODE

Wireless Connection

1. Long press the ⏻ button to power on the speaker and it automatically enter the wireless pairing state.
2. While in pairing mode, turn on the Wireless Connection on your device, Scan/Search & select “**AUDIO MATRIX- SW165**”.
3. Once connected with your device, the SPEAKER will have a prompt. And it will reconnect in the future automatically if it is in the range.

TWS Mode

1. You can choose to use one of speakers or make these 2 speakers paired each other by TWS function for stereo sound.
2. Active TWS function- Turn them on and both of them are in Wireless Mode. Double short press the 🔊 button of one of speakers. When you hear a prompt, which means two speakers are connected successfully.
3. They will auto-link when turning on the speaker next time.
4. You can double short press one of speakers 🔊 button to disconnect 2 speakers.

TF Card Mode

1. Insert a TF card into the TF Slot. The SPEAKER will automatically enter to the TF MODE and play the music in the card.
 2. Compatible with up to 32GB SD card.
- * When in TF card mode, TWS function can't be activated. And when 2 speakers in TWS mode, they will disconnected each other automatically if switch to TF card mode.

FM Radio Mode

1. Long press the 🔊 button switch to FM mode.
2. Double short press the ⏻ button to automatically search for channels.
3. Short press the ⏻ button to last channel , short press the 🔊 button to next channel.

Please note1 : that this function needs to plug in a charging cable to enhance the radio signal. And open areas will get more channels .

Please note2: FM volume defaults to 70% volume and cannot be adjusted

CHARGE THE SPEAKER INSTRUCTIONS

- The device has built-in rechargeable battery, and we recommend to fully charge the battery before first use.
- Please connect one end of the charging cable provided to the charging port and the other end to a power source 5V and with a minimum Amp 1A but not greater than 2A.
- When the speaker is charging, the red LED light indicator is always on, and it will be off when it is fully charged.

⚠ WARNING: Cancer and Reproductive Harm
ADVERTENCIA: Cáncer y Daño Reproductivo
AVERTISSEMENT: Cancer et Troubles de
l'appareil reproducteur
www.P65Warnings.ca.gov



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.