


ADJUSTABLE REVOLVING SPRINKLER WITH SPIKE, QUICK CONNECT SET

Center fountain head nozzle creating fountain effect



Rotation angle changes both coverage & speed. Slow speed mode for big coverage; Fast speed for small coverage.






Riser - 5" Extensions

Flow control & shut off

FULL

PARTIAL

OFF



Flow through connection

Hose connection

Spike can be easily placed into the soil

Water your lawn and enjoy a show with the Eden Adjustable Revolving Sprinkler with spike. The 3-arm design twirls and provides a dancing water effect that is fun to watch and provides ideal watering for your lawn or garden. It's easy to set up and easy to adjust. It connects to standard garden hoses and is easily moved to anywhere in the yard!

From watering your lawn or greenhouse to cooling off on hot summer days, this multi-purpose sprinkler covers all your watering needs. The speed of the rotation varies according to the angle of the arm nozzles. From 90° (no rotation) to 45° (full rotation), you can adjust the rotation speed to suit your needs.

Attach the sprinkler to the hose connector and turn on the faucet to start watering a large circular area. It can be connected in series with other units to increase the total coverage area (max. suggested 3).

Quick Connect Adapter fits all standard garden hoses



Features & Benefits

- Easy to use and setup
- Spike can be easily placed into the soil
- Made from premium ABS material for strength
- Circular spray pattern
- 15 spray nozzles provide a dancing fountain watering effect

- Great for summertime amusement
- Watering without wasting water resources
- Easily adjust for smaller or larger watering areas
- 5" Riser to increase the height or remove for lowers plantings

For setup, you can choose Method A or B

Method A

Simply attach the sprinkler to the top of the spike (*Do not overtighten*) and connect to your hose. (Fig 1 & 2)



Connect riser to increase the height according to your watering needs. (Fig 3)



Method B

Connect the adapter to the spike, attach the hose with the quick lock connector, then simply snap in the water hose to the sprinkler.

To extend, simply remove the end-cap and attach another hose and sprinkler.





⚠ CAUTION ⚠

- For outdoor use with cold water only
- Do not spray near electrical connections
- When not in use, rinse the tool with water to remove most of the dirt, dry your tool, and store indoors

This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov

The Quick Connect Adapter (2 pcs) and Hose Connector with Water Stop (1 pc) simplify your watering experience. Simply attach the connector at the end of your hose. Then, connect the adapters to your watering tools. Interchange various tools in a snap without turning off the water as the adapter will stop the water flow. No more kinking or hose twisting as the adapter allows the hose to swivel 360 degrees.



Quick and easy connections to 5/8-inch and 1/2-inch garden hoses, sprinklers, nozzles, and or any other garden watering tools