


BIUBLE
MOVABLE FAN
X88
Clip-on large fan



USER MANUAL

» Product Structure



» Product Parameters

BASIC PARAMETER

PRODUCT MODEL	X88
SPEED CONTROL	STEPLESS SPEED REGULATION
INPUT CURRENT	TYPE-C > 5V/3A; 9V/2A; 12V/1A
OUTPUT POWER	3W-15W
LED POWER	1W-5W
PRODUCT SIZE	210.6mmx200mmx288.5mm
PRODUCT WEIGHT	1350G
PRODUCT ACCESSORIES	TYPE-C CABLE AND MANUAL

» Product Feature

- 1.Brushless motor, Lightweight PC fan blade, super strong winds.
- 2.Environmental ABS material, strong and resist compression,resistant to fall,suitable for movable use.
- 3.The product has powerful functions, stepless speed regulation, free switching, four levels of brightness adjustable, 360 or so automatic shaking head, can be clipped and stood, equipped with timing function.

» Product Size



» How to use

CAN BE CLIPPED



ROTATE UP ,DOWN,LEFT,AND RIGHT



» Method of application

1. Make sure the accessories are complete and product appearance is good after unpacking.
2. Find stepless speed regulation switch, turn right to open the fan and switch the speed. 3. When the fan stop working or charging please turn off the switch.
4. Find the LED lighting switch, Four model lighting brightness can be provided.
5. (type-c) charging wire attached to this product, Charging Operation Indicator (25% 50% 75% 100%) The battery is full when the Charging Operation Indicator stop flashing.

» Warranty certificate

- 1.Please keep the warranty card properly as a certificate for maintenance.
- 2.The warranty period is within one year from the date of purchase.
- 3.During the warranty period, if this product breaks down under normal use and is verified by our company, we will provide maintenance and replacement services free of charge.

The Following Conditions Will Not Be Free Maintenance

Our products are subject to limited warranty within the warranty period. Equipment failure or damage under the following circumstances is not covered by the limited warranty, and the Company will not undertake the warranty obligation free of charge.

1. Equipment or parts have exceeded the valid warranty period.
- 2.Equipment failure or damage caused by the customer's incorrect installation, storage and use according to the instructions
- 3.Equipment failure or damage caused by disassembly by non-authorized agencies or personnel of the Company.
- 4.The breakdown and damage caused by the accidental factors or human operation including Incorrect operation, move scratch and bump, the inappropriate voltage and current etc.
- 5.Product damage caused by force majeure (like earthquake, fire).

» Precautions

- 1.Please recharge when the fan stop or LED lighting not working, please charge once in three months, when the product not use, increases product life time.
- 2.Do not put your finger in to the net when the fan working. Avoid bodily harms(less three years of age, under adult supervision).
- 3.Do not open the front and back cover of the fan and refit this product.
- 4.Do not use this product near fire and wet place.
- 5.Please use the battery charging wire with product.

» Packing list

- fan*1
- type-c cable (1M) *1
- manual*1



Can be clamped



360° Adjust



Safety and Noiseless



Adjusting Wind
Stepless speed
regulation



Multiple circuit
protection



2A Safety quick
charging

CE FC ROHS
Made in China