



### Customer Service

If you need assistance with your headphones, please contact us through the [Amazon Message Center](#). You may also reach our support team at:

**Phone: +1 (781) 381-6022 Mon.-Fri.**    **Email: help@bmani.store**

---

### Packing List

- Headphones\*1
- Type-C Charging Cable\*1
- 3.5mm AUX Audio Cable\*1
- User Manual\*1

---

### Specification

Model No.	H2
Product Name	Active Noise Cancelling Headphones
Speaker Size	40.0mm
Maximum Working Range	10m/33ft
Capacity	3.7V 500mAh, 1.85Wh
Input	5V ⚡ 1A
Charging Time	2 Hours
FCC ID	2ATU8-H2
Support Device	Smart Phone, PC, Laptop, Smart Watch, Tablet, etc

### Product Introduction

- 1 Battery Level Display
- 2 ANC Button
- 3 USB-C Charging Port
- 4 3.5mm Aux Audio Jack
- 5 Microphone
- 6 Play/Pause/On/Off Button
- 7 Volume +/- Next Track
- 8 Volume +/- Previous Track
- 9 Earmuff
- 10 Adjustable Headband

**Notice:** The power button shares the same function as the play/pause button. Long press 2S this button to power the headset on or off, and single click it to control media playback or calls.

### Pre-Use

Please check the following components for integrity before first use:

- Check if the headphones have power: Press and hold the power button on the headphones and see if the digital indicator lights up. If there is no power, please use the provided Type-C charging cable to charge the headphones.
- Check if each headphone headband is adjustable and if the headphone stands are adjustable.
- Check if there are any missing parts of the product.

If you encounter any of the above issues, please contact us immediately, and we will assist you in resolving them.

---

### Maintenance

- Please charge your headphones regularly to ensure you have enough battery for listening to music each time.
- Please clean the ear pads and headband of your headphones regularly. You can use a cotton cloth dipped in alcohol to wipe the ear pads and headband.
- Please use a pointed cotton swab to clean the 3.5mm audio jack and USB-C port regularly to ensure wired listening and headphone charging are not affected.

### How to Wear

Please follow the diagram below to adjust the headphones to a comfortable position.

---

### Power on/off

**Power on**  
Press and hold the Power button for 2s to power on the headset. A "Power On" voice prompt will be heard, and the display will indicate the battery level for 10 seconds before automatically turning off.

**Power off**  
Press "Power on/off" Button for 2s to power off the headphones. You will hear a prompt "power off" from the headphones.

**Notice:**  
1. If the headphones are turned on, not paired with any device, they will automatically power off after more than 5 minutes.

### Bluetooth Pairing

#### 1. First time pairing with your device

- Press the power button "O" to turn on the headphones, then wear the headphones and enable the bluetooth of your device.
- Search and choose "H2" on bluetooth menu, then you will hear a prompt "connect"

#### 2. Next time pairing

For device second-time pairing, just enable bluetooth on your device and turn on the headphones; they will connect automatically.

---

### Connect to a New Device

**Step 1:** On the device that has been connected to the headset, delete the Bluetooth connection with "H2".

**Step 2:** Activate Bluetooth on your new device, search for and choose "H2" on your new device to connect.

### Button Controls

<b>Power on</b> Press and hold for 2s	<b>ANC On</b> Press and hold for 2s
<b>Power off</b> Press and hold for 2s	<b>ANC Off</b> Press and hold for 2s

---

### Phone Call Control

<b>Answer Call</b> Once click	<b>Reject Call</b> Press and hold for 2s
<b>End Call</b> Press and hold for 2s	

---

### Music Control

<b>Volume +</b> Once click	<b>Volume -</b> Once click
<b>Next Track</b> Double click	<b>Previous Track</b> Double click
<b>Play/Pause</b> Once click	<b>Enable Voice assistance</b> Three clicks

H2说明书  
尺寸: 142\*168mm  
材质: 书纸  
装订方式: 骑马订

### ANC Mode

After turning on the headset, press and hold the ANC button for 2 seconds to enter ANC mode. The headset will not shut down when it is not connected to Bluetooth.

---

### Reset

**Method for Reset**  
Press and hold the volume +/- buttons at the same time. When you hear the prompt tone "power off", the reset is successful.

**When Headphones Should be Reset**

- You can not find the device where the headphones connected to.
- Headphones disconnect with your device frequently.
- Headphones have no sound even connected with device and the volume of device and headphones has been adjust to Maximum.

### Wired Listening Mode

**When headphones is powered off**  
Just insert the 3.5mm AUX audio cable we provided from your phone a other player which has 3.5mm audio jack.

**When headphones is powered on**  
When headphones is power on or headphones is connected with your device via bluetooth. Once insert the 3.5mm AUX audio cable we provided, the headphones will turn off automatically. Then headphones will change to wired listening mode, it is powered by the device that play music or video now.

**Notice:** ANC mode can not be enabled when headphones in wired listening mode.

### Charging

Please plug the provided USB-C charging cable (included) into the headphones and connect it to a charger (not included) to charge the headphones.

**Battery Warning**  
Using the wrong battery can cause fire and other hazards (for example, in the case of some lithium battery types)  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.  
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Do not leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

---

### FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.  
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

---

### ISED Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:  
(1) This device may not cause interference, and  
(2) This device must accept any interference, including interference that may cause undesired operation of the device.  
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:  
(1) L'appareil ne doit pas produire de brouillage, et  
(2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance.  
Le présent appareil est conforme  
Après examen de ce matériel aux conformités ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité et compliance d'acquérir les informations correspondantes.

---

### Caution

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

The symbol indicates DC voltage

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.  
This product can be used across EU member states.  
The device is low power device, it can meet the requirement of the RF exposure.

Hearing Safety:

- High Sound Pressure
- Hearing Damage Risk
- Do not listen at high volume levels for long periods.

### Troubleshooting

**Q: Headphones cut in/out when it connects with my phone via bluetooth**

**A: We kindly ask you to try the following troubleshooting steps, as they have often proven helpful:**

- Reduce the distance between your headphones and your audio device.
- Reset the headphones: Follow these steps to reset your headphones:  
**Step 1:** Delete the pairing history from your Bluetooth device.  
**Step 2:** Press the button on the "power on/off" for 5 seconds.
- Reset your Bluetooth connection: Turn off Bluetooth on your device (phone/tablet/etc.) for at least 10 seconds and then turn it back on. Please note, quickly turning Bluetooth off and on will not reset the connection.
- Close unused apps: Try closing any other apps you are not using on your device.
- Test the headphones: Listen to downloaded music or videos to test the headphones.
- Try another device: Please try using the headphones with another device (phone/tablet/etc.) to see if the issue persists.

**Q: What should I do if the ANC function doesn't work even though I have pressed "ANC" button for 2s?**

**A:** ① Please make sure that the headphones are not plugged into any AUX cable, because once the headphones are plugged into the audio cable to listen to a song through a device, the ANC noise cancellation function will be automatically disabled.  
② If you are sure that the headset is not plugged into any AUX audio cable, please reset your headset and press the ANC button again for 2s to enable the ANC function.  
③ If above methods do not work, please contact us for help.

**Q: Headphones can not connect to my phone.**

**A: First, please make sure your headphones is power on, then follow steps below.**

- Disable and re-enable the Bluetooth function.
- Remove the headphones pairing name from the Bluetooth list on your device.
- Clear the pairing list on your device. Connect again.

If above method do not work, please reset your headphones and reconnect with your device.

CE RECYCLING  
Made in China

