
95*210mm




SCENT DIFFUSER INTRODUCTION

Our scent diffuser utilizes the latest cold-air diffusion technology which turns any of our hotel-inspired fragrance oil into a dry nano mist, allowing the scent to stay idle in the air for much longer while providing superior, long-lasting coverage. It uses no water or heat and preserves the therapeutic properties of our fragrance oils without altering their smell.

Uses advanced atomization technology which makes it residue free and safe for pets, children, artwork, and furniture.

This model comes with an easy to use remote control.




TECHNICAL FEATURES


Model.: BD918 | Power: 10W | Voltage: 5V 2A | Noise: <38 db

Coverage: 1,000 sq.ft | Oil bottle capacity: 120ml

- The package includes the diffuser, with 120mL oil bottle * 1, remote control * 1, cleaner * 1, replaceable atomizing core * 2, USB-C cable + Adapter * 1, seal rubber ring * 1, metal hook * 1 and user manual * 1.
- The remote controller is designed for convenient adjustment of fragrance concentration levels to suit your preferences, as well as setting the desired operating duration for the device.
- Please follow the instructions set out in this manual and use the device correctly.



USING GUIDE




Step 1: Remove Empty Bottle

- Take the upper part of the diffuser directly.
- Rotate the bottle counter-clockwise to remove it.



Step 2: Add the Fragrance oil

- Fill the bottle with your favourite fragrance oil.



Step 3: Install the bottle and upper part

- Put the upper part directly in the diffuser.



Step 4: Power On the Diffuser

- Connect the device with the USB-C and adapter.
- Use the remote controller to turn on the device, or press the power button to turn on.

Please note: in the default settings for the diffuser, it will emit scent for 30 seconds and then pause for 180 seconds. This cycle will continue for 8 hours, after which the device will turn off automatically.

LIGHT INDICATOR / DEVICE FUNCTION

The power button on the front of the device serves a dual purpose:

Turning the device on and off, and once powered on, controlling the mist intensity and timer settings.



Power On/Off:

Long press the button to turn the diffuser on or off.
When powered on, the device defaults to L2 mode, with a misting cycle of 30s misting and 120s pause,and a timer setting of 4 hours.

Mist Intensity Switching:

While the device is on, press the button once to adjust the mist mode.


Mode	Mist	Pause	The display screen indicator light will turn on accordingly.
LOW	30s	60s	LOW
MED	30s	120s	MED
HI	30s	180s	HI

Timer Switching:

While the device is on, press the button twice quickly in a row.

Atomatically turns off after	The display screen indicator light will turn on accordingly.
1 Hour	1H
4 Hours	4H
8 Hours	8H

REMOTE CONTROLLER



HOW TO USE REMOTE CONTROLLER

- ON/OFF: Press the button to turn on/off the device.
- Switch the light color: blue-red-green-purple-cyan-yellow-white-off light.
- LOW: The diffuser will mist scent 30s, pause 180s.
- MED: The diffuser will mist scent 30s, pause 120s.
- HIGH: The diffuser will mist scent 30s, pause 60s.
- 1H: 1 hour timer setting. The screen on the front of device will display 1H. The device will turned off automatically after 1 hour.
- 4H: 4 hours timer setting. The screen on the front of device will display 4H. The device will turned off automatically after 4 hours.
- 8H: 8 hours timer setting. The screen on the front of device will display 8H. The device will turned off automatically after 8 hours.

SAFETY

1. The diffuser should be used in an upright position always.
2. Do not tilt the diffuser as oil can spill inside and damage the device.
3. Do not use the device with any other power cords. Please use the original power cord that comes with diffuser. Position the power cord to prevent tripping hazard.

Q & A

Questions	Answers
Does your diffuser work with any brands of fragrance oils? And do you sell oils for my NoxLumina waterless diffuser?	Yes, it works with other high-quality fragrance oils. However, lower quality ingredients oils may affect performance. Our oils use premium ingredients and are tested for optimal diffusion. Shop our oils in the "Diffuser Oils" section of our Store.
Why does the diffuser pause or stop automatically?	The diffuser releases fragrance in intervals based on the selected mist level (Default: L2), so brief pauses are normal. It will also automatically power off when the selected 1/2/4/8 Hours Timer ends to avoid oil waste. (Default: 4H)
Why is there no mist or fragrance coming out after I turn on the machine?	1. Ensure the top curved ridges are properly aligned. 2. Some oil ingredients produce no visible mist, but a fragrance can still be smelled, which is normal. 3. If there is neither mist nor smell, please try to replace a new included atomizing core
Why did my diffuser stop working after about one month?	After a period of use, essential oil residue may clog the atomizing core. We recommend to follow the steps to use included “CLEANER” accessory to clear the blockage. If still doesn't work, simply replace a new included atomizing core to resolve.
Why does the mist output decreases significantly after a period of use? And how often should I clean the diffuser?	We recommend to clean the diffuser once per month, as over time, fragrance oil residue may cause clogging. Cleaning is also recommended between changing fragrances to avoid altering fragrance composition. Cleaning Methods refer Manual "MAINTENANCE".

TROUBLESHOOT METHODS

How to use the cleaner?


When the diffuser does not spray or becomes clogged, use the included cleaner to clear the blockage; if still doesn't work, follow the steps in next image to replace a new included atomizer core

Step 1: 	• Gently pull the core out through the small hole with your hand.
Step 2: 	• Insert the cleaner into one side of the atomizer, quickingpull and push the cleaner to clear the blockage.
Step 3: 	• Then insert the cleaner into another side of the atomizer, quicking pull and push the cleaner to clear the blockage.
▲Kindly Remind: The cleaner is for diffuser cleaning only.Non-medical use. Not for human use. Non-sterile.	

Still no mist or scent after cleaning? Replace the atomizing core as shown below.

Minimize Maintenance & Extend Product Life


Atomizing Core Replacement



Prepare a new atomizing core (Included in the package).

Use the hook to gently pull the core out through the small hole.

Replace with the new atomizing core.



Seal Replacement

If the seal ring becomes corroded or is used improperly, you can replace it with the new seal ring we provide.

WARRANTY

Your device comes with limited warranty. Please ensure that you have proof of purchase in case a claim arises. Please note that the warranty is non-transferable.

The following will not be covered under warranty:

- Damage caused by accidents or fire.
- Failure to use device properly.
- If the device is repaired by a non-authorized dealer.
- Third party parts used in the machine.

MAINTAINANCE

The scent diffuser should be cleaned every 1-2 months to ensure optimal performance. To clean the inner workings of the device, please follow these steps:

1. Take the upper part of diffuser, and fill rubbing alcohol to the bottle.
2. Install the upper part with bottle to diffuser.
3. Turn on the diffuser and keep working 15 minutes, to ensure alcohol go through the whole device.
4. Remove the electric cord from the diffuser and keep the diffuser in an upright position. Wipe the device with a damp cloth to remove oil stains and fin-gerprints. Don't use any harsh or abrasive to clean the device.

Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction