



English  Wireless Earbuds user manual	 Touch area Touch area [1]	Product parameters ◎Wireless version: V6.0 ◎Working range: barrier-free 10 meters ◎Wireless frequency: 2.402-2.480GHz ◎Charging case capacity: 3.7V,300mAh ◎Charging voltage: DC5V-200mA ◎Charging time: 2 hours ◎Music time: :5 hours (80% volume) ◎Talk time: 4 hours (80% volume) ◎Earphone battery: 3.7V, 50mAh ◎Times of Case charging Earbuds:1.5 times Note: The specifications and parameters of this product are all laboratory test data, which will be different in different environments; the product is constantly being upgraded and improved, and the specific functions and product pictures may be slightly different from the actual product, please refer to the actual product. [2]	Touch method • Power on: After removing the earphones from the charging case, the earphones automatically turn on • Power of: Put the earphones into the charging case • Play/Pause: Double click on the left or right earphone • Previous song: Three clicks on the right earphone • Next song: Three clicks on the left earphone • Volume + : Click the right earphone • Volume - : Click the left earphone • Voice assistant: Long press the left or right earphone for 2 seconds • Answering/hanging up calls: Double click on the left or right earphone • Refuse call: Long press the left or right earphone for 2 seconds [3]	Charging case LED indicator status • When charging: Orange light flashing • When fully charged: Orange light always on • When the battery is low: the white light flashes • When charging headphones: The white light stays on for a long time and turns off after being fully charged Universal wireless connection operation 1. Please place the wireless earphones and mobile phone (or other connected device) together; 2. Ensure that the earphones are charged, remove them from the charging case, make sure the left and right earphones are connected, and the earphones will enter pairing mode; 3. Turn on the Bluetooth function of the user's mobile phone (or other wireless devices) and search or scan. At this time, the phone will search for all nearby wireless devices. Click on the corresponding wireless model name to connect, and after successful pairing and connection, you can make headphone calls, listen to music, etc. [4]	Considerations when connecting wirelessly 1. Please keep the distance between the wireless earphones and the mobile phone (or other connected devices) within 1 meter, the closer the better; 2. Remove the earphones from the charging case and connect them; 3. The charging case needs to have sufficient power. If the earphones cannot be turned on, please put them into the charging case, close the case, and plug in the charger to charge for at least one hour; Precautions 1. Never use corrosive cleaning agents to clean this product; 2. Do not allow this product to heat or come close to fire sources, such as cooking stoves; 3. Do not expose this product to direct sunlight for a long time to avoid high temperature; 4. Do not dispose of this product in fire to avoid explosion; 5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components; 6. Do not use this product in the rain; 7. If you do not plan to use this product for a long period of time, please store it in a dry environment. And charge the headset at least once a month to extend the life and avoid extreme temperatures and dust. [5]	FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. *RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
--	---	---	--	--	--	---