Purchase Date:___/___/___ Order/Customer Reference Number:_____

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit https://tiny.cc/SunnydazeWarranty

If you have any questions, comments or concerns, feel free to contact us by phone at **833-982-1977**, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

LOG CLAW

Review all information before using this product.
Save this manual for future reference.

Save the packing slip.

SAFETY: Always wear appropriate safety gear, such as gloves, when using a log grabber. Be mindful of the weight of the log and the limitations of the grabber's capacity.

PREPARATION: Ensure the log grabber is in good working condition and that the mechanism is free from obstructions.

GRIPPING: Carefully maneuver the grabber's claw to securely engage the center of the log.

LIFTING: Apply lifting force, ensuring the grabber holds a firm grip on the log.

MOVING: Once the log is lifted, navigate it to the desired location.

RELEASING: To release the log, reverse the gripping action, allowing the grabber to disengage.

EXPOSURE & MAINTENANCE: Long-term exposure to high-intensity heat can cause the high-temperature paint to flake or burn off the steel. If the steel is exposed to moisture, it will rust. As with any outdoor steel product, periodic maintenance is required to maintain integrity and appearance. Remove rust and refinish with a suitable high-temperature paint; carefully follow the paint manufacturer instructions and ensure the paint is completely dry before using the unit again.

CLEANING: Wipe with a damp cloth.

STORAGE: Ensure the unit is completely cool before storing. Store in a dry location to protect it from environmental elements. The manufacturer is not liable for damage resulting from general use and/or environmental conditions.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues or the product was damaged during transit,
please contact our customer service team through one of the methods mentioned at the top of page 1.
Please have the item number and order information ready to expedite response time.

⚠ WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.