

<b>设计版本号</b>	<b>产品名称   Product name</b>	<b>比例   scale</b>	<b>日期   Date</b>	<b>设计师   Designer</b>	<b>审核   Audit</b>
<b>Rev_V0_EN</b>	DR-HHM019S_美规快速指南	1:1	20260227	Lily	Alyssa
<b>Hesung</b> innovation 和生创新	<b>材质印刷与 技术要求</b> 材质要求: 157g铜版纸 双面覆哑膜 印刷要求: 双面彩色印刷 上下风琴折页	<b>字体   Fonts</b>	Manrope	<b>尺寸   Size</b>	单页尺寸: 160*130 mm

图纸设计禁止修改, 尺寸刀模图为准



**IMPORTANT SAFETY INSTRUCTIONS**

**READ ALL CAUTIONARY MARKINGS ON THE APPLIANCE AND SAFETY INSTRUCTIONS IN THE USER MANUAL BEFORE USE.**

**DO NOT** block or cover the nozzle while in operation.

**DO NOT** touch or hold the plug or power cord with wet hands.

**DO NOT** let children or pets play with this appliance.

**General Safety**

- Children should be supervised to ensure that they do not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury.
- This is not a toy. This is an electrical appliance and must be operated and maintained by an adult. In addition to the water to be dispensed, any additional liquids advised by the manufacturer for cleaning or fragrance shall be used.


**Operation Safety**

- Always place this appliance on a firm, flat and level surface to avoid dropping or tilting.
- DO NOT move this appliance while it is on.
- DO NOT attempt to repair any parts on this appliance. The inside of this appliance contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- DO NOT leave water in the reservoir when the appliance is not in use.
- DO NOT permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the humidifier down. If the humidifier output volume cannot be turned down, use the humidifier intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
- DO NOT immerse in water or any other liquids.
- DO NOT use the appliance until the base is installed.
- DO NOT use sharp objects, such as fingernails, pencils and any other objects into the grilles or openings while in operation.

**WARNING:** Microorganisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.

- Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
- Unplug the appliance during cleaning. Empty and clean the humidifier before storage. Clean the humidifier before next use.
- Empty the tank and refill every third day. Before refilling, clean it with fresh tap water or cleaning agents. Remove any scale, deposits, or film that has formed on the sides of the tank or on exterior surfaces, and wipe all surfaces dry.

折页压痕线



**Before Use**

When using your appliance for the first time, remove the wraps and follow the steps below.

- Remove the label and cap. Make sure the water doesn't pass the MSA line. Make DROPTOP stop water into the mist tube.
- Detach the cover and water tank from the humidifier and clean thoroughly.
- Fill the tank with water. Make sure the water doesn't pass the MSA line. Make DROPTOP stop water into the mist tube.
- Put the water tank back in place and close the top cover.

**LED Display**

Cartridge Change: AUTO SLEEP (Low Water)

Timer: 88 h Hour

Schedule: Humidity %

**Control Panel**

- Power on/off
- Long press for 5 seconds to restore WiFi and factory settings.
- Switch between Low/Medium/High mist level.
- Turn Auto Mode on.
- Long press for 5 seconds to enter WiFi settings.
- Tap to increase the target humidity by 5% (20-50% range).
- Press to exit.
- Turn on/off ambient display and beep sounds.
- Touch any button to wake up the display (auto-off in 5s).
- Long press to change light colors (orange-green-blue-rose red-purple).
- Long press and to adjust brightness.

**Troubleshooting**

- The appliance will shut down in the event of low water.
- Auto Mode: the appliance will stop adding mist when it reaches the room humidity target.
- If there is no mist produced, check the water level and clean the mist tube.
- If the appliance is not working, check if there is a plug attached to the back of the appliance. If necessary, scan the QR code on the first page for detailed cleaning and installation instructions.

**Connecting to the DREO App**

Scan the QR code to download the DREO app.

Search "DREO" on Google Play or the App Store.

Look for "Smart Humidifier 119S" when connecting your new appliance.

Tip: Add Device and select Smart Humidifier 119S. Tip: Enable Bluetooth on your mobile device and plug in the appliance.

You're now ready to control the appliance on your app. Tip: To restart connection settings, hold again for 5 seconds.

\*To learn more, read the full user manual on [www.dreo.com](http://www.dreo.com)

**Is Your New Appliance Leaking?**

**REMOVE**

Make sure to remove the label and the cardboard.

Fix the left prong on the bracket. Then slide the other prong to secure the float in place.

Remove any particles or hair blocking the water valve.

Make sure the appliance is placed on a flat surface.

**Contact Customer Service If...**

The water valve is not flat or the tank leaks water when refilling.

Your water tank has leakage due to prolonged use of essential oils or liquid medication.

**FOR HOUSEHOLD USE ONLY**

**READ AND SAVE THESE INSTRUCTIONS**

**DREO CUSTOMER CARE**

**12-MONTH LIMITED WARRANTY**

DREO warrants to you that your product will be free from any defects in materials and workmanship for a period of twelve (12) months from the date of your purchase, when used in accordance with the instructions provided in this user manual.

Please retain your proof of purchase. If you do not retain your proof of purchase, your warranty will start two (2) months from the date of manufacture printed on your product label.

**What is Not Covered**

This warranty only applies to the original purchaser of your product and is non-transferable. This warranty is void if your product is used in the country in which you purchased it or if your product is used in a country where DREO does not have a service center.

Damage or destruction caused by wiring or unsafe electrical current.

Damage to the product or its components due to:

- Abuse or misuse.
- Compliance with handling, storage, loading, unloading, and use instructions in accordance with the User Manual.
- Use of unauthorized accessories, parts, or components (e.g., essential oils).
- Products with already existing defects.
- Changes or modifications to the product.
- Use of the product in an environment not intended for use.
- Defects caused by or resulting from damage from shipping or handling are the responsibility of the carrier. DREO will ship your product or your accessories or handling from the service center nearest to your product or any of its components and/or the nearest repair person authorized by DREO.

Our service and customer support team (DREO) provides to you under the limited warranty will not extend the duration of this limited warranty.

**Warranty Limitations and Exclusions**

ANY EXPRESS WARRANTY IS LIMITED TO THE APPLIANCE ONLY AND DOES NOT INCLUDE ACCESSORIES. THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, USE, OR SERVICE IS LIMITED TO THE APPLIANCE ONLY AND DOES NOT INCLUDE ACCESSORIES. THE LIMITED WARRANTY DOES NOT COVER THE APPLIANCE IF THE USER HAS NOT USED THE APPLIANCE IN ACCORDANCE WITH THE USER MANUAL. THE LIMITED WARRANTY DOES NOT COVER THE APPLIANCE IF THE USER HAS NOT USED THE APPLIANCE IN ACCORDANCE WITH THE USER MANUAL. THE LIMITED WARRANTY DOES NOT COVER THE APPLIANCE IF THE USER HAS NOT USED THE APPLIANCE IN ACCORDANCE WITH THE USER MANUAL. THE LIMITED WARRANTY DOES NOT COVER THE APPLIANCE IF THE USER HAS NOT USED THE APPLIANCE IN ACCORDANCE WITH THE USER MANUAL.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and other rights may vary from jurisdiction to jurisdiction.

**Limited Remedies**

In the event of a defect in material or workmanship during the warranty period, DREO will repair or replace (at DREO's sole discretion) your product. For any other reason, please contact your local service center at (888) 290-1688 (available from Monday, Friday, 9:00 AM - 5:00 PM PST) for further instructions.

**We're Here to Help!**

- (888) 290-1688 Mon-Fri 9:00am-5:00pm PST (PST)
- support@dreo.com
- www.dreo.com
- DREO Inc., LTD.
- 112 ROBINSON ROAD, #03-01, ROBINSON 112, SINGAPORE 068992

Intertek

**图层使用规范:**

- 备注信息图层为非印刷区域, 展示印刷物料基础信息。
- 刀板线、备注工艺、尺寸层展示印刷工艺部分。
- 画面信息层展示印刷展示图片与文字。

\*电子文档为Adobe Illustrator制作

M 式: model规格类目日期.AI (为可编辑原始文档)  
式: model规格类目日期.pdf (为文件转曲不可编辑文档)

<p>审稿 检查事项 会以“√”形式确认 (负责部门/范畴确认)</p>
<p>审稿检查事项</p>
<p>商标规范</p>
<p>字符高度</p>
<p>工艺材质</p>
<p>颜色标识</p>
<p>产品文案</p>
<p>条码检查</p>
<p>厂址</p>
<p>全成分</p>
<p>警告标语</p>
<p>执行标准</p>
<p>产品尺寸</p>
<p>外/内箱尺寸</p>
<p>OEM信息*</p>
<p>产品包装信息</p>
<p>请相关部门确认产品、包装等信息!</p>
<p>*OEM信息: 委托方及被委托方 信息(名称、地址、 邮编、电话、生产 许可证、卫生许可 证)</p>

设计师	审核	产品负责人	法规	采购
-----	----	-------	----	----