

DK01



1. When using it for the first time, please install button batteries on the product.
2. The button function of this product.

Status	Key	Function	Buzzer
Sleep	Press for 2 seconds	Wake up	A confirmation beep will sound
Power off	Press for 2 seconds	Power on	A confirmation beep will sound
Power on	Press for 4 seconds	Read SN	One beep will sound, and then two beeps
	Press for 6 seconds		Power off
Advanced settings	Press and hold the button to hear	Restore initial settings	One confirmation beep, two consecutive confirmation beeps, and three consecutive confirmation beeps. Continue holding the button until you hear a long beep, then release it

[Learn More](#)

1. Locate the button on the DK01.
 2. Press and hold the button for four seconds. One beep will sound, and then two beeps.
- How to Disable
1. Locate the button on the DK01.
 2. Press and hold the button for six seconds. One beep will sound, then two beeps, and then three beeps.

※Rotate the back cover counterclockwise, open the battery cover, take out the CR2032 button battery that comes with the package, install the CR2032 button battery, then slide the battery cover clockwise to fully close.

※ Please make sure that you have an iPhone, iPad, or iPod touch with iOS 14.5 or iPad OS 14.5 or later and two-factor authentication enabled.

1. Turn on **[Bluetooth]** on your Apple device, and go to **[Settings]** → **[Privacy & Security]** → Turn on **[Location Services]** and swipe down and tap **[Find My]** to allow access to the location and turn on **[Precise Location]**.
2. Go back to main screen of the apple device, click the **[Find My]** app, and the select the **[Items]** tab.
3. Click **[+]**, and then click **[Add Other Items]**.
4. Find the item name "DK01", click **[Connect]**, fill in the "Name" item "customer product name, and click **[Continue]**. Choose an emoji, "👉" click to continue to show "This item is linked to your Apple ID", please check that the email address and mobile phone number are correct, then tap **[Agree]** and then tap **[Finish]** to add successfully.

1. When the base station is a certain distance away from the console, you need to turn on the lost mode to mark the item as lost. Tap item at the bottom of the screen, then tap the name of the missing item. Under Lost Mode, tap Enable.
2. Follow the on-screen instructions and enter a phone number where you can be contacted, or if you want to enter an email address instead, tap Use email address. Then press Enable.

Note: Please make sure to allow notifications from the Find My app first.

1. Open the Find My app, then click the Items tab. Select the location you want to locate in the Items list. If the locator is within the coverage area of your device or the Find My network where the locator was recently detected, you can see it on the map. Below its name, you'll see the location and time of the update.
2. If the base station is not within range of your device or any device on the Find My network, you can see its last known location and time. If you want to receive notifications when the tracker comes within range of your device or can be detected by the Find My network, please turn on [Notify when found] under [Notifications].

Open the **[Find My]** app, select the **[Item]** tab, click the product you need to use, the mobile phone interface will display the **[Play Sound]** button, click the **[Play Sound]** button, and then you will hear a piece of music, indicating that the product can be used normally.

※When the device and the product are out of the distance, the **【Find My】** app cannot connect to the product and the product cannot play sound normally.

1. If any of the locators and other Find My network accessory products leave their owners and move with you for a period of time, you can send a notification to your Apple through the Find My app device, and be able to observe the walking path as you move and in time.
2. These features are designed to prevent people from trying to track you without your knowledge, so if you feel your safety is at risk, contact your local law enforcement officer.

※ This product as a function to prevent unauthorized tracking, and should not be used to track others, nor should it be used to track property that does not belong to you. In many countries and regions around the world, it is an offense to use these products to track someone without their consent.

1. Rotate the back cover counterclockwise, open the battery cover.
2. Remove the battery, replace it with the prepared new battery "CR2032 3v" and install the battery.
3. After installing the battery, you can hear the product make a "drop" sound, indicating that the battery has been successfully replaced. Then slide the battery cover clockwise to fully close it.

2. When you need to replace/unbind the product bound to your Apple device, in the **[Find My] app, in the Item** tab, find the product that needs to be unbound, slide to the bottom of the page, click **[Remove Item]**, click **[Remove]** and click **[Remove]** again to confirm that the product is no longer available in the **[Item]** tab.

2. Press and hold the button to hear, in sequence: one confirmation beep, two consecutive confirmation beeps, and three consecutive confirmation beeps. Continue holding the button until you hear a long beep, then release it. The device will now be restored to factory settings.
3. If you are unable to use the base station, make sure the product is ready to be set up, remove and replace the battery, place the base station close to the portable device you want to connect to, or reset the product before attempting to connect to the base station.
- ※ If you physically reset the product before unbinding, it will take longer for the Apple device to remove the product.

MODEL: DK01
Battery: CR2032
Bluetooth version: BLE 5.3
Material: PC+ABS
Size: 32x32x9.5mm
Weigh: 8g±2g
Manufacturer: Shenzhen Mutual Technology Co., Ltd
Address: Room B, 6th Floor, Building 3, Tingwei Industrial Park,
Xin'an Street, Bao'an District, Shenzhen

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPod, macOS, Mac, and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find My app on Apple Watch requires the latest version of watchOS.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Plug the device into a power outlet that is different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements for the device category. The device is designed to be used in portable exposure condition without restriction.

正面

Front



反面

[Back](#)