

zip
vac



USER GUIDE

Table of Contents

1. Introduction
2. What's in the Box
- 2.1 Get Familiar with Your ZipVac
3. Setup
- 3.1 Using the Vacuum
- 3.2 Cleaning the Vacuum
- 3.3 General Tips
4. Precautions
5. Specifications



Thank you for choosing one of our exciting and innovative products. We strive to bring you the latest technology, providing lifelong value and keeping you ahead.

Vacuuming shouldn't feel like a workout—especially when only dealing with small cleaning tasks. This super-lightweight, portable vacuum switches from a traditional vacuum cleaner to a handheld vacuum cleaner in seconds. A simple, convenient solution to your basic vacuum cleaner needs is right here.

- **Makes cleaning a breeze with a super-lightweight design weighing under 5lbs.**
- **Quickly switches from traditional vacuum cleaner to handheld vacuum cleaner.**
- **Included crevice tool lets you vacuum those hard-to-reach places.**

**Get ready to clean in
FLOOR WHEEL DRIVE!**



2 What's in the Box

Your new ZipVac is easy and quick to assemble.
Let's start with all the parts you will be taking out of the box:

Handheld Vacuum Base

Extender Handle

Slim Nozzle Attachment

Floor Roller Brush

User Guide



2.1 Get Familiar with Your ZipVac

Power Cord
20ft long



Handheld Vacuum Base
Compact with easy ON/OFF controls

Extender Handle
Attach for upright vacuuming

HEPA Filter
Removeable and easy to clean

Slim Nozzle Attachment
Reaches tight corners and hard-to-reach areas

Large Dustbin
Convenient and quick snap on/off design

Floor Roller Brush
Low profile and effective multi-surface cleaning



3

Setup

1. Insert the handle into the top of the vacuum and secure with the release clip.
2. Attach the floor nozzle or the crevice tool to the bottom of the vacuum.

3.1 Using the Vacuum

1. There are two ways to clean with the vacuum—standard mode using the floor nozzle or handheld mode using the crevice tool.
 - To switch to handheld mode, detach the handle from the vacuum unit by undoing the release clip and pulling it out. Press the release clip down into the vacuum unit to hide it.
 - Remove the floor nozzle from the dustbin's suction component and attach the crevice tool instead.
2. Use the power cord to plug the vacuum into the nearest wall outlet.
3. The power switch is located on the handheld vacuum base. "I" powers ON the vacuum, "O" turns the vacuum OFF.
4. Start cleaning!

3.2 Cleaning the Vacuum

Dustbin

1. Use the release clip on the bottom of the dustbin to empty dust.
 - Remove any attachments from the dustbin for an easier clean.

HEPA Filter

1. Use the release clip on the handheld vacuum base to open the dustbin and remove the HEPA filter.

Continued...

2. Wash the HEPA filter under running water and let air dry.
 - If you are replacing the HEPA filter, there is no need to wash it! Throw the old one out and insert a new one instead.
3. Make sure the HEPA filter is completely dry before re-inserting.

3.3 General Tips

- The floor nozzle and wheels can sometimes become jammed, in which case it will need to be cleaned to maintain maximum effectiveness. To do this, be sure that the vacuum is powered off and carefully remove anything that has become entangled in the floor nozzle or wheels.
- The HEPA filter is suggested to be changed every 3 months.
- The crevice tool is best used for corners, edges, radiators, drawers, etc.

4.

Precautions

1. Always operate the vacuum with the dustbin and HEPA filter installed.
2. Unplug the vacuum before cleaning.
3. Be sure to not let the dustbin become too full.
4. Clean the HEPA filter by hand under running water only.
5. Do not use things like a hair dryer to dry the HEPA filter. Air dry only.
6. Unplug vacuum while not in use.
7. Do not use outdoors or on wet surfaces.
8. Keep away from children.
9. Do not use with damaged cord or plug.
10. Return to authorized service center if the vacuum is not working, has been dropped, damaged, left outdoors, or dropped in water.
11. Do not pull or carry by cord, use cord as handle, close a door on cord, or pull cord around sharp edges or corners.
12. Be sure to keep the air intakes clean from dust, lint, hair, or anything else that may block or reduce airflow.
13. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
14. Do not handle plug with wet hands.
15. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
16. Turn vacuum off before unplugging.
17. Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
18. Do not vacuum anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

5.

Specifications

Power	400W MAX
Suction power	≥ 12KPA
Noise	≤ 78 DB
Rated Voltage	110-120V 50-60HZ
Dustbin Capacity	50 oz.
Size	44.4 x 5.9 x 9.8 in.
Weight	About 4.5lbs

IonVac ZipVac Item No. 8200. Distributed by tzumi Inc. NY, NY, 10016.

©Copyright 2021 tzumi. All Rights Reserved. Made In China

All pictures shown are for illustration purposes only.

Actual product may vary due to product enhancements.

Subject to change without prior notice.



If you have any questions
or need support setting up
or using your ZipVac,
email us at support@tzumi.com
or call 1-855-GO-TZUMI

For more details on
the ionVac family of products
or to check out more brilliant
innovations visit: www.tzumi.com.

tzumi®
live awesome.