

Voice remote control manual

User Manual

1. Product Introduction

This is a BLE low- power Bluetooth voice remote control, compatible with Android- TV smart televisions and TV boxes. It supports Bluetooth pairing, voice search, one- click quick- access streaming hot- keys and full- function operation. No line- of- sight alignment is required. You can control your TV from wide- angle and long- distance positions.

 Important Notice: This remote is **Bluetooth- only, no IR infrared function**. It can NOT work with traditional infrared- only televisions.

2. Technical Specifications

Item	Parameter
Communication	BLE Bluetooth 5.0 (Low- Energy)
Power Supply	2 × AAA Batteries (DC 3V)
Control Distance	≥ 10 meters (open space without obstacles)
Functions	Voice Search, Channel Selection, Navigation, Media Control, APP Shortcut Keys
Operating Temperature	-10℃ ~ +45℃

3. Button Function Description

Left- side Buttons

1. Voice Key: Press and hold to speak, release to send voice command
2. Numeric Keys (0- 9): Input channel numbers or digits
3. - / - - Key: Double- digit channel switch
4. Recall Key: Jump back to previous channel

5. Netflix / YouTube / Live-TV Hot- keys: One- tap launch corresponding streaming applications
6. Power Key: Turn TV on / enter standby mode

Middle Navigation Area

- Up / Down / Left / Right: Move on- screen cursor
- OK Key: Confirm selection
- Return Key: Go back to previous menu
- Home Key: Return to TV main home screen

Right- side Function Buttons

- Menu Key: Open TV system settings menu
- Volume + / Volume - : Adjust speaker volume
- CH + / CH - : Switch TV channels
- Color Buttons (Blue/Yellow/Green/Red): Expandable shortcut functions, follow on- screen prompts

4. Bluetooth Pairing Steps (Must pair for first- time use)

1. Open the battery cover and insert 2×AAA batteries, follow polarity marks inside the compartment.
2. Power on your Android TV, go to **Settings > Bluetooth**, turn on Bluetooth and start searching new devices.
3. Press and hold **Home + Return buttons together for 5- 8 seconds**. The remote will enter pairing mode.
4. Select the remote device name on your TV's Bluetooth list and complete connection.
5. Once connected successfully, all buttons will work normally.

Troubleshooting for failed pairing: Remove batteries, wait 10 seconds, reinstall batteries and restart pairing procedure.

5. How to Use Voice Function

1. Make sure the remote has been successfully connected over Bluetooth. Voice will not work under infrared connection.
2. **Press and hold the Voice button**, speak clearly toward the remote microphone.

Example voice commands: Open YouTube, Play movie, Set volume to 20, Search Andy Lau videos

3. Release the voice button after you finish speaking, the TV will execute your command.

6. Troubleshooting Guide

Problem	Solution
All buttons no response	1. Check AAA battery power & polarity; 2. Re- pair Bluetooth; 3. Reboot TV
Buttons work, but voice fails	1. Verify Bluetooth connection status; 2. Confirm your TV supports built- in voice assistant; 3. Enable microphone permission on TV
Intermittent / unstable control	1. Keep closer distance, stay away from 2.4GHz Wi- Fi routers (signal interference); 2. Replace with brand- new batteries
APP shortcut key no reaction	Corresponding streaming application is not installed on your TV, please download and install the APP manually.

7. Safety Precautions

1. Do NOT mix old and new batteries or different battery brands. Remove batteries if you will not use the remote for a long time to avoid battery leakage and circuit corrosion.
 2. Do not drop, submerge in water, or store this remote under high- temperature & humid environment.
 3. This remote only works for BLE- Bluetooth- enabled Android- TV devices, non- Bluetooth TVs are not compatible.
-

Outer Box Quick- Start Guide

Quick Pairing

1. Insert 2×AAA batteries
2. Turn on TV Bluetooth & start search
3. Hold **【Home + Return】** 5- 8s for pairing

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.