


Cordless Aesthetic

FACE SONO

사용설명서

Manual



***본 제품은 의료기기가 아닌 미용기기입니다.**

This product is a beauty device, not a medical device.

Homecare Device

(주)제이엘유의 제품을 구매해 주셔서 감사합니다.

본 제품은 의료기기가 아닌 미용기기입니다.

사용감과 체감에는 개인차가 있으며, 이상 증상이 나타나면 즉시 사용을 중지하십시오.

제품의 외관 및 규격 등은 품질 개선을 위하여 사전에 통보 없이 변경될 수 있습니다.

목차

01. 주의사항	03
02. 제품 소개	
- 구성품 및 명칭	04
- 제품 사양 및 충전 안내 및 디바이스 관리 방법	05
03. 사용 방법	
- 사용 방법	07
04. 보증 및 A/S	
- 보증 및 A/S	10
- 제품 보증서 및 정품 등록 방법	11
05. 영문 매뉴얼 ENGLISH MANUAL	12


※ 주의사항 (필독)

1. 본 제품은 의료기기가 아닌 미용기기입니다. 미용 관리 목적 외의 용도로 사용을 삼가십시오.
2. 제품 사용 전 헤드의 보호 필름을 제거하고 사용하십시오.
3. 제품 사용 전 반드시 제품이 정상 작동하는지 확인한 뒤 사용하시기 바랍니다.
4. 어린이·임산부·수유 중인 자에게 사용을 삼가하십시오.
5. 어린이 손이 닿지 않는 곳에 보관하십시오.
6. 심장 박동기 착용·장치 이식·중증 질환 이력·통원 치료 등 건강상 주의가 필요한 자에게 사용을 삼가하십시오.
7. 목걸이·귀걸이 등 금속류 액세서리를 제거 후 사용하십시오.
8. 상처·감염·종기 등 피부 질환 부위는 사용을 삼가하십시오.
9. 임플란트·신경 치료·교정 등 치과 치료와의 병행은 전문 의료인의 소견에 따르는 것을 권장합니다.
10. 수정체(눈), 눈 주변, 갑상선이 지나는 부위는 사용을 삼가하십시오.
11. 본 제품은 얼굴 전용 피부 관리 제품으로 얼굴 피부 외 다른 부위에 사용을 삼가하십시오.
12. 고객의 피부에 제품을 사용하기 전, 반드시 접촉부의 상태를 확인한 뒤 사용하시기 바랍니다.(온도, 이물질 등)
13. 관리 시 반드시 피부와 기기 사이가 뜨지 않도록 정확히 밀착해서 사용해 주십시오.
14. 한곳에 오래 멈추어 사용하면 피부가 자극을 받게 되므로 주의하여 사용하십시오.
15. 피부 민감도에 따라 적절한 강도를 설정하여 사용하십시오.
16. 관리 후 7일 내에는 사우나·찜질·각질 제거 등 피부 자극을 줄 수 있는 행위는 삼가하십시오.
17. 권장사항을 지키지 않아서 발생하는 부작용에 대해서는 당사가 책임지지 않습니다.


※ 제품 관리

1. 분리형 전원 공급 장치가 제공된 경우, 제품과 함께 제공된 전원 공급 장치만 사용하십시오.
2. 본 제품에는 전원 공급 장치가 포함되어 있지 않으므로, 제품 사양에 적합한 전원 공급 장치를 사용하십시오.
3. 제품을 개조하거나 분리·수리하지 마십시오. 사용자 임의로 개조·분리·수리 시 기간 내 무상 A/S 서비스를 받을 수 없으니 반드시 지정 A/S 센터를 이용하십시오.
4. 제품을 물에 씻거나 담그지 말고, 젖은 손으로 조작하거나 젖은 상태에서 충전하지 마십시오.
5. 제품을 습기가 있는 곳(욕실·세탁실·사우나 등)에 보관하면 고장의 원인이 될 수 있으므로, 습기에 노출되지 않도록 보관하십시오.
6. 제품에 충격을 주거나 떨어뜨리지 않도록 주의하십시오.
7. 제품 사용 후 헤드(접촉부)를 알코올로 가볍게 닦아 청결을 유지하십시오. 소독 시 거친 질감의 천을 사용하거나 표면을 강하게 닦으면 스크래치 등 손상이 발생할 수 있으므로 부드러운 천을 이용하십시오.
8. 본체는 알코올 소독 시 변색·오염 등이 발생할 수 있으므로 물티슈 또는 부드러운 천을 이용하십시오.
9. 이외 자세한 제품 관리·A/S 서비스는 제조사의 품질보증 규정을 따릅니다.

구성품






본체



림핏 하이드라 소닉
에센스 겔 300g
(증정용 겔)

명칭



제품 사양

*본 제품의 사양은 성능 향상이나 개선을 위하여 별도의 고지 없이 변경될 수 있습니다.



*본 제품의 사양은 측정 도구 및 위치 등 측정 방법에 따라 차이가 있을 수 있습니다.

모델명	JAH-S100A	제품명	피부관리기
제품 사이즈	H220 x D47 mm	제품 무게	약 370g
정격 전압	DC 5V 2A	배터리	2400mAh
충전 케이블	C-TYPE	LCD	1.14inch (135 x 240 px)
충전 시간	약 180분	사용 시간	약 150분
제조/판매원	(주)제이엘유	제조년월	별도 표기
A/S 센터	010-4505-7989	고객센터	051-331-7185


충전 안내

충전 케이블을 본체 또는 크레들에 연결할 때는 커넥터를 끝까지 밀어 넣어 주십시오. 연결이 불완전할 경우 충전이 원활하지 않을 수 있습니다. 충전이 되지 않거나 전원이 켜지지 않을 경우 충전부의 연결 상태를 확인해 주십시오.

제품 단독 사용





제품 하단




C-TYPE
충전단자 연결

크레들 사용




크레들 후면




C-TYPE
충전단자 연결

충전 화면



충전 중 화면

아이콘이 깜빡거리며
충전됩니다.



충전 완료 화면

충전 안내

1. 정격 전압(DC 5V 2A) 어댑터 사용을 권장합니다. 보조배터리를 이용한 충전도 가능하나, 충전 속도가 다소 느려질 수 있습니다.
2. 완충 후 전원을 켜를 때, 상단 배터리가 4칸에서 3칸으로 표시될 수 있습니다.
3. 이는 배터리가 덜 충전된 것이 아니라, 배터리 4칸 구간이 전압의 최고점에만 해당하도록 설계되어 있어 조금만 사용해도 3칸으로 표시되기 때문입니다.
4. 실제 배터리는 완충 상태이므로 사용 시간에는 지장이 없습니다.
5. 완충 직전과 방전 직후 단계에서는 배터리 안정성을 위해 미세한 전류로 천천히 충전되도록 설계되어 있어, 충전 시간이 다소 길게 느껴질 수 있습니다.
6. 완충 후 충전기를 다시 연결했을 때 'CHARGING(충전 중)' 표시가 나타나는 것도 정상 동작이므로 안심하고 사용해 주세요.
7. 충전 중 버튼 조작 등 디바이스 사용은 고장의 원인이 될 수 있습니다.
8. 충전 단자가 올바르게 맞춰지지 않았거나, 단자에 먼지·이물질이 쌓여 있는 경우 접촉 불량 발생할 수 있으므로 주의해 주세요.

디바이스 관리 방법



알코올 소독 가능

소독 시 부드러운 천 이용

알코올 금지

디바이스 본체는 알코올 소독 시 변색·오염 등이 발생할 수 있으므로 물티슈 또는 부드러운 천을 이용해 관리해 주세요.


*거친 질감의 천을 사용하거나 표면을 강하게 닦으면 스크래치 등 손상이 발생할 수 있으며 사용 부주의로 인한 제품 손상은 교환·환불이 불가능합니다.

사용 주기	매일 사용 가능, 하루 20분 내외 *개인의 피부 상태에 따라 사용 강도와 횟수는 조절하십시오.
사용 금지 부위	수정체(눈), 눈 주변, 갑상선이 지나는 부위
모드	4가지 (QUAD-1/3/10/17MHz 교차, DUAL-3/10MHz 교차, MASSAGE-3MHz, MOIST-10MHz)

자이로 센서 기능

디바이스의 오작동 및 과열을 방지하기 위해 움직임 감지 자이로센서 기능이 탑재되어 있습니다. 작동 중 움직임이 감지되지 않으면 안전을 위해 전원이 자동으로 꺼집니다. 이후 다시 사용하려면 전원 버튼을 눌러 디바이스를 재작동해 주세요.





[자이로센서 아이콘]

30초 이상 움직임 X ▶▶ 일시 정지

3분 이상 움직임 X ▶▶ 전원 OFF

주의사항

*방수·습기 및 초음파 겔·화장품 사용 시 주의

1. 본 제품은 방수가 되지 않으니 욕실, 세탁실, 사우나 등 습기가 많은 장소에서 보관하거나 사용하는 것은 피해 주세요.
2. 물기나 습기에 노출될 경우 제품 고장의 원인이 될 수 있습니다.
3. 초음파 겔이나 화장품을 디바이스에 직접 짜서 사용할 경우, 내용물이 제품의 틈 사이 또는 충전 연결부로 유입될 수 있으며, 제품 고장의 원인이 될 수 있습니다. 이로 인한 고장·손실은 소비자 과실로 제조사에서 책임지지 않습니다. 초음파 겔이나 화장품을 얼굴에 먼저 도포한 후 사용해 주세요.

사용 가능



디바이스 사용 전
초음파 겔이나 화장품을
얼굴에 먼저 도포한 후 사용해 주세요.

- * 수분감 있는 앰플류의 제품 사용을 권장합니다.
- * 마스크팩은 젤리 제형이 아닌 시트형 마스크팩을 사용해 주세요.

내용물 유입 주의

제품 틈 사이




환풍구



충전 연결부





STEP 01

얼굴에 물기를 제거하고 관리하려고 하는 부위에 전용 겔을 충분히 도포해주세요.

STEP 02

모드(주파수)와 강도를 선택한 뒤 사용을 시작해주세요.

STEP 03

1번,2번,3번 주위를 각 30초씩 순서대로 러빙해주고 3번→2번→1번 방향으로 쓸어내리듯 핸들링해주세요.

STEP 04

턱 부위부터 볼→눈가→이마 순으로 얼굴 전체를 러빙해주세요.


STEP 05

얼굴 관리 후 얼굴 중앙→3번→2번→1번 방향으로 쓸어내듯 핸들링해주세요.

작동법

전원 ON	전원 버튼을 2초 이상 누르면 화면과 함께 전원이 켜집니다.
전원 OFF	전원이 켜진 상태에서 전원 버튼을 2초 이상 누르면 화면과 함께 전원이 꺼집니다.
모드 설정	모드 버튼을 짧게 눌러 주파수를 설정합니다. (QUAD, DUAL, MASSAGE, MOIST)
강도 설정	전원 버튼을 짧게 눌러 강도를 설정합니다. (1~5단계)
일시 정지	시작/정지 버튼을 누르면 일시정지가 가능합니다.

화면 표시



- ① 배터리 상태
- ② 현재 설정된 모드
- ③ 현재 설정된 강도
- ④ 일시 정지 아이콘
- ⑤ 잔여 시간

본 보증 규정은 당사가 정한 보증기간과 조건의 범위에 한하여 적용되며,
A/S서비스는 제품 구매처 또는 본사 A/S 센터로 문의하여 주십시오.

※ 보증기간

제조일로부터 1년 이내, 정품 등록 시 무상 유지보수

보증기간 중 장비 본체의 제조상 결함이 확인될 경우, 무상 A/S 서비스를 제공받을 수 있습니다.

※ 유상 A/S 대상

① 보증 범위 외 제품

- 보증 기간이 지난 제품
- 정상적인 사용에 따른 배터리 성능 저하 및 소모품 마모

② 소모품 및 액세서리

- 소모품 (도자, 카트리지, 케이블, 어댑터, 핸드피스, 카트 등)
- 별도 제공 액세서리 (거치대, 크래들 등)

③ 소비자 과실 및 관리 미흡

- 낙하·충격·침수 등 소비자 과실로 인한 파손
- 부적절한 보관·사용 상태로 인한 제품 손상
- 천재지변(화재, 지진, 홍수 등)에 의한 파손

④ 임의 개조·환경적 요인

- 임의 분해·개조·수리로 인한 고장
- 비공식 소프트웨어·펌웨어 변경으로 인한 문제
- 천재지변(화재, 지진, 홍수 등)에 의한 파손

※ 예외 사항 (A/S 불가)

분실 또는 도난

※ A/S 배송비

택배로 진행되는 서비스의 배송비는 판매사와 소비자가 각각 부담합니다.

- 수리 전 발송 : 소비자 부담
- 수리 후 발송 : 판매사 부담

※ A/S 센터

- 대표 번호 : 010-4505-7989
- 운영 시간 : 오전 9시 ~ 오후 6시 토/일/공휴일 휴무 (점심시간 오후 12시 ~ 1시)
- 주소 : 부산광역시 북구 효열로 111 부산지식산업센터 4층 411호 (주)제이엘유

제품 보증서

(주)제이엘유의를 제품을 구매해 주셔서 감사합니다.

본 제품은 본사에서 제조한 정품으로
엄격한 품질 관리 및 검사 과정을 통과한 후 출하된 제품입니다.

홈페이지를 통해 정품 등록을 완료하시면
보증기간 내 무상 서비스가 가능합니다.

A/S 센터 : 010-4505-7989

[정품 등록 방법]

자사몰 접속 (www.jlu.kr) → 정품 등록 페이지 → 로그인 → 제품 시리얼 번호 입력

*제품 시리얼 번호 : 본체 별도 표기

전자적 표시(E-라벨) 확인 방법

본 제품의 적합성평가 정보를 제품 화면에 표시하는 전자적 표시(E-라벨) 방식을 적용하였습니다.

E-라벨 동작방법


제품의 전원을 켜후, 아래 순서에 따라 E-라벨 정보를 확인해 주세요

- ① 모드 버튼을 3초간 눌러주세요.
- ② 3초 이후 E-라벨 화면에서 적합성평가 정보가 표시 됩니다.

확인 종료

모드 버튼에서 손을 떼면 제품 동작 화면으로 돌아갑니다.

※ E-라벨 정보는 별도의 비밀번호 입력이나 추가 정치 연결없이 제품의 화면에서 확인 할수 있습니다.



※ 본 제품의 인증 정보는 제품의 E-라벨 뿐만 아니라 포장 박스 및 메뉴얼에 추가 기재되어 있으며, 언제든지 해당 정보를 확인 하실수 있습니다.

Homecare Device

Thank you for purchasing a product from JLU Co., Ltd.

This product is a beauty device, not a medical device.

Please note that the user experience and perceived effects may vary by individual. If any abnormal symptoms occur, discontinue use immediately

Table of Contents

01. Caution	-----	13
02. Product Introduction		
- Product Components & Name	-----	14
- Product Specifications & Charging Information	-----	15
03. Usage Method		
- Usage Method	-----	17
04. Warranty & A/S		
- Warranty & A/S	-----	20
- Product Warranty & Product Registration Guide	-----	21


※ CAUTION

1. This product is a beauty device, not a medical device. Please refrain from using it for any purpose other than beauty care.
2. Remove the Protective film from the head before using the device.
3. Before using the product, please make sure it is functioning properly.
4. Avoid use on children·pregnant·breastfeeding women.
5. Please keep out of reach of children.
6. Avoid use on people who require health precautions, such as having pacemaker·device implants·history of severe illness·outpatient treatment.
7. Remove metal accessories such as necklaces·earrings etc., before use.
8. Avoid use on areas with skin diseases such as wounds·infections·boils.
9. It is recommended to consult with a medical professional when using with dental treatments such as implants·nerve treatments·orthodontics.
10. Avoid use on pupils(eyes), around the eyes and where the thyroid gland passes.
11. This product is a skin care device intended for use on the face only. Avoid using it on any area other than the face.
12. Before applying the product to the customer's skin, always check the condition of the contact surface first (temperature, foreign substances, etc.).
13. During use, make sure the device is in full contact with the skin.
Do not leave any space between the device and the skin.
14. Use carefully, as prolonged use on one area may cause skin irritation.
15. Set the appropriate power based on the skin sensitivity.
16. Within 7 days after treatment, avoid activities that may irritate the skin, such as sauna·steaming·exfoliation
17. We are not responsible for any side effects that may occur as a result of not following our recommendations.


※ Product Care

1. If a detachable power supply is provided, only use the device with the power supply provided with it.
2. This product does not include a power supply unit. Use a power supply unit that complies with the product specifications.
3. Do not modify or disassemble·repair the product. If the user modifies·disassembles·repairs the product, free A/S service cannot be provided within the warranty period, therefore be sure to use the designated A/S center.
4. Do not touch with wet hands, do not wash or immerse the product in water. Be careful as it may cause electric shock·malfunction.
5. Do not store the product in humid environments (bathrooms·laundry rooms·saunas etc), as this may cause malfunction. Store it in a dry place, away from moisture.
6. Avoid dropping the product or subjecting it .
7. After use, gently wipe the head(contact area) with alcohol to maintain hygiene. Use a soft cloth for disinfection, as rough cloths or strong wiping can cause scratches or damage.
8. Use wet tissues or a soft cloth to clean the main body, as using alcohol may cause discoloration·contamination.
9. For detailed product care·A/S services, follow the manufacturer's warranty regulations.

Components




Main Body



Lymfit Hydra
Sonic Essence Gel 300g
(Complimentary)

Name



Product Specifications

*This product's specifications may be subject to change without separate notice for performance improvement.


*The specifications of this product may vary depending on the measuring tools, location, and other measurement conditions.

Model Name	JAH-S100A	Product Name	Skin care device
Product Size	H220 x D47 mm	Product Weight	About 370g
Input	DC 5V 2A	Battery	2400mAh
Charging Cable	C-TYPE	LCD	1.14inch (135 x 240 px)
Charging Time	About 180 minutes	Usage Time	About 150 minutes
Manufacturer/Seller	JLU Co., Ltd.	Date of Manufacture	Separate Notation
A/S Center	+82 10-4505-7989	Customer Center	+82 51-331-7185


Charging Information

When connecting the charging cable to the device or cradle, make sure the connector is fully inserted. An incomplete connection may result in improper charging. If the device does not charge or power on, please check the charging connection.


Device Charging



Cradle Charging




Charging Screen



Charging Screen

The icon will blink while charging.



Charging Complete Screen

Charging Information

1. We recommend using an adapter with the rated voltage (DC 5V, 2A).
Charging with a power bank is also possible, but the charging speed may be slightly slower.
2. After a full charge, when the power is turned on, the battery indicator may show 3 bars instead of 4.
3. This does not mean the battery is undercharged. The 4 bar section is designed to indicate only the very highest voltage range, so it may drop to 3 bars after just a short period of use.
4. The battery is still fully charged, and this does not affect the actual usage time.
5. Near full charge or right before complete discharge, the device is designed to charge slowly with a micro-current for battery safety. Because of this, charging may feel slightly longer than expected.
6. If the charger is reconnected after a full charge, the display may still show "CHARGING", which is also normal. You can use the device with confidence.
7. Do not operate the device while charging (e.g., pressing buttons), as this may cause malfunction.
8. If the charging port is not properly aligned, or if dust or foreign substances accumulate on the connector, poor contact may occur. Please check carefully before charging.

Device Care Method



Alcohol Disinfection Allowed

Use a soft cloth for disinfection

Alcohol Prohibited


Using a rough cloth or wiping the surface too hard may cause scratches or damage. Product damage due to user negligence is not eligible for exchange or refund.

*Use wet tissues or a soft cloth to clean the device body, as using alcohol may cause discoloration-contamination.

Usage Cycle	Can be used daily, recommended for 10~15 minutes a day *Depending on your skin condition, adjust the intensity and frequency of use.
Prohibited Areas of Use	Pupils(eyes), around the eyes the area where the thyroid gland passes
Mode	3 types (QUAD-1/3/10/17MHz cross, DUAL-3/10MHz cross, MASSAGE-3MHz, MOIST-10MHz)

Gyro Sensor Function

To prevent malfunction and overheating, the device is equipped with a movement detector gyro sensor. If no movement is detected during operation, the output will automatically stop. Once movement is detected again while the gyro sensor is active, the output will automatically resume.



Precautions

*Precautions for Water·Moisture, and the Use of Ultrasound Gel·Skincare

1. This product is not waterproof. Please avoid storing or using it in humid environments such as bathrooms, laundry rooms, or saunas.
2. Exposure to water or moisture may cause product malfunction.
3. If ultrasound gel or skincare are applied directly onto the device, the contents may seep into gaps in the product or into the charging port, which may cause malfunction. Any damage-loss resulting from this will be considered consumer negligence, and the manufacturer will not be responsible. Apply ultrasound gel or skincare to the face first before using the device.

Usable



Before using the device,
apply ultrasound gel or cosmetics to your face.

* Use cosmetics with a light,
liquid texture rather than cream-type products.

* Use sheet masks instead of gel-type masks.

Prevent liquid from entering the device

Gaps in the product



Vent




Charging port



03. Usage Method - Quick Guide

19



STEP 01

After cleansing, dry your face and apply a sufficient amount of the gel to the area to be treated.

STEP 02

Select the desired mode(frequency) and intensity level, then start.

STEP 03

Rub each area in order 1,2,3 for about 30 seconds each, then gently handle the device in the direction of 3→2→1.

STEP 04

Rub the entire face starting from the chin area then cheeks→ eyes→forehead.


STEP 05

After facial treatment, gently handle the device from the center of the face to 3→2→1.

Operation Method

POWER ON	Press the power button for more than 2 seconds and the device will turn on with the screen.
POWER OFF	When it turns on, press the power button for more than 2 seconds to turn it off.
Mode Settings	Set the frequency by briefly pressing the mode button. (QUAD, DUAL, MASSAGE, MOIST)
Power Settings	Set the power by briefly pressing the power button. (Level 1~5)
Pause	It is possible to pause with the start/stop button.

Screen Information



- ① Battery status
- ② The currently set mode
- ③ The currently set power
- ④ Pause icon
- ⑤ Remaining Time

This warranty policy applies only within the warranty period and conditions specified by our company. For A/S service, please contact the place of purchase or our headquarters A/S center.

※ Warranty Period

Within 1year from the date of manufacture, free maintenance is provided upon product registration. If a manufacturing defect in the main body is confirmed during the warranty period, free A/S service will be provided.

※ Paid A/S

① Products outside the warranty scope

- Products past the warranty period
- Battery performance degradation and wear of consumables due to normal use

② Consumables and accessories

- Consumables (head, cartridge, cable, adapter, handpiece, cart, etc.)
- Separately provided accessories (stand, cradle, etc.)

③ Customer negligence or improper management

- Damage caused by customer negligence such as dropping·impact·water exposure
- Damage due to improper storage or usage conditions
- Exterior damage (scratches, discoloration, peeling of coating, etc.)

④ Unauthorized modification·environmental factors

- Failures caused by unauthorized disassembly·modification·repair
- Issues due to unofficial software·firmware changes
- Damage caused by natural disasters (fire, earthquake, flood, etc.)

※ Exceptions (A/S is not available)

Lost or stolen

※ A/S Shipping Fee

For services conducted via courier, shipping costs are shared between the seller and the customer.

- Before repair : Customer bears the cost
- After repair : Seller bears the cost

※ A/S Center

- Contact Number : +82 10-4505-7989
- Operating : 9:00 AM ~ 6:00 PM Closed on Sat/Sun/public holidays(Lunch break 12:00 PM - 1:00 PM)
- Address : JLU Co., Ltd. 411 office, Busan Knowledge Industry Center, 111, Hyoyeol-ro, Buk-gu, Busan, Republic of Korea

Product Warranty

Thank you for purchasing JLU products.

This product is a genuine product manufactured by the headquarters and shipped after passing strict quality control and inspection processes.

Free service within the warranty period is available if you complete the product registration through the homepage.

A/S Center : +82 10-4505-7989

[How to Register the Product]

Visit the official website (www.jlu.kr) → Go to the Product Registration page
→ Log in → Enter your product serial number

*S/N : Separate notation on the product

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

How to check the electronic label (e-label)

This product utilizes an electronic labeling (e-label) method to display conformity assessment information on the product screen.

How to access the e-label


After turning on the device, please check the e-label information by following the steps below.

- ① Please press and hold the Mode button for 3 seconds.
- ② After 3 seconds, the conformity assessment information is displayed on the E-label screen.

Exit View

Releasing the Mode button returns the display to the operation screen.

※ E-label information can be viewed directly on the product screen without entering a password or connecting additional devices.



※ Certification information for this product is provided not only via the on-screen E-label but also on the packaging box and in the manual, allowing you to check the details at any time.