



2.Pull out the tray using the handle.




3.Put the phone into inner plate and use the suction cup to suck the back of the phone to prevent the phone from loosening. The position of the mobile phone camera must be aligned with the camera window.




The foam is designed to hold the phone in place, avoiding unobstructed screen operation. The default configuration is fixed foam.
If the phone fits tightly when placed, you may opt for the complementary thin foam provided separately.

6

4.Place the tray together with the phone into the diving case.



5.Close the side sealing cover and fasten the case-release latch. Installation is complete.



7

5 Waterproof test

- 1) Prepare several pieces of napkin
- 2) Place the napkin into the case
- 3) Close the case, make sure it is completely locked
- 4) Immerse the case in the water for 60 minutes, make the depth is no more than 15 meters
- 5) Take out the case, wipe the surface with fibre cloth
- 6) Open the case and take out the napkin
- 7) Carefully check the napkin, only if the napkin is dry could the case be used, otherwise stop using and ask the customer service for a new one.

6 Reminder

Lower left button: Long press this button when the phone screen is off to directly activate the camera function.
During charging, the four blue lights at the bottom will illuminate progressively. When fully charged, these four blue lights will remain steadily lit. When the battery is low, the four blue lights at the bottom will turn off. During power-on pairing, the blue light at the top will flash; once pairing is successful, the light will turn off. Each press of the button will trigger a single flash of the top blue light.
The Bluetooth controller will automatically power off after 1 hour of inactivity and disconnect from the phone. Long press the power button to turn it on, and it will automatically reconnect to the phone upon startup.

Accessibility

Zoom

Zoom

Zoom magnifies the entire screen:
• Double-tap three fingers to zoom
• Drag three fingers to move round the screen
• Double-tap three fingers and drag to change zoom

PRECAUTIONS FOR USE

1.After installing the diving case, the phone's touch functionality will be disabled, rendering the screen unusable.

2.The mobile phone needs to complete Bluetooth connecting with the case before diving.

3.If the mobile phone is set with the rest screen function, the rest screen function needs to be turned off before diving in order to take pictures/photography functions underwater at any time.

4.The Bluetooth remote control has limited signal under water and cannot be separated from the diving case underwater.

5.Note: The IOS system needs to be turned on "Settings"->"Accessibility"->"Turn on zoom"(Double-tap three fingers to restore to original size after turn zoom)

9

QUICK START GUIDE

Before using your case, read all instructions on this manual. Complete the WATER TEST before using this case with your phone.

Mode d'emploi
Gebrauchsanweisung
Gebruiksaanwijzing
Instrucciones de uso
Istruzioni per l'uso



FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Warning Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

1 Product appearance



Bluetooth Camera Controller	Mounting Groove
Compass	Anti-slip Silicone
Vent Hole	Camera window

- Maximum diving depth with this case is 15 meters.

2 Attention

Please read the below instructions carefully before using this case.

Operation and maintenance

- Strictly follow the installation & disassembly instructions every time when using.

1

- Ensure the case-release latch is securely fastened and the seal is tightly closed before diving.
- Stop using this case if the sealing ring is damaged or deformed.
- Maximum diving depth is 15meters,over 15 meters is not guaranteed.
- Test the camera shutter button after every-time installation,make sure it is able to rebound after pressing.
- If the camera window is fogged up,keep the desiccant inside the case at least for 10 minutes before putting the case into the water.
- After every-time using,immerse the completely locked case in fresh water for 20 minutes,then wipe the case with soft fibre cloth and keep in a dry place.
- Do not expose the case under the high temperature environment or beside heating equipments,e.g.hot sunshine,oven,or water heater.
- Conduct waterproof test before diving.
- Do not use the case in sulfur-bearing hot spring.
- Do not take the case apart or outfit,privately,otherwise the waterproof function may be descended.
- It is not suggested you rent or lend this case to others in case of any disputes.

Keep away from Children.

- This product is not a toy, adults must have custody of the children.

2

Accessories

- Only the self-contained or manufacturer approved accessories could be used, other accessories may violate the local rules and possible safety issue may occur. Please contact customer service if you need approved accessories.

Environment protection

- Do not dump this product and its accessories as daily trash.
- Please follow your local rules to handle and recycle.

3 Compatible Phone Model

- Newly upgraded design, compatible with most mobile phone models such as iPhone and Samsung, with a compatibility rate of over 98%.

4 Installation instructions

Installation premise

- Please do waterproof test to this case before installing your phone.
- Tear off any protective tempered glass or film from the phone screen and wipe the phone screen with fibre cloth,make sure the screen is clean before installing the phone into the case.


Installation steps

1.Long press around 3 seconds to open the Bluetooth of controller before using, open the Bluetooth of phone test whether the controller function is in normal use.

3

- Press and hold the shooting button for 3 seconds to power on, and the blue light will flash continuously. Press and hold for 3 seconds again to power off.
- Select SHELL BOX-BT-PRO to pair your phone and then can be used normally.

Shutter Power Button



The device shall not be operated normally during charging.

BLUETOOTH CONTROLLER BUTTON FUNCTION

Long press (on/off), short press to shoot

Short press to switch camera mode? Press and hold to power on

Short press to zoom in? Press and hold to zoom out

Short press to zoom out? Press and hold to zoom in

Short press to enter the camera menu? Press and hold to enter the camera menu

NOTICE


For IOS: Apple system needs to open "Settings"->"Accessibility"->"Turn on zoom" to use Bluetooth device normally. 10-20s, long press when the screen is off can only turn on the screen first and then short press to enter the camera.

For Cam: After the screen turns off or exits to a 110s, long pressing this button does not allow you to quickly enter the camera via MOTO, you cannot shoot when sleep. To shoot, you have to turn on the screen first and then short press the button to quickly enter the camera.

4

Bluetooth device


- Charging time: Standard charging approx 2 hours
- Battery capacity: 3.7V 110mAh
- Signal distance: Signal propagation range on land 18m



Fasten the USB plug securely prior to water exposure.

Bluetooth remote control has limited signal underwater; cannot be used separately from the diving housing.

1.Twist the screw and open the side Airtight cap



5

M