

PO11035_UAKSSTGY UAKSSTBG_Artikl_ Bluetooth Karaoke Set_PKG_Outlined_Jul08

Fold Size: 70w x 90h mm

Artikl Bluetooth Karaoke Set
with 2 Mics & Mic Storage



Read this user manual thoroughly before you use the product and keep it for future reference.

PACKAGE INCLUDES

- 1 x Karaoke Speaker

2 x Microphones
- 1 x USB-C Charging Cable

1 x Audio Jack

1 x User Manual

FEATURES

1. RGB Lights

2. Wireless Bluetooth Connectivity

3. Microphone Storage at the Back

4. Dual Microphone Input

5. Adjustable Volume on Microphones

6. Voice Effects

PRODUCT SPECIFICATIONS

Speaker:


Model:	UAKSSTGY, UAKSSTBG
Material:	ABS, Fabric
Dimension:	192 x 138 x 259 mm
Bluetooth version:	v6.0
Bluetooth Range:	10 m
Connectivity:	TF Card/USB/AUX/Bluetooth
Charging Port:	USB-C

Rated input Voltage	5V/1A
Rated Power:	8 W
Battery Capacity:	2400 mAh
Playback Time:	Up to 6 hours
Charging Time:	4-6 hours

Microphone:

Battery Capacity:	300 mAh
Playback Time:	Up to 8 hours
Charging Time:	Around 1 hour
Charging Port:	USB-C
Quantity:	2 pcs

OVERVIEW



1. LED Lighting

2. VOL- button/Previous song

3. Play & Pause button

4. VOL+ button/Next song

5. Power ON/OFF button

6. USB-C charging port

7. Micro SD/TF card slot
8. USB for audio playback

9. AUX in port

10. Mic Power ON/OFF button

11. Mic VOL+ button

12. Mic VOL- button

13. Change voice

INSTRUCTIONS

Charging:

1. A USB-C Cable is provided. Insert the provided USB-C cable into the USB-C port. Connect the other end of the cable to a compatible wall adapter.

2. Regularly charge the device (at least once a month) to maintain battery life. Prolonged storage at low charge may reduce battery performance.

3. The indicator remains red during charging and turns off once fully charged.

4. It takes 4-6 hours to fully charge the product.

How To Use:

1. Hold the power button to turn on the speaker.

2. Connect your phone to the speaker via Bluetooth, select "Artikl Karaoke Set" in your Bluetooth settings to pair.

3. Turn on the microphone, and it will automatically connect to the speaker.

4. Micro SD or USB Operation: Insert the USB drive into the USB port or the MicroSD card into the TF slot.

5. Play, pause, or skip a selected track using the controls on the speaker.

6. AUX-in Operation: You can connect an external music player or sound source to your Bluetooth speaker.

7. Plug the micro side of the AUX-in cable into the Bluetooth speaker and connect the 3.5mm AUX side to your external audio source.

8. Short press Play & Pause button can stop or continue music.

Safety Instructions:

Read all the instructions carefully before using the product.

1. Use only the supplied USB-C charging cable or a compatible USB-C charging cable.

2. Disconnect the charging cable once charging is complete.

3. Do not use the product while it is being charged.

4. Use indoors and in a dry location only. Keep away from wet or damp locations.

5. Keep the product away from any liquids or moisture.

6. Do not handle with wet hands.

7. Unplug the product when unused for long periods of time.

8. Do not store the product in a high-temperature environment, including heat caused by intense sunlight or other forms of heat.

9. Do not expose the product to fire or excessive temperature.

10. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use.

11. Do not disassemble the product or attempt to re-purpose or modify it in any manner.

12. Do not use the product in excess of its output rating. Overloading outputs above rating may result in a risk of fire or injury to persons.

13. Stop using immediately in the event of abnormalities, such as overheating, unstable power supply, or the presence of a burnt smell.

14. Do not let children use it without supervision. Store the product out of reach of children and pets.

15. Clean with dry cloth if necessary.

TROUBLESHOOTING

Problem Description	Reason	Troubleshooting
Speaker doesn't turn on	Battery is low or depleted	Charge the device using the supplied USB-C cable and try again.
Speaker is not connecting to Bluetooth	Bluetooth is not enabled or the device is out of range	Turn on Bluetooth on your device, place it closer to the speaker, and try pairing again.
No sound is coming from the speaker	Volume is set too low or the device is not connected properly	Increase the volume on both the speaker and connected device, and check the connection
Microphone is not working	Microphone is not powered on or connected properly	Ensure the microphone is turned on and properly connected to the speaker.

RoHS
compliant
conforme
à la norme



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.