

Homedics®

ModMassage Shiatsu + Air Foot Massager with Heat



INSTRUCTION MANUAL AND WARRANTY INFORMATION

1-year limited warranty

FMS-386H-AU



IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING.

DANGER: TO REDUCE THE RISK OF ELECTRIC SHOCK:

- An appliance should NEVER be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts or attachments.
- Close supervision is necessary when this unit is used by, on, or near children, or disabled persons.
- DO NOT use outdoors.
- Use this appliance only for its intended use as described in this manual. DO NOT use attachments not recommended by Homedics; specifically, any attachments not provided with the unit.
- DO NOT carry this appliance by the supply cord or use cord as a handle.
- NEVER operate this product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. DO NOT attempt to repair this product. There are no user-serviceable parts.
- Keep the cord away from heated surfaces.
- NEVER operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- NEVER drop or insert any object into any opening.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- DO NOT stand on or in appliance. Use only while seated.
- DO NOT operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- To disconnect, turn all controls to the off position, then remove plug from outlet.
- Use heated surfaces carefully. May cause serious burns. DO NOT use over insensitive skin areas or in the presence of poor circulation. The unattended use of heat by children or incapacitated persons may be dangerous.
- DO NOT use massager in close proximity to loose clothing or jewelry.
- Keep long hair away from massager while in use.

SAVE THESE INSTRUCTIONS

CAUTION — PLEASE READ ALL INSTRUCTIONS BEFORE OPERATING

- This product is not intended for medical use
- Consult your doctor prior to using this product, if:
 - You are pregnant
 - You have a pacemaker
 - You have any concerns regarding your health
- Not recommended for use by diabetics.
- NEVER leave the unit unattended, especially if children are present.
- NEVER cover the unit when it is in operation.
- If at any time, soreness, rash, or pain occurs, discontinue use and consult your physician.
- DO NOT use this product for more than 15 minutes at a time.
- NEVER use this product directly on swollen or inflamed areas or skin eruptions.
- DO NOT use this product as a substitute for medical attention.
- NEVER use this product while in bed.
- This product should NEVER be used by any individual suffering from any physical ailment that would limit the user's capacity to operate the controls or who has sensory deficiencies.
- This product is intended for household use only.
- This product is not intended for use in automobiles.
- Not for use by children.

To avoid injury and irreparable damage, always remain seated when using massager. NEVER stand on the unit.

Always use power adapter supplied with this product only.

Adapter Input	100-240V AC, 50/60 Hz, 1 A
Massager Input	24 V DC, 1.5 A
	Made in China



INSTRUCTIONS FOR USE

1. Insert the power adaptor into the port at the back of the foot massager, and insert the plug into the power outlet.
2. It is highly recommended that you wear socks while using this foot massager.
3. Place massager on the floor in front of your chair or seat and place feet in the massager.

BUTTON OPERATION

POWER BUTTON

Note: Device will not power on if the top lid shell is not properly closed.

To turn on the massage functions, press the power button . Massage will automatically begin in the default setting: low massage intensity and Mode 1, indicated by a white LED light. To power off the unit, press the power button  again.

MODE BUTTON (M)

This device is equipped with three operating modes. Each mode uses different sequences of the massage styles combined with pauses and pulsing sensations to create three unique massage experiences.

Mode 1: Shiatsu + Air Indicated by a white LED light.

Mode 2: Shiatsu + Air + Vibration Indicated by a blue LED light.

Mode 3: Shiatsu + Air + Vibration Indicated by a green LED light.

NOTE: For your safety, there is a 15-minute auto shutoff on the unit.



INTENSITY BUTTON

The device offers three air compression intensity levels

- Low Intensity: Indicated by a white LED light.
- Medium Intensity: Indicated by a blue LED light.
- High Intensity: Indicated by a green LED light.

HEAT BUTTON


For soothing heat when the massage is on, press the heat button. Please allow a few minutes for the massager to heat up. To turn off the heat, press the button again.

For your safety, the heat cannot be turned on if massage is not selected.

INTERCHANGEABLE MESSAGE NODES

Interchangeable massage nodes

Non-removable heat nodes



Additional set of message nodes stored on docking prongs

Includes two sets of interchangeable messages nodes that provide three unique massage experiences:

SET 1. DUAL-SIDE NODES –

These nodes can be flipped over for two different massage sensations



Larger ball tip = gentler massage



Smaller ball tip = deeper massage

SET 2. LARGE CONCENTRIC NODES –

Offer a more intense massage, great for massaging feet arches.



We or us means Homedics Australia Pty Ltd ACN 31 103 985 717 and our contact details are set out at the end of this warranty;

You means the purchaser or the original end-user of the Goods. You may be a domestic user or a professional user;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia and New Zealand; and

Goods means the product or equipment which was accompanied by this warranty and purchased in Australia and New Zealand.

For Australia:

Our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled, subject to the provisions of the Australian Consumer Law, to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled, subject to the provisions of the Australian Consumer Law, to have the Goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This is not a complete statement of your legal rights as a consumer.

For New Zealand:

Our Goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This guarantee applies in addition to the conditions and guarantees implied by that legislation.

The Warranty

Homedics sells its products with the intent that they are free of defects in manufacture and workmanship under normal use and service. In the unlikely event that your Homedics product proves to be faulty within 1 year from the date of purchase due to workmanship or materials only, we will replace it at our own expense, subject to the terms and conditions of this guarantee. The warranty period is limited to 3 months from the date of purchase for products used commercially/professionally.

Terms and Conditions:

In addition to the rights and remedies that you have under the Australian Consumer Law, Consumer Guarantees Act of New Zealand or any other applicable law and without excluding such rights and remedies warranty against defects: The Goods are designed to withstand the rigors of normal household use and are manufactured to the highest standards using the highest quality components. Whilst unlikely, if, during the first 12 months (3 months commercial use) from their date of purchase from the Supplier (Warranty Period), the Goods prove defective by reason of improper workmanship or materials and none of your statutory rights or remedies apply, we will replace the Goods, subject to the terms and conditions of this warranty.

We **DO NOT** have to replace the Goods under this Additional Warranty if the Goods have been damaged due to misuse or abuse, accident, the

attachment of any unauthorised accessory, alteration to the product, improper installation, unauthorised repairs or modifications, improper use of electrical/power supply, loss of power, malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance, transportation damage, theft, neglect, vandalism, environmental conditions or any other conditions whatsoever that are beyond the control of Homedics.

This Warranty does not extend to the purchase of used, repaired or second-hand products or to products not imported or supplied by Homedics Australia Pty Ltd, including but not limited to those sold on offshore internet auction sites.

This Warranty extends only to consumers and does not extend to Suppliers.

Even when we **DO NOT** have to replace the Goods, we may decide to do so anyway. In some cases, we may decide to substitute the Goods with a similar alternative product of our choosing. All such decisions are at our absolute discretion. All such replaced or substituted Goods continue to receive the benefit of this Additional Warranty for the time remaining on the original Warranty Period (or three months, whichever is the longest).

This Additional Warranty does not cover items damaged by normal wear and tear including but not limited to chips, scratches, abrasions,

discolouration and other minor defects, where the damage has negligible effect on the operation or performance of the Goods.

This Additional Warranty is limited to replacement or substitution only. As far as the law permits, we will not be liable for any loss or damage caused to property or persons arising from any cause whatsoever and shall have no liability for any incidental, consequential, or special damages.

This warranty is only valid and enforceable in Australia and New Zealand.

Making a Claim:

In order to claim under this Warranty, you must return the Goods to the Supplier (place of purchase) for replacement. If this is not possible, please contact our Customer Service department by email: cservice@homedics.com.au or at the address below.

All returned Goods must be accompanied by satisfactory proof of purchase which clearly indicates the name and address of the Supplier, the date and place of purchase and identifies product. It is best to provide an original, legible, and unmodified receipt or sales invoice.

You must bear any expense for return of the Goods or otherwise associated with making your claim under this Additional Warranty.

DISTRIBUTED BY

AUSTRALIA: Homedics Australia Pty Ltd,
14 Kingsley Close, Rowville, VIC 3178

NEW ZEALAND: CDB Media Ltd, 4 Lovell Court, Albany,
Auckland, New Zealand 0800 232 633

Homedics Customer Service:
Email: cservice@homedics.com.au



DISTRIBUTED BY

**AUSTRALIA: Homedics Australia Pty Ltd,
14 Kingsley Close, Rowville, VIC 3178**

**NEW ZEALAND: CDB Media Ltd, 4 Lovell Court, Albany,
Auckland, New Zealand 0800 232 633**