

防丢器使用说明书

Loss prevention instruction manual

本产品为 IOS 的移动设备专用,安卓用户请勿购买!!

防丢器收到后确认有无破损,塑料绝缘片是否存在,若有产品外观损坏或者绝缘片缺失,请将产品装回包装盒,在平台申请退货。

使用方法:

- 1、拔出产品上用来绝缘的塑料卡片,听到’滴”声后代表设备开机,进入匹配状态。
- 2、打开 iOS 设备的’查我” APP,点击’物品”然后点击右上角的“+”,然后点击“添加其他物品”这时会出现搜索界面,当搜索到设备名称后点击连接
- 3、根据提示给设备命名,此时你的设备就和防丢器绑定好了

将防丢器绑定在物品上(比如钥匙,钱包等物品),当你找到物品时,可以打开“查找”来查看物品的位置,如果距比较远可以根据导航我到位置,如果物品很近,在 10 米的范围内,可以点击“播放声音”根据“滴滴”的声音找到物品

防丢器的电池为 2032 纽扣电池,当防丢器电池没电后,可以自行比较近的商店购买补充

This product is for IOS mobile devices, Android users please do not buy!

Loss prevention device received to confirm that there is no damage to the plastic insulation piece is present, if there is damage to the appearance of the product or the insulation piece is missing, please put the product back into the box and apply for a return on the platform.

Usage:

1, pull out the plastic card used to insulate the product, after hearing the "drop" sound

On behalf of the device is turned on, enter the matching state.

2, open the iOS device's "Find" APP click on "items" and then click on the "+" in the upper right corner, then click on "add other items". The search interface will appear, when the device name is searched, click on the connection.

3, According to the prompts to give the device a name, at this time your device and the anti-loss device binding good!

Bind the anti-lost device to items (such as keys, wallets and other items), when you can't find the items, you can open the "Find" to check the location of the items, if the distance is far away, you can find the location according to the navigation, if the items are very close to the 10-meter range, you can click on the "Play Sound" button. If the item is very close, within 10 meters, you can click "Play Sound" to find the item according to the sound of "drop".

The battery of the anti-lost device is 2032 button battery, when the battery of the anti-lost device is dead, you can buy a supplement from the nearest store.

Steps to Use

(No additional APP download required)

01

Press the power switch
"didi" sound indicates
power on



02

Open APP "find my"
device "Add new items"
- supported items"



03

Item name completed
, start to use



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.