




Contact our experts
support@yelow.net

CR1001F



Alarm Clock with Time Projection
CREATE YOUR PERFECT SLEEP ENVIRONMENT

[Http://www.yelow.net](http://www.yelow.net)



Version 1.3

Chapter 1 LOCATION OF CONTROLS




- | | |
|--------------------------|----------------------|
| 1.SET TIME | 2.HOUR |
| 3.MINUTE | 4.DIMMER/DST |
| 5.SNOOZE/OK | 6.ALARM 1/ALARM OFF |
| 7.ALARM 2/ALARM OFF | 8.ALARM ON/PAUSE |
| 9.PROJECTION ON/FLIP/OFF | 10.VOLUME+ |
| 11.VOLUME- | 12.PM INDICATOR |
| 13.DST INDICATOR | 14.ALARM 1 INDICATOR |
| 15.ALARM 2 INDICATOR | 16.FOCUS RING |
| 17.BATTERY DOOR | 18.USB PORT |
| 19.DC JACK | 20.SPEAKER |
| 21.HOELDER (x 2pcs) | |

Chapter 2 POWERING ON

1. Install 2pcs 1.5V "AAA" size batteries to the proper terminals in the battery compartment to memorize the time setting in case of power outage.

NOTE: Batteries(not included) don't support time display but can trigger an alarm in case of AC power failure

2. Connect the adapter line to DC jack , then plug into a 100~240V AC wall power outlet.



Chapter 3 TIME SETTING

1. Press **SET TIME** button once, display **12:00** starts flashing.
2. Press **HOUR** button to set the hour. press **MIN** button to set the minute.
3. Press **SET TIME** button or **OK SNOOZE** button to save time or wait for another 5 seconds to confirm automatically.

To change 12H/24H time format

Hold press **SET TIME** to change 12H/24H time format.

Chapter 4 ALARM SETTING

1. Press  button, the alarm indicator  will light up, the display  starts flickering.
2. Press  button to set the hour, press  button to set the minute.
3. Press  button or  button to save alarm time or just wait for another 5 seconds to confirm automatically.
4. Push  or  button to adjust alarm volume.

Turn off Alarm

When alarm goes off:


1. Press  button to temporarily turn off alarm for 9 minutes. Alarm will ring every next 9 minutes.
2. Press  button to turn off alarm for 24 hours.
The alarm indicator  is still on, which means alarm is still activated and will ring after 24 hours.
3. Cancel Alarm
Hold press  button until the alarm indicator  will disappear from the display.

Setting ALARM 2 is the same as ALARM 1.

- 03 -

Chapter 7 PROJECTION MODE

1. Press Projection mode  button to turn on projection.
2. Press  button once again to flip the projection time reversely.
3. Press  once again to turn off projection.




Note: 1. Best projection distance is between 1.5 to 3.0 meters.

2. Projector is a common LED light. So the projector is not visible in bright environment.

4. Rotate focus ring  to adjust clarity of projection image.

Note: if projection numbers are fuzzy, please rotate the focus ring (17) to adjust proper angle for clear projection image.




- 05 -

Chapter 5 DIMMER & DST

Repeat  button to adjust the brightness of display for your preference.
Hold press  button to switch DST function.

Chapter 6 USB CHARGING

Plug charging cable into device such as phone or tablet.
Device can charge both your phone or tablet at the same time.
The maximum charge current is 1 Ampere.



- 04 -

Chapter 8 WARRANTY

1. ROCAM Electronics Co., Ltd warrants the ROCAM branded alarm clock and accessories contained in the original packaging against defects in materials and workmanship when used normally in accordance with ROCAM's published guidelines for a period of 1 year and replacement service within 3 months from the date of original retail purchase by the end-user purchaser ("Warranty Period"). Moreover, 1-month refund policy is available for the original consumer or recipient.
2. The original consumer or recipient can sign up on our website for a 18 months extended warranty.
3. If you need any help for this product, please feel free to contact us by [Email:support@yelow.net](mailto:support@yelow.net)

Remarks:

- a. This warranty does not include: damage to product or components resulting from abuse, accident, or climatic/environmental conditions; damage resulting from normal wear or tear, misuse, or unauthorized repair; changes in surface finishes due to aging or exposure to light. The company's obligation under this warranty shall be limited to repairing the product or component, or at its option, replacing it with a new product or components.
- b. Our company reserves the right to revise the warranty policies without notification. Please check our website to obtain the latest updates.

- 06 -