

PHILIPS

HD Antenna



Audio/Video

SDV3238N/27

v3 3/22

1. Connect

Attach the antenna stand to the antenna for tabletop placement.




Connect the coax cable from the antenna to the TV's coax cable port, then connect the AC adapter to the power inserter and a wall outlet.

Note: If your TV does not have a coax cable port, a converter box is required for installation.

Please note: Use only the supplied AC adapter.


2. Place

Place the antenna in your desired location.



Mounting supplies included.


Check the signal finder LED indicator lights with the antenna in different locations to discover the best reception.



Press the ON/OFF button to operate the signal finder LED indicator lights.

3. Scan

Perform a TV channel scan.



1. Open your TV's *setup* or *settings* menu.
2. Select your TV's scanning command — *scan*, *auto tune*, *channel search* or *channel scan*, making sure it's set to scan for over-the-air channels rather than cable.
3. Wait for the channel scan to finish.

Scanning Tips

- Consult the TV manual or visit the TV manufacturer's website for specific instructions.
- Rescan for over-the-air channels anytime you move the antenna.

Antenna helpful tips

- Maximize the number of channels you receive by placing the antenna in several different locations. **Be sure to run a new channel scan on your TV in each position.** Refer to the instruction manual that came with your TV if you are unsure how to do this.
- Position or mount the antenna as high as possible or near a window for best performance.
- Visit www.antennaweb.org to determine the available television stations and location of the broadcast towers in your area.

QUESTIONS? ISSUES?
CALL OUR U.S.-BASED EXPERTS AT
1-844-816-0320

MADE IN TAIWAN

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of Jasco Products Company, and Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114 is the warrantor in relation to this product.

This product comes with a limited-lifetime warranty. Visit www.philips.com/support for warranty details.

Questions? Contact our U.S.-based Consumer Care at 1-844-816-0320 between 7AM-8PM, M-F, Central Time.



byjasco.com/recycle

THANK YOU FOR YOUR PURCHASE!




Product instructions made easy

Scan to watch a step-by-step video or visit <https://byjasco.com/45289i>



Register your Philips product

Get exclusive, web-only deals and more! Scan here or visit byjasco.com/deals



Need accessories?

Find antennas, amplifiers, splitters, cables and more, just visit our website! byjasco.com/antennas



Like our product?

Leave us a review on Amazon.com or your favorite retailer website!



Having issues and need support?

Call our U.S.-based experts Monday-Friday, from 7AM-8PM (Central Time).
1-844-816-0320



User Guide



PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE, CALL US FIRST!

Installation questions?

Contact us at 1-844-816-0320 between 7AM-8PM, M-F, Central Time.



PHILIPS

HD Antenna

Audio/Video



SDV3238N/27



V3 3/22

1. Conectar

Fije el soporte de antena para ubicarla sobre una mesa.




Conecte el cable coaxial desde la antena hacia el televisor, luego conecte el adaptador de CA en el insertador de potencia y un tomacorriente de pared.

Nota: Si su televisor no tiene un puerto de cable coaxial, se requiere un convertidor para la instalación.

Nota: Use únicamente el adaptador de CA suministrado.


2. Colocar

Coloque la antena en su ubicación deseada.



Accesorios de montaje incluidos.


Compruebe las luces indicadoras LED del buscador de señal ubicando la antena en distintos lugares para descubrir la mejor recepción.



Presione el botón de ENCENDIDO/APAGADO para operar las luces indicadoras LED del buscador de señal.

3. Buscar

Explore los canales en su TV.



1. Abra el menú de configuración o ajustes del televisor.
2. Seleccione buscar, sintonización automática, búsqueda de canales o exploración de canales, asegurándose de que esté configurado para buscar canales de señal abierta en lugar de los de cable.
3. Espere que el televisor complete la búsqueda de canales.

Consejos para escanear

- Consulte el manual del televisor o comuníquese con el fabricante del televisor para obtener instrucciones detalladas.
- Vuelva a realizar una búsqueda de canales de señal abierta cada vez que mueva la antena.

Consejos útiles sobre la antena

- Optimice la cantidad de canales al colocar la antena en diversas ubicaciones. **Asegúrese de realizar una nueva búsqueda de canales de TV en cada posición.** Consulte el manual de instrucciones de su TV de ser necesario.
- Posicione la antena a la mayor altura posible o cerca de una ventana para garantizar su funcionamiento óptimo.
- Visite www.antennaweb.org para determinar las estaciones televisivas disponibles y la ubicación de las torres de transmisión de su zona.

**¿PREGUNTAS? ¿PROBLEMAS?
CONTACTE CON NUESTROS EXPERTOS AL
1-844-816-0320**

HECHO EN TAIWAN

Philips y el emblema de escudo Philips son marcas registradas de Koninklijke Philips N.V. y se usan bajo licencia. Este producto ha sido fabricado y se comercializa bajo responsabilidad de Jasco Products Company y Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114, es el garante en relación a este producto.

Este producto tiene una garantía limitada de por vida. Visite www.philips.com/support para conocer los detalles de la garantía.

¿Tiene preguntas? Comuníquese al 1-844-816-0320 entre las 7 a. m. y 8 p. m. de lunes a viernes, hora del centro.



byjasco.com/recycle

GRACIAS POR SU COMPRA




Instrucciones fáciles

Escanee para ver un video instructivo paso a paso o visite <https://byjasco.com/452891>



Registre su producto Philips

Para ofertas exclusivas, que solo encontrará en Internet y ¡más! Escanee o visite byjasco.com/deals



¿Necesita más accesorios?

Obtenga antenas, amplificadores, divisores, cables y más, visite nuestro sitio web! byjasco.com/antennas



¿Le gusta nuestro producto?

Déjenos una reseña en Amazon.com o el sitio web de su comercio favorito.



¿Tiene problemas y necesita ayuda?

Llame a nuestros expertos en los EE. UU., de lunes a viernes, de 7 a. m. a 8 p. m. (hora del centro).

1-844-816-0320



Manual del usuario



NO DEVOLVER A LA TIENDA
¡LLÁMENOS PRIMERO!

¿Tiene preguntas? Comuníquese al

1-844-816-0320 entre las 7 a. m. y 8 p. m. de lunes

miércoles, CT (hora del centro).

