

User Manual for Remote Control Farmer Car

Thank you for using our toy product. For a better understanding of this product, please read the following instructions carefully before use, which will bring you a different operating experience.

Warning

- Age grade: Over 36 Months.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- This product contains batteries that are non-replaceable, this is a rechargeable battery.
- There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
- Do not dismantle, crush, incinerate or short-circuit battery.
- Contains a tool, the tool is only for adult use, keep away from children, this is not a toy.

Product Content

- 1 x Remote Control Car with Metal Tractor Head; 1 X Remote Control; 1 X Dumpable Trailer; Realistic Farm Accessories
- Electronic control product: This product is suitable for children aged 3 years and above. Children can play the toy after it is assembled or charged by adults.
 - Please use the product under adult supervision. Do not disassemble or modify it without authorization, as any modification may cause the product to malfunction.

Precautions for Use

1. The remote control car is powered by a non-replaceable 3.7 V lithium battery, while the remote control utilizes two 1.5 V AAA non-rechargeable batteries;
2. Adult supervision is required during charging of the rechargeable battery;
3. Turn off the product switch when charging rechargeable battery;
4. The power supply terminals must not be short-circuited;
5. Do not connect it to more power supplies than recommended;
6. When charging, please connect to a USB interface adapter or a USB power supply that complies with relevant national standards;
7. The car battery must be an Original Equipment Manufacturer (OEM) battery, and it should be charged by using the OEM-provided USB cable;
8. Unscrew the screws on the battery cover of the remote control with a screwdriver, and install the batteries with the correct positive and negative poles; Connect the round end of the USB charging cable to the charging port of the remote control car for charging;
9. Repair and maintenance: This product is composed of plastic, hardware and electronic components. It shall not be immersed in water, nor shall it be placed or operated in a humid environment for extended periods. Regularly inspect the wires, plugs, casing, and other components for any damage. Stop using it if any defect is found, until it is fully repaired.

2.4G Automatic Pairing Instructions

1. Install batteries into the remote control, and switch it to the "ON" position. The indicator light will flash. Turn on the remote control car switch to enter the pairing mode. Upon successful connection, the indicator light of the remote control will go out, while the indicator light of the remote control car will stay on. Note: If the connection is unsuccessful, please repeat the above operation.
2. Each control can be connected to one remote control car only. Once connected successfully, each car will not interfere with each other. Note: When multiple vehicles are used simultaneously, they can be connected sequentially.
3. When the remote control fails to pair, it will enter sleep mode after 45 seconds.
4. To pair with another remote control or remote control car of the same model, please remove the remote control batteries, and turn off the power switch of the remote control car before re-pairing.


How to Install Batteries

Remote Control



1. Open the battery cover of the remote control, and install 1.5 V AAA batteries according to the polarity indicated inside the battery compartment of the remote control;
2. Close the battery cover and secure the screws.

Remote Control Car

The remote control car is equipped with a built-in 3.7 V lithium battery. The location of the charging port is shown in the right diagram.




Instructions for Remote Control Features



The remote control utilizes two 1.5 V AAA batteries (purchased separately).


How to Charge

1. This is a new 3.7 V battery, which requires charging before use.
2. First, connect the round end of the USB charging cable to the charging port of the remote control car, then insert the USB charging plug into the USB port of the computer or other USB power supply. (Note: Please do not use a fast charger so as to avoid the USB charging cable from burning out.)
3. It takes approximately 2-3 hours for the battery to fully charge. The charging plug has an indicator light. The red light will be always on during charging, and it will go out when the battery is full. Do not overcharge, as charging for too long will not increase the battery capacity.
4. Regularly inspect the toy and batteries, as well as the wires and plugs of the charging cable. Stop using it if any defect is found, until it is fully repaired or replaced.
5. The car switch must be set to the OFF position before charging.



Set Operating Instructions


Height Adjustment




Rotate the adjustment device to make the front wheels of the truck contact the ground.



Connection Of Dump Trailer



Loading & Dumping Action



Short press the "Light Switch" button to control the light on and off. Long press the "Light Switch" button to initiate an automatic demonstration mode of the remote control car.

Troubleshooting

The battery charger of this toy must be picked up for inspection to prevent damage to wires and other components. If damaged, it must be repaired before use.

General Troubleshooting Methods

Symptoms of Malfunction	Causes of the Malfunction	Troubleshooting Methods
The car cannot move	1. The remote control is not connected or the remote control car switch is not turned on. 2. Batteries are not properly installed in the remote control or the car. 3. The rechargeable battery is running low.	1. Turn on the switches of the remote control car and the remote control again, and reconnect the remote control. 2. Install the batteries correctly into the remote control or remote control car. 3. Charge the rechargeable battery.
The car is uncontrollable or the remote control distance is short	1. The power of the remote control batteries or rechargeable battery is insufficient. 2. There may be interference sources near the site.	1. Replace the batteries in the remote control with new ones, or charge the rechargeable battery. 2. Change the venue.
Abnormal protection	The remote control car's functions are impeded by external forces, hindering its full motion capability, or the circuit battery is short circuited.	Turn on the power switch again, or remove the batteries and power it off before reinstalling it.

To Consumers

1. When playing with remote control cars indoors, please be careful not to cause damage to furniture or glassware.
2. Please play in a safe outdoor place. Do not operate the remote control car on roads or in crowds to avoid danger.
3. Stop playing immediately if you hear thunder while using the remote control car outdoors.
4. When the wheels are rotating, do not reach your hands close to avoid injury, and do not get hair, clothing, or other items caught in them.
5. Do not direct the remote control car towards people.
6. Do not throw or violently collide the remote control car.
7. When storing the remote control car, please keep it away from fire sources and high temperatures.
8. The car contains complex electronic circuits and numerous components. Do not disassemble or modify the circuit board at will.
9. If the remote control car is covered with mud or dust after use, please gently wipe it clean with a damp cloth.
10. Do not submerge the toy in water, as this will damage electronic components.

FCC Compliance Statement

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: This product contains small parts that pose a choking hazard and it is not suitable for children under 3 years old. Adults must be present during use for monitoring and guidance. This manual contains important information and should not be discarded for easy reference.