


100mm

65mm


User Manual

Model:G51/AIR51




5000mAh Qi2.1 Slim MagSafe Power Bank
for iPhone 12-17 and subsequent series

·Product Introduction




·Charge your phone or devices




Fully charge the product before first use
1) You can use Trickle-Charging mode to charge low-power devices.
2) After turning on the product, long-press button 3s to activate the Trickle-Charging mode. The power LED or display screen will start flashing. Double-click the button again to exit this mode.

·Recharge your Slim MagSafe Power Bank



·Pass-through Charging



The power bank can charge other devices while it is being charged.

·Specifications

Product Name: **Slim MagSafe Power Bank**
Model: **G51/AIR51**
Capacity: 5000mAh
USB-C Input: 5V $\approx$ 3A, 9V $\approx$ 1.8A
USB-C Output: 5V $\approx$ 2.4A, 9V $\approx$ 2A, 12V $\approx$ 1.5A
Wireless Charging: 5W/7.5W
Total Output: 5V $\approx$ 2.4A
Size: 104x65x9.8mm
Weight: 125g

Company Name: Shenzhen Esorun Technology Co., LTD
Address: Room 226, Building A, B, C, Zone B, Yuanfen Industrial Zone,
Taoyuan Community, Dalang Street, Longhua District, Shenzhen



User Tips

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- This wireless charger is not compatible with non-MagSafe phone cases, such as Otterbox Defender cases.
- Do not use an adapter with an output of 5V/1A (5W) or less.
- High temperatures will reduce charging speed and restrict power, which is something that happens to all wireless chargers. It is recommended that you charge your device in environments with temperatures below 25°C / 77°F.

IMPORTANT SAFETY INSTRUCTIONS

Please make sure to notice the following reminder:

- 1) The operating temperature of the product should be between 0°C and 40°C / 32°F and 104°F.
- 2) DO NOT place the product near a fire source or in a high-temperature environment. Avoid placing it in a car, kitchen, bathroom, or any other high-temperature and high-humidity areas. Exposure to fire or excessive heat may cause an explosion.
- 3) DO NOT use the product if it has been submerged in water. Keep it away from rain and snow.
- 4) Using chargers or charging cables not recommended or sold by the manufacturer, or those that do not meet local safety standards, may result in fire or injury.
- 5) Ensure someone is present while charging the product. Unplug the power when going out or leaving for an extended period of time.
- 6) DO NOT charge the product in places like bags, on beds, or sofas, as this can affect heat dissipation. Avoid covering it with clothing, bedding, or other items while charging.
- 7) DO NOT let children use the product unsupervised. Close supervision is required when the product is used near children.
- 8) DO NOT attempt to disassemble the product. For service or repairs, contact the manufacturer's after-sales service. Incorrect disassembly or reassembly can cause fire or injury.
- 9) The product may become hot during use, which is normal. Limit contact with high-temperature areas to less than 10 seconds.
- 10) The product contains a built-in lithium battery. Be aware of the risk of fire and burns. DO NOT attempt to replace the battery yourself.
- 11) DO NOT disassemble, strike, crush, or burn the product. If it swells, leaks, deforms, or overheats, stop using it immediately.