

Instruction Manual

Item Number: 25736



What's included:

1 x Wireless Speaker

1 x USB to Type-C charging cable

1 x Instruction Manual

LED Indicator:

Charging: Glowing Red LED

Charging Complete: Red LED off

Tech Specifications

Pairing Name: 25736

Battery capacity: 500mAh

Listening Time (at max vol): 2.5 hour

Charging Time: 2 hours

Instructions:

1. Charging the speaker:

a. Using a Regulated USB Adapter:

- Connect the provided USB cable to a regulated USB adapter.
- Connect the opposite, TYPE-C end of the cable to the charging port on the speaker.
- Plug the USB adapter into the outlet to begin charging.

b. Using a computer:

- Connect a USB cable to a USB outlet on your computer.
- * Make sure the computer is on to begin charging the speaker.

2. Connecting the speaker with Bluetooth:

a. Turn ON the power switch:

- Once on, the speaker will enter Bluetooth pairing mode.
- Using a Bluetooth enabled device, search the list of available options.

3. Using the Speaker:

- Use the audio device to control track selection and volume

* Note: In order to charge device, use only accessory cable (provided with device) or the cable included with your own device by the manufacturer.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

