


- SANGE**  
SINCE 1974
15. It is advised to only charge batteries at room temperatures between 5 degrees C - 35 degrees C. In lower or higher temperatures full charge cannot be achieved.
16. Depending on the capacity of the batteries, charging from "empty" to "full" can take several hours, even up to 6 hours or more.
19. Do not charge batteries when the radio is hot or exposed to heat or other sources.
20. It is advised to check the metal contacts of the batteries and of the charger inside the radio e.g. with a contact-spray from time to time.
21. Do not use a mix of old and new rechargeable batteries.
22. Do not use a mix of rechargeable and non-rechargeable batteries.
23. Do not use a mix of full and empty rechargeable batteries.
24. Do not use batteries that have a different mAh capacity.
25. Do not use damaged, deformed or leaking batteries.
26. Battery level indication is an approximate indication only and can vary with battery type that is used.
27. Batteries can become hot during charging.
28. In cold conditions the capacity of batteries will be much lower than when used at normal room temperature.
29. Batteries (even when supplied with the radio), as being consumables, do not fall under the warranty conditions of the radio.
30. Batteries should not be disposed of by incineration and with household waste.
31. Disposable batteries should be taken to a suitable recycling center if possible.
32. **CAUTION:** Risk of explosion if the battery is replaced by an incorrect type.

## PR-D12BT



- Controls**
- |  |   |
|--|---|
| ① Page button                                | ⑩ Volume down button  |
| ② Preset 1                                   | ⑪ Bluetooth pairing button                                    |
| ③ Preset 2                                   | ⑫ Source / Tuning step button                                 |
| ④ Preset 3 / Rewind button                   | ⑬ Clock / Time setting button                                 |
| ⑤ Play / Pause button                        | ⑭ Power / Standby button                                      |
| ⑥ Preset 5 / Fast-forward button             | ⑮ Radio alarm button  |
| ⑦ Speaker                                    | ⑯ Battery compartment   |
| ⑧ LCD display                                | ⑰ NiMH / Alkaline batteries switch                            |
| ⑨ Battery charging / Bluetooth LED indicator | ⑱ USB socket for software upgrade (for customer service only) |
| ⑲ Power / Standby / Sleep button             | ⑳ Telescopic antenna  |
| ⑳ Tuning control knob / Select / Seek button | ㉑ Headphone socket  |
| ㉒ Scan / Auto button                         | ㉓ DC IN socket  |
| ㉔ Volume up button                           |   |

### Display icons

- |                                       |                           |
|---------------------------------------|---------------------------|
| ① Signal strength meter               | ⑩ FM indicator            |
| ② FM stereo indicator (for Headphone) | ⑪ Battery error indicator |
| ③ Sleep / Snooze indicator            | ⑫ Buzzer alarm indicator  |
| ④ Battery power indicator             | ⑬ Radio alarm indicator   |
| ⑤ Bluetooth indicator                 | ⑭ Indicates Band in use   |

### Battery operation

1. Open the battery cover on the rear of the unit by lifting the latch.
- ▲ NOTE**  
When using NiMH batteries, check the NiMH / Alkaline switch position. If you use non-rechargeable batteries, make sure the NiMH / Alkaline switch located inside the battery compartment is switched to Alkaline position. If you use rechargeable batteries, make sure to switch NiMH / Alkaline switch to NiMH position.
2. Insert 4xLR6 (AA size) batteries into the spaces in the compartment.
3. Make sure all batteries are inserted with correct polarity as shown in the battery compartment. Reproache battery cover.
- When using NiMH batteries the battery switch must be placed in the alkaline position. Failure to do so could result in serious damage to the batteries or radio.
4. Reduced power, distortion, "bubbling" sound, and the symbol "E" flashing or empty battery icon flashing on the display are all signs that the batteries need replacing.
- If the radio is not to be used for an extended period of time, it is recommended that the batteries are removed from the radio. The device cannot be used with the connected Bluetooth devices. If already listening using batteries is anticipated, then the use of rechargeable batteries is recommended.

### Charging the batteries

- ▲ IMPORTANT**  
When using rechargeable batteries the battery switch must be placed in the NiMH position. Batteries will only be charged when the radio is switched off and connected to the AC adaptor.
- The charge indicator will flash red indicating that batteries are charging. Batteries will be fully charged in around 4-6 hours depending on their capacity. The charge indicator shows a steady red light when battery charging is complete.
- ▲ NOTE**  
Duration for charging your batteries fully can vary according to the mAh capacity of the batteries. Higher mAh batteries require longer charging time.
- During the charging process, if a battery is verified as faulty / damaged, the display will show the battery error icon with the corresponding battery number. "E" will flash on the display.

### Using the AC power adaptor

- The AC power adaptor is used with this unit in 9V DC at 1.2A center pin positive.
- Insert the adaptor plug into the DC socket on the left side of the radio. Plug the adaptor into a standard AC outlet.
- Whenever the adaptor is used, the batteries are automatically disconnected. The AC adaptor should be disconnected from the main supply when not in use.
- ▲ IMPORTANT**  
The AC adaptor is used as the means of connecting the radio to the power supply. The AC Adaptor used for the radio must meet the requirements of the power supply. The AC adaptor used for the radio must comply with the requirements of the power supply.

### Setting clock time

- Upon initial use of the radio after the batteries have been installed or the AC adaptor is plugged in, the display will flash "12:00".
- Rotate the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
1. Press and hold the Power button until the radio beeps. The display will show "12:00".
2. Press and hold the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
3. Press and hold the Power button until the radio beeps. The display will show "12:00".
4. Press the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

### Seek and Scan Tuning - FM / AM

1. Press the Power button to turn on the radio.
2. Select the required frequency band by pressing the Source button. For the FM band fully extend and rotate telescopic antenna to get best reception. For the AM band, rotate the radio to get the best signal. (Please note this radio has a built-in antenna.)
3. To seek up in frequency, rotate the Tuning control knob in a clockwise direction. It will press the Seek button. Your radio will seek in an upwards direction (low frequency to high frequency) and stop automatically when it finds a station of sufficient strength.
- To seek down in frequency, rotate the Tuning control knob in an anti-clockwise direction, then press the Seek button. Your radio will seek in a downwards direction (high frequency to low frequency) and stop automatically when it finds a station of sufficient strength.
- Scan Tuning: Press the Scan button, the radio will search and stop automatically about 6 seconds when it finds a radio station. Press the Scan button again within 6 seconds to listen to the found station. If you do not press the Scan button when it finds a radio station, after 6 seconds the radio will continue to search for the next available station.
- If you want to adjust the time, simply press the Clock button.
5. Press the Volume up / down button to set your required sound level.
6. To turn off the radio, press the Power button. The display will show "OFF".

### ATS tuning (Auto Tuning System) - FM / AM

- The radio features an Auto Tuning System (ATS) that will automatically store radio stations into the memory presets on the FM and AM band upon the signal strength of the incoming stations. ATMS / ATMS AM can be operated only when the radio is on.
1. Turn on the radio. Select either the FM or AM band by pressing the Source button.
2. Press and hold the Power button until the radio beeps. The display will show "12:00".
3. Press and hold the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
4. Press the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

### Manual Tuning - FM / AM

1. With your radio switched on, press the Source button to select the desired frequency band.
2. Press and hold the Power button until the radio beeps. The display will show "12:00".
3. Press and hold the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
4. Press the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

### Presetting stations - FM / AM

- The radio has 20 memory presets each for FM and AM radio.
1. With your radio switched on, press the Source button to select the desired frequency band.
2. Press and hold the Power button until the radio beeps. The display will show "12:00".
3. Press and hold the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
4. Press the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

### Recalling a preset station - FM / AM

1. With your radio switched on, press the Source button to select the desired frequency band.
2. Press and hold the Power button until the radio beeps. The display will show "12:00".
3. Press and hold the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
4. Press the Tuning control knob to select the desired time and press the Select button. The Tuning control knob will stop at the desired time. The wide blades and a third grounding prong are included. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

### Setting the alarm

- Your radio has two types of alarms which can be set to wake you up with AM / FM radio or buzzer alarm. Ensure that the time setting is complete before setting the alarm time. The alarms can be set while the unit is off or while playing. Alarms will be retained in the event of a power failure.

### Setting the radio alarm

1. Press and hold the radio alarm button until the radio alarm symbol flashes on the display followed by two beeps.
2. Rotate the Tuning control knob to select the desired time and press the Select button to confirm the hour setting.
3. Rotate the Tuning control knob to select the desired minute and press the Select button to confirm the minute setting. The buzzer alarm setting is now completed. The active radio alarm symbol is shown on the display.
4. To quick change the On / Off status of the buzzer alarm, press and release the buzzer alarm button.

### Disabling / cancelling alarm setting

- To cancel the radio / buzzer alarm symbol before the alarm sounds, press the radio / buzzer alarm button. The display will show "OFF". The radio / buzzer alarm setting will disappear from the display.

### Snooze function

- When the radio alarm sounds, pressing any button other than the Volume buttons and Power button will silence the alarm for 5 minutes. When the buzzer alarm sounds, the buzzer alarm can be silenced for 5 minutes by pressing any button other than the Power button. The display will show the snooze symbol and "Z" will flash on the display. To cancel the Snooze timer while the alarm is suspended, press the Power button to cancel the alarm.

### Sleep function

- The sleep timer will automatically switch off the radio after a preset time has elapsed.
1. Press and hold the Power button until the radio beeps. Keep long pressing the Power button and the display will cycle through the preset options (00:05-15:00-30:00-45:00-1 hour).
2. Press and hold the Power button until the radio beeps. The display will show the selected sleep time.
3. Release the Power button when the required sleep time appears on the display. The Sleep symbol will show on the display.
4. To cancel the sleep function, press the Power button. The Sleep symbol will disappear and the radio is switched off.

### Software version / Setting the time format / tuning step

- Software version**  
The software display cannot be altered and is only for your reference.
1. Press the Power button to turn off the radio.
2. Press and hold the Source button until the radio beeps. Software version number (e.g. Pxx) is shown on the display.

### Setting the time format / tuning step

1. After the software version is shown on the display, keep long pressing the Source button until the time format (e.g. 24H) is shown on the display. Rotate the Tuning control knob to select "12H" or "24H".
2. Press the select button to confirm the time format setting and enter the AM tuning step setting.
3. Rotate the Tuning control knob to select "10" or "9" kHz. Press the select button to confirm the AM tuning step setting and enter the FM tuning step setting.
4. Rotate the Tuning control knob to select "100", "200" or "50" kHz. Press the select button to confirm the FM tuning step setting.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**
1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Pairing and playing your Bluetooth device for the first time

1. With your radio switched on, press the Source button to select Bluetooth function. Bluetooth icon will show on the display. The Bluetooth LED indicator on the radio will flash a fast blue to show the radio is discoverable.
2. Activate Bluetooth on your device according to the device's user manual to link to the radio. Locate the Bluetooth device list and select the device name "PR-D12BT" (With some Smartphones that are equipped with earlier versions than 5.0, the Bluetooth device can pair or link with your radio).
3. Once connected, there will be a confirmation tone sound and the Bluetooth LED indicator will turn a solid blue. You may simply select any play music from your source device.
4. The volume control can be adjusted from your source device, or directly from the radio. Use the controls on your Bluetooth-enabled device or on the radio to play / pause and navigate tracks.

### Listening to music via Bluetooth streaming

- You need to pair your Bluetooth device with your PR-D12BT before you can auto-link to play / stream Bluetooth music through your PR-D12BT. Pairing creates a "bond" so the two devices can recognize each other.
- Pairing and playing your Bluetooth device for the first time**

