


USER 'S MANUAL

Vacuum cleaner



VC006

FC YTE PRO

MADE IN CHINA

REGISTER
NOW!

18 months
Warranty

As a special thank-you for registering your YTE PRO unit, you'll automatically receive an additional 6 months added to your limited manufacturer's warranty!

All you need to do is send your order ID to our Email: prosupport@ytetech.com, or enter your order ID to activate the extended warranty online at <https://ytetech.com/?vipwarranty>

This warranty only cover orders from authorized brand online stores and our official website. We are not responsible for any purchases from other distribution channels.

- ✓ Any questions, please REACH OUT to YTE PRO before returning it, as we provide hassle-free after-sales support.
- ✓ FREE upgrade to FULL Replacement Guarantee - no need to return.
- ✓ Once registered, you will be ensured that if anything goes wrong with your product, we will either send you a brand new unit as a replacement (Absolutely FREE) or provide a FULL refund of your order.
- ✓ Just send your Amazon Order ID to Email prosupport@ytetech.com or scan the QR code to activate the extended warranty.

NOTE: Must register within 7 days after receiving your new product.



Send:

prosupport@ytetech.com

Subject:

Warranty

Order ID:



WARNING

Please read this manual carefully before using this product and keep it for future reference.

- All parts must be completely dry before reassembly.
- The device will not function properly while charging.
- Please ensure that the HEPA filter is properly installed before use to avoid damaging the machine.
- Do not place in high temperature or humidity.
- It is forbidden to modify, disassemble, crush, or throw into fire.
- Do not continue to use if there is an abnormality.
- It is strictly forbidden to use unlicensed or incompatible adapters and charging cables to charge the product, which may cause malfunction and danger.
- If you do not use this product for a long time, please store the product in a cool and dry environment, in order to ensure the service life of the product battery, please fully charge and discharge the product at least once every 3 months.
- This product is not intended for use by children or persons with physical, sensory, or mental impairments.

NOTE

- Short press the power button, the vacuum cleaner will not start, it is a low battery, please charge it in time.
- Please use the charging cable supplied with this machine to charge the product, or use a mobile phone adapter with safety certification of 5V/2A and above and the standard charging cable to charge the product, and it is forbidden to purchase an adapter to charge the product without permission.
- As the number of times the product is used increases, the vacuum cleaner battery life may decline.
- Clean the HEPA filter element in time, otherwise it will affect the dust removal effect.
- After use, please keep the product in a cool, dry, away from high temperature, high humidity and high dust environment.
- It is strictly forbidden to inhale combustible substances such as cigarette butts, freshly extinguished charcoal ash and burning paper scraps when using this product to remove dust.
- Due to the built-in high-rate lithium battery, it is strictly forbidden to disassemble the product in case of abnormal noise or other suspected quality problems.


- Do not use this product to absorb water and wet objects, otherwise it will damage the motor and cause permanent damage to the product, and the product quality problems caused by this behavior are not covered by the product warranty.
- After use, please keep out of reach of children, children are strictly prohibited from operating without permission.
- This product is not suitable for use in high magnetic field environment.



Do not suction combustibles.



Do not absorb water or moisture



Do not refit, disassemble or squeeze




Do not throw into fire



Do not cover the air intake/outlet with your hands or foreign objects



Do not inhale sharp hard objects




Not suitable for use in high magnetic field environments




Place in the car away from direct sunlight

PRODUCT INTRODUCTION

- ❶ Air intakes
- ❷ Dust bin
- ❸ HEPA filter
- ❹ On/off power button
- ❺ Air outlet
- ❻ Handle
- ❼ Type-C charging port
- ❽ Indicator light



PACKAGE CONTENTS



Host



Brush




Type-C charging cable



Long nozzle



Hose connector



Corrugated hose



Small brush



user's manual




Floor brush

PRODUCT PARAMETERS

Model	VC006
Working voltage	7.4V
Battery specification	2000mAh*2
Charging time	About 4H
Charging voltage	DC-5V
Dust cup capacity	400ML
Charging port	Type-C
Working temperature	0°F~40°F
Storage temperature	-10°F~60°F
Material	ABS
Product size	346X87X104mm
Product weight	538g

CHARGING METHOD

During the use, the battery power will gradually decrease with the increase of the use time. If the battery power is too low and the device is shut down during the use, please use the charging cable to charge the product.




1, the machine charging, the indicator light is red;

2, the machine is full of power, the indicator light is green.

Recommend using 5V $\equiv$ 2.4A charger.

5V $\equiv$ 2.4A




1. Put the vacuum cleaner on the desktop/plane;
2. Insert the USB power cable into the charging hole of the vacuum cleaner;
3. Connect the other end of the power cord with the 5V $\equiv$ 2.4A and above USB socket, such as mobile phone charger, mobile power bank, etc.

(Tip: This product does not contain adapters)

ACCESSORIES INSTALLATION AND USE

Install the corresponding accessories according to different occasions.


▲ Note: Please turn off the vacuum cleaner before replacing the accessories.



❶ Corrugated hose: It can be twisted at any angle, and other accessories can be added to clean all kinds of corners that cannot be reached.



❷ Brush: It has the dual functions of suction and wiping, and is suitable for cleaning dust on various surfaces such as cushions, floor cushions, keyboards, and air conditioning outlets.




❸ Floor brush: suitable for dust cleaning of floor, trunk, mattress, sofa and all kinds of large flat surface.




- ④ Long nozzle: It is suitable for dust cleaning in various crevices such as car doors, seats, cabinet corners, drawers and ashtrays.

DUST REMOVAL OPERATION

This product is a multifunctional wireless vacuum cleaner for both car and home use, please fully charge the battery before use. Please use the accessories reasonably and correctly to achieve the best dust removal effect.



Short press the power button once, Power on.



Press the power button again, Power off.


⚠ Note: If the machine is suddenly shut down during use, please check whether the air inlet is blocked, if it is blocked, please clean it up and continue to use it normally. If the system is turned off due to insufficient power, please charge the product in time Electricity.

DISASSEMBLY AND CLEANING

Please clean up the dust bin in time after each use, and keep the dust bin dry.



- ① Rotate the dust bin to remove the dust bin from the fuselage.



- ② Separate dust bin from HEPA filter element.



- ③ Pour the garbage in the dust collection hood into the garbage can.



- ④ If necessary, use a slightly damp rag or Disposable paper towels to clean the dust bin.



- ⑤ HEPA filter can be washed with water.

※Do not expose to the sun



- ⑥ Let the HEPA filter dry before using again.

Failure Phenomena	Analysis of causes	Solutions
The vacuum cleaner is not working	Low battery level	Use when fully charged
	Excessive use and high temperature	Leave to cool, then turn it on again and use
	The power switch is not turned on	Turn the switch on button correctly
	Motor blocking protection	Clean the suction prot
	Damaged motor / damaged battery	Please contact the after-sales service via prosupport@ytetech.com .
	The device is charging.	The device will not function properly while charging.
Excessive noise	The dust cup is full	Clean up the dust cup
	The suction port is blocked by a foreign object	Clean the suction port
Reduced suction power	Clogged HEPA / not sufficiently dried	Clean the HEPA / dry it well
	A foreign object stuck in the suction port	Clean the suction port
	The dust bowl is full	Clean the dust bowl
Unable to recharge	Poor connection of the adapter to the AC power supply	Ensure the adapter plug is frmly connected to the powersupply
	Bad connection between the adapter and the mainframe	Ensure the adapter plug is correctly connected to the mainframe



Scan the QR Code to Activate Warranty

GET MORE HELP HERE

 prosupport@ytetech.com

 <https://ytetech.com>

 facebook.com/ytetech